



- U.S.A. : **KUBOTA TRACTOR CORPORATION**
1000 Kubota Drive, Grapevine, TX 76051
Telephone : 888-4KUBOTA
- Canada : **KUBOTA CANADA LTD.**
5900 14th Avenue, Markham, Ontario, L3S 4K4, Canada
Telephone : (905)294-7477
- France : **KUBOTA EUROPE S.A.S**
19-25, Rue Jules Vercurysse, Z.I. BP88, 95101 Argenteuil Cedex, France
Telephone : (33)1-3426-3434
- Italy : **KUBOTA EUROPE S.A.S Italy Branch**
Via Grandi, 29 20068 Peschiera Borrome (MI) Italy
Telephone : (39)02-51650377
- Germany : **KUBOTA (DEUTSCHLAND) GmbH**
Senefelder Str. 3-5 63110 Rodgau /Nieder-Roden, Germany
Telephone : (49)6106-873-0
- U.K. : **KUBOTA (U.K.) LTD.**
Dormer Road, Thame, Oxfordshire, OX9 3UN, U.K.
Telephone : (44)1844-214500
- Spain : **KUBOTA ESPAÑA S.A.**
Avenida Recomba No.5, Poligno Industrial la Laguna, Leganes, 28914 (Madrid) Spain
Telephone : (34)91-508-6442
- Australia : **KUBOTA AUSTRALIA PTY LTD.**
25-29 Permas Way, Truganina, VIC 3029, Australia
Telephone : (61)-3-9394-4400
- Malaysia : **KUBOTA MALAYSIA SDN. BHD.**
Lot 766, Jalan Subang 4, off Persiaran Subang Sungai Penaga Industrial Park,
47500 Subang Jaya
Telephone : (60)-3-7890-3533
- Philippines: **KUBOTA PHILIPPINES, INC.**
232 Quirino Highway, Baesa, Quezon City 1106, Philippines
Telephone : (63)2-422-3500
- Taiwan : **SHIN TAIWAN AGRICULTURAL MACHINERY CO., LTD.**
16, Fengping 2nd Rd, Taliao Shiang Kaohsiung 83107, Taiwan R.O.C.
Telephone : (886)7-702-2333
- Indonesia : **PT KUBOTA MACHINERY INDONESIA**
Tower A at EightyEight@Kasablanka Lantai 16
Jalan Raya Casablanka Kav. 88, Jakarta 12870 Indonesia
Telephone : (62)-21-29568-720
- Thailand : **SIAM KUBOTA CORPORATION CO., LTD.**
101/19-24 Moo 20, Navanakorn Industrial Estate, Tambon Khlongnueng, Amphur Khlongluang,
Pathumthani 12120, THAILAND
Telephone : (66)2-909-0300
- Korea : **KUBOTA KOREA CO., LTD.**
41-27, Jayumuyeok-gil, Baeksan-myeon, Gimje-si, Jeollabuk-do, Korea
Telephone : (82)-63-544-5822
- India : **KUBOTA AGRICULTURAL MACHINERY INDIA PVT. LTD.**
No.15, Medavakkam Road, Sholinganallur, Chennai-600119, T.N., India
Telephone : (91)44-6104-1500
- Vietnam : **KUBOTA VIETNAM CO., LTD.**
Lot B-3A2-CN, My Phuoc 3 Industrial Park, Thoi Hoa Ward, Ben Cat Town, Binh Duong Province, Vietnam
Telephone : (84)-274-3577-507

KUBOTA Corporation


BD . G . 10 - 10 . - . AK

English (U.S.A.)
Code No. 7K505-7991-9

OPERATOR'S MANUAL

KUBOTA BACKHOE

MODEL BH92



1AJABALAP0030

B
H
9
2

READ AND SAVE THIS MANUAL



ABBREVIATION LIST

Abbreviations	Definitions
2WD	2 Wheel Drive
4WD	4 Wheel Drive
API	American Petroleum Institute
ASABE	American Society of Agricultural and Biological Engineers, USA
ASTM	American Society for Testing and Materials, USA
DIN	Deutsches Institut für Normung, GERMANY
DT	Dual Traction [4WD]
fpm	Feet Per Minute
GST	Glide Shift Transmission
Hi-Lo	High Speed-Low Speed
HST	Hydrostatic Transmission
m/s	Meters Per Second
PTO	Power Take Off
RH/LH	Right-hand and left-hand sides are determined by facing in the direction of forward travel
ROPS	Roll-Over Protective Structures
rpm	Revolutions Per Minute
r/s	Revolutions Per Second
SAE	Society of Automotive Engineers, USA
SMV	Slow Moving Vehicle
UDT	KUBOTA UDT fluid (Transmission-hydraulic fluid)

California Proposition 65

 **WARNING:** Handling passenger or off-highway motor vehicle parts can expose you to chemicals such as phthalates and lead, which can cause cancer and reproductive harm. To minimize exposure, service the vehicle in a well-ventilated area, wear gloves, and wash your hands. For more information see www.P65Warnings.ca.gov/motor-vehicle-parts.

FOREWORD

Thank you for the purchase of a Kubota product.

Before using this product, read this manual carefully and use the product correctly. After reading, keep the manual in a safe and easy-to-access place for future reference.

Note that product specifications are subject to change without prior notice. The product delivered to you may differ slightly from the product described in the manual.



SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to assemble or use this unit.



DANGER : Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING : Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION : Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.

IMPORTANT : Indicates that equipment or property damage could result if instructions are not followed.

NOTE : Gives helpful information.

CONTENTS

▲ SAFE OPERATION	▲ -1
BEFORE OPERATING BACKHOE	1
OPERATING THE BACKHOE	1
SAFETY FOR CHILDREN	1
DRIVING THE TRACTOR ON THE ROAD	1
SERVICING THE BACKHOE	2
SAFETY LABELS	3
CARE FOR SAFETY LABELS	5
SERVICING OF BACKHOE	1
SPECIFICATIONS	2
BACKHOE SPECIFICATIONS	2
Dimensions	2
Specifications	3
Lift Capacity (Per SAE J31)	4
BACKHOE TERMINOLOGY	5
PRE-OPERATING INSTRUCTIONS	6
PRE-OPERATION CHECKS	6
OPERATOR'S SEAT	6
BALLAST	6
OPERATION	6
OPERATING INSTRUCTIONS	7
OPERATING SPEED	7
BACKHOE CONTROLS	7
Boom & Swing Lever	8
Dipperstick & Bucket Lever	8
Stabilizer Control Levers	8
PLACING THE STABILIZERS	9
GENERAL BACKHOE OPERATION	9
Dipperstick Digging	10
Spoil Pile Location	10
Straight Wall or Cemetery Digging	11
Stabilizer pads	11
TRANSPORTING	12
Driving to the Job-site	12
Trailer Transporting	12
AUXILIARY HYDRAULIC VALVE SYSTEM (if equipped)	12
Remote Control Valve Coupler Connecting and Disconnecting	12
Auxiliary Hydraulic Valve Pedal	13
MAINTENANCE	14
DAILY CHECKS	14
EVERY 50 HOURS	16
Checking Sub Frame Bolt Torque	16
LUBRICATION	16

TIRE INFLATION	17
BUCKET SERVICE	17
Changing the Backhoe Bucket	17
Changing the Bucket Teeth	17
REMOVING THE BACKHOE	18
REMOVAL OF THE BACKHOE	18
STORAGE OF THE BACKHOE	20
REINSTALLING THE BACKHOE	21
GENERAL TORQUE SPECIFICATION	23
ADAPTERS, ELBOWS AND OTHERS	24



SAFE OPERATION

Most backhoe equipment accidents can be avoided by following simple safety precautions. These safety precautions, if followed at all times, will help you operate your backhoe safely.

BEFORE OPERATING BACKHOE

1. Know your equipment and its limitations. Allow only trained personnel to operate or service this equipment. Read and understand all instructions and precautions in this manual before service or operation. Also read and understand all instructions and precautions found in the tractor and loader operator's manuals before using this equipment.
2. For safe operation, check the mounting bolts for tightness and that the mount levers are in the right position before operation.
3. Never operate tractor with backhoe attached and loader removed.
4. Check for buried material such as electrical, telephone, gas and water lines. When in doubt, contact local utility companies for their buried location prior to operating the backhoe.
5. Replace any safety decal that becomes damaged, lost or illegible. Also renew all decals when repainting.

OPERATING THE BACKHOE

1. Do not allow anyone other than the operator on the unit while in operation or transport.
2. Use care when operating on slopes to avoid tip-over. Travel at a speed compatible with safe operation, especially when operating on uneven terrain, crossing ditches or while turning.
3. Operate the backhoe from the backhoe operator's seat only.
4. When using on slopes, one stabilizer may be lower than the other. Use extreme care during excavation as risk of tip-over will increase.
5. When digging on a hillside, always dump the bucket on the uphill side of excavation.
6. To reduce the risk of tip-over on a slope, place the spoil to the high side of the excavation.
7. Do not dig under the stabilizer or tractor, especially in soft or sandy conditions. Take extra precaution in wet or thawing ground.
Under these conditions the ground can become unstable and may collapse under the weight of the machine and may cause the unit to tip over.
8. Never operate the machine or any equipment while under the influence of alcohol or other drugs, or while fatigued.
9. When leaving the machine unattended, be sure to lower the backhoe to the ground. Set the parking brake, then shut the engine off and remove the key.


SAFETY FOR CHILDREN

Tragic accidents can occur if the operator is not alert to the presence of children. Children are generally attracted to machines and the work being done. Never assume children will remain where you last saw them.

1. Keep children out of the operating area and under the watchful eye of another responsible adult.
2. Be alert and turn the machine off if children enter the work area.
3. Before and when backing, look behind and down for small children.
4. Never carry children while operating the machine. They may fall off and be seriously injured or interfere with safe operation of the machine.
5. Never allow children to play on the machine or attachment even when turned off.
6. Never allow children to operate the machine even under adult supervision.
7. Use extra care when approaching blind corners, shrubs, trees, or other obstructions that might hide children from sight.

DRIVING THE TRACTOR ON THE ROAD

1. Raise and center the boom, close the dipperstick, curl the bucket and engage the boom and swing locks before transporting the machine.
2. Check the local codes or regulations that may apply to tractor / loader / backhoe operation on public streets or highways, before transporting or traveling. Use SMV emblem and warning flashers as required. (SMV: Slow Moving Vehicle)



(1) SMV emblem

SERVICING THE BACKHOE

1. Before disconnecting hydraulic lines, relieve all hydraulic pressure by moving the controls.
2. Always use personal protection devices such as safety goggles and gloves when servicing or repairing the machine.
3. Lower the backhoe to the ground and shut the engine off before servicing.
4. When servicing or repairing pins in cylinder ends, bucket, etc., always use a brass drift and hammer. Failure to do so could result in injury from flying metal fragments.
5. To avoid serious personal injury, keep clear of working area of the backhoe.
6. When servicing or checking underneath, do not get under the machine while it is being held with only the bucket, backhoe or stabilizers. Securely support with jackstands.
7. For your safety, do not work under any hydraulically supported machine elements. They can settle, suddenly leak down, or be accidentally lowered.
8. Escaping hydraulic fluid under pressure can have sufficient force to penetrate the skin, causing serious personal injury. Before applying pressure to the system, be sure that all connections are tight and that lines, pipes and hoses are not damaged. Fluid escaping from a very small hole can be almost invisible. Do not use hands to search for suspected leaks, use a piece of cardboard or wood. If injured by escaping fluid, see a doctor at once. Serious infection or allergic reaction will develop if proper medical treatment is not administered immediately.



1BAACAAAP010B

9. Do not tamper with any backhoe control valve relief pressure setting. The relief valve pressure is preset at the factory. Changing the setting can cause overloading of the backhoe and the tractor, and serious personal injury or death may result.
10. Do not modify the backhoe for any reason. Modifying the backhoe can cause an unstable condition of the tractor / loader / backhoe combination and serious personal injury or death may result.


SAFETY LABELS

(1) Part No. 75597-7528-1



1AJABAAAP064A

(2) Part No. 75595-7529-3



1AJABAAAP073A

(3) Part No. 75595-7524-2




1AJABAAAP067A

(4) Part No. 7K500-7532-1



1AJABAAAP066A




1AJABALAP0180

(1) Part No. 7K523-8452-1




1AGAJBJAP034E

[BH4949 MECHANICAL THUMB] (Option for BH92)



1AJABALAP038A

[BT4598 HYDRAULIC THUMB] (Option for BH92)



1AJABALAP039A

1AJABALAP0400

(1) Part No. 75595-7517-2 (Both sides)



1AJABAAAP068A

(2) Part No. 75597-7517-3




1AJABAAAP074A

(3) Part No. 7K500-7531-1



1AJABAAAP069A



1AJABALAP002A

1AJABALAP0190

CARE FOR SAFETY LABELS

1. Keep the safety labels clean and free from obstructing material.
2. Clean the safety labels with soap and water, and dry the safety labels with a soft cloth.
3. Do not spray high-pressure water directly on the safety labels, otherwise the safety labels may peel off.
4. Replace damaged or missing safety labels with new safety labels from your local KUBOTA Dealer.
5. If a component with safety label(s) attached is replaced with new component, make sure that new safety label(s) is (are) attached in the same location(s) as the replaced component.
6. Attach new safety labels by applying on a clean, dry surface and pressing any bubbles to outside edge.

SERVICING OF BACKHOE

Your dealer has knowledge of your new backhoe and has the desire to help you get the most value from it. After reading this manual thoroughly, you will find that you can do some of the regular maintenance yourself.

However, when in need of parts or major service, be sure to see the KUBOTA dealership which you purchased your equipment from or a local KUBOTA dealer.

When in need of parts, be prepared to give your dealer the backhoe model and serial number.


Locate the serial number now and record it in the space provided.

The reference to left hand and right hand used in this manual refers to the position when seated in the operator's seat at backhoe position and facing rearward of the tractor.

KUBOTA BACKHOE

Model	BH92
Serial Number	
Date of Purchase	
Name of Dealer	

(To be filled in by purchaser)



(1) Serial number

SPECIFICATIONS


BACKHOE SPECIFICATIONS

■ Dimensions

Item		BH92
Transport height	(A)	2542 mm (100.1 in.)
Stabilizer spread-transport	(B)	1758 mm (69.2 in.)
Ground clearance	(C)	323 mm (12.7 in.)
Overall width	(E)	1810 mm (71.3 in.)
Maximum digging depth	(F)	2816 mm (110.9 in.)
Digging depth, 2 ft. flat bottom	(G)	2789 mm (109.8 in.)
Digging depth, 8 ft. flat bottom	(H)	2312 mm (91.0 in.)
Operating height, fully raised	(J)	3775 mm (148.6 in.)
Loading height	(K)	2141 mm (84.3 in.)
Loading reach	(L)	1360 mm (53.5 in.)
Reach from swing pivot	(M)	3819 mm (150.4 in.)
Swing pivot to rear axle center line	(N)	1069 mm (42.1 in.)
Bucket rotation	(P)	180 deg.
Stabilizer spread-operating	(R)	2336 mm (92.0 in.)
Angle of departure per SAE J1234	(A3)	20.6 deg.
Leveling angle	(U)	10.6 deg.
Swing arc		180 deg.

NOTE :

- The specifications are taken with KUBOTA L5740-3 tractor with foldable ROPS. (Tire size: Front 9.5-16, Rear 14.9-26)



■ Specifications

Digging force (Per SAE J49)

With bucket cylinder	4548 lbs (20230 N)
With dipperstick cylinder	2698 lbs (12000 N)

Cycle Time (seconds)

Boom cylinder, extend	3.9
Boom cylinder, retract	3.2
Swing cylinder, from 90 degrees to center	1.8
Dipperstick cylinder, extend	3.7
Dipperstick cylinder, retract	2.7
Bucket cylinder, extend	2.9
Bucket cylinder, retract	1.9
Stabilizer cylinder, max. height to ground	1.5
Stabilizer cylinder, ground to max. height	1.2

Hydraulic cylinders


	Boom cm (in.)	Dipperstick cm (in.)	Bucket cm (in.)	Stabilizer cm (in.)	Swing cm (in.)
Rod diameter	4.0 (1.57)	4.0 (1.57)	4.0 (1.57)	4.0 (1.57)	3.5 (1.38)
Cylinder bore	8.0 (3.15)	7.5 (2.95)	6.5 (2.56)	7.0 (2.76)	6.0 (2.36)

Bucket Sizes



	Width cm (in.)	SAE Struck Capacity m ³ (cu-ft)	SAE Heaped Capacity m ³ (cu-ft)	Number of Teeth	Weight kg (lbs)
Trenching 12"	30.5 (12)	0.034 (1.19)	0.042 (1.47)	3	54 (119)
Trenching 16"	40.6 (16)	0.047 (1.67)	0.061 (2.16)	3	66 (146)
Trenching 18"	45.7 (18)	0.054 (1.91)	0.071 (2.51)	4	69 (152)
Trenching 24"	61.0 (24)	0.074 (2.63)	0.102 (3.60)	5	80 (176)
Trenching 30"	76.2 (30)	0.095 (3.34)	0.133 (4.69)	6	92 (203)
Trenching 36"	91.4 (36)	0.115 (4.06)	0.164 (5.78)	7	104 (229)

■ Lift Capacity (Per SAE J31)

Lift capacities shown are 87% of maximum lift force, according to SAE definition.



BACKHOE TERMINOLOGY



- (1) Backhoe bucket (Quick bucket : Option)
- (2) Bucket teeth
- (3) Link, bucket
- (4) Cylinder, bucket
- (5) SMV emblem
- (6) Dipperstick
- (7) Thumb bracket
- (8) Thumb (Option)
- (9) Cylinder, dipperstick
- (10) Boom
- (11) Cylinder, boom
- (12) Boom lock lever
- (13) Swing frame
- (14) Main frame
- (15) Cylinder, swing
- (16) Stabilizer
- (17) Stabilizer pad
- (18) Cylinder, stabilizer
- (19) Joystick control
- (20) Auxiliary hydraulic valve pedal (Option)

- (21) Stabilizer control
- (22) Swing lock pin
- (23) Seat

PRE-OPERATING INSTRUCTIONS

PRE-OPERATION CHECKS

Prior to starting the engine, make pre-operation checks according to " MAINTENANCE ".




CAUTION


To avoid personal injury:

- Read " SAFE OPERATION " section in the front of this manual.
- Read the safety labels located on the backhoe.
- Make sure the swing lock pin is set before entering or exiting the backhoe operator area.

OPERATOR'S SEAT



(1) Operator's seat (backhoe position)



(2) Support link

(3) Lock plate

1. Tilt the seat down at the front to provide foot space, and watch your step and use caution and do not use controls as handholds when getting on or off.
2. Before sitting down, make sure the support link is resting on the lock plate and the seat is stable.

3. To avoid pinching a hand, keep them away from seat support link.

BALLAST



WARNING

To avoid serious personal injury or death:

- Never remove loader when backhoe is attached to ensure tractor stability at all times.

IMPORTANT :

- Do not add liquid ballast or any other weights to the front tires.
- While BH92 backhoe is installed on the tractor, liquid ballast in the rear tires should be removed.

OPERATION

1. BH92 backhoe is approved for use on:
 - L3240-3, L3540-3, L3940-3, L4240-3, L4740-3, L5040-3, L5240-3 and L5740-3 tractors with foldable ROPS or CAB, LA514, LA724 or LA854 Loader and applicable backhoe mount Kit only.
 - L3240, L3540, L3940, L4240, L4740, L5040, L5240 and L5740 tractors with foldable ROPS, LA514, LA724 or LA854 Loader and applicable backhoe mount Kit only.
 - L4400-1, MX4700, MX4800, MX5100, MX5200 and MX5800 tractors with foldable ROPS, LA703, LA844 or LA1065 Loader and applicable backhoe mount kit only.
 - L4600, L4701 and L4802 tractors with foldable ROPS, LA764, LA765 or LA766 Loader and applicable backhoe mount kit only.
 - L3560, L4060, L4760, L5060, L5460, L6060 tractors with foldable ROPS or CAB, LA805 or LA1055 Loader and applicable backhoe mount kit only.
2. The BH92 backhoe can not be mounted on a tractor together with mid mount mower.
3. When using other implements with backhoe removed, mount the 3-point linkage to the tractor.
4. It is necessary to have the backhoe detached when using rear remotes, the 3-point hitch or any other valves that are downstream of the backhoe valve. Failure to do this may cause the exceeding allowable back pressure to break the seal or case of the backhoe valve.
5. Removal and reinstallation of backhoe sub frame should be performed by your KUBOTA dealer.
6. Save the loader sub frame and the 3-point linkage components which are removed.

OPERATING INSTRUCTIONS

OPERATING SPEED



CAUTION

To avoid personal injury:

- Use care when operating tractor on slopes to avoid tip-over. Travel at speed compatible with safe operation, especially when operating in uneven terrain, crossing ditches, and while turning, or upset may occur.

1. This backhoe can be operated at any engine speed from about 75% of rated rpm to factory rated rpm. The backhoe is most efficient at rated engine speed. However, in special digging conditions, for optimal fuel economy, or in residential neighborhood where noise may be a consideration, the engine speed can be lowered to about 75% of rated rpm.
2. When operating in temperature below 0 °C (32 °F), run the tractor engine below about 50% of rated rpm until the oil temperature exceeds 0 °C (32 °F).

BACKHOE CONTROLS




CAUTION

To avoid personal injury:

- For all excavation work, operate the backhoe from the backhoe operator's seat only.
- Do not tamper with any backhoe control valve relief pressure setting.

The relief valve is preset at the factory. Changing the setting can cause overloading of the backhoe and the tractor and serious personal injury may result.

The backhoe is controlled by using the two lever "joystick" system. The left lever controls the boom and swing circuits, and the right lever controls the dipperstick and bucket circuits. The further the levers are moved from neutral, the faster the component will move. Learn the feature of the controls for smooth and precise component movement.




- (1) Boom and swing lever
 (2) Dipperstick and bucket lever
 (3) Stabilizer control lever, left
 (4) Stabilizer control lever, right

■ Boom & Swing Lever

Pushing the lever forward will lower the boom, and pulling it back will raise it.


Movement of the lever to the left will swing the bucket to the left, and right lever movement will swing to the right. By moving the lever out of the plus "+" position; into an "X" relationship, it is possible to raise or lower and swing at the same time.



(1) Boom and swing lever

■ Stabilizer Control Levers

Moving the levers downward will lower the stabilizers, and upward lever movement will raise them.




(1) Stabilizer control lever, left
(2) Stabilizer control lever, right

■ Dipperstick & Bucket Lever

Pushing the lever forward will crowd out the dipperstick and the bucket and pulling it back will crowd them in. Lever movement to the left will curl the bucket to fill it, and right lever movement will dump the bucket.

Again, movement into an "X" relationship will crowd in and fill the bucket, or crowd out and dump the bucket.

With experience, the combination of both "joystick" levers will allow lift, swing, crowd out and spoil dumping, all in one smooth movement, or lowering, swing, crowd in and bucket filling with reverse movement.



(1) Dipperstick and bucket lever

PLACING THE STABILIZERS



CAUTION


To avoid personal injury:

- When working on slopes, one stabilizer may be lower than the other. Use extreme care during excavation as risk of overturn will increase.
- When digging on a hillside, always dump the bucket on the uphill side of excavation.
- To reduce the risk of overturn on a slope, place the spoil to the high side of the excavation.

1. Lower the stabilizers and remove the weight of the backhoe from the rear wheels. However, one or both rear tires should remain in light contact with the ground. This will give the backhoe the widest possible stance and the lowest center of gravity.

If the rear wheels are raised too high, digging depth will be reduced and undue stress will be exerted on the backhoe frame components.

If the slope is unusually steep, cut a level surface with the loader and pile the spoil on the downhill side. Backdrag and pack the spoil so it will support the stabilizer on the low side. This procedure is recommended when a wall, tree line or other obstruction prevents placing backhoe spoil on the high side of the excavation.



2. The loader bucket should be lowered to give the backhoe unit a "tri-pod" stance. With the loader bucket in ground contact, front tire bounce will not be a factor in overall control.

GENERAL BACKHOE OPERATION




CAUTION

To avoid personal injury:


- Do not dig under the stabilizer or tractor, especially in soft or sandy conditions. Take extra precaution in wet or thawing ground. These conditions can cause the ground to become unstable very quickly and may collapse under the weight of the machine and the unit may tip over.
- Use care for buried material such as electrical, telephone, gas and water lines. When in doubt, contact local utility companies for their buried location.


IMPORTANT :

- Do not use the tractor to pull out tree stumps with the boom dipper extended and the bucket in its crowded position.



- When working with the hydraulic thumb or the mechanical thumb, do not handle long objects (objects longer than the width of the machine). Such long objects held by the hydraulic thumb or the mechanical thumb can hit the machine and other objects, which can damage the machine and others.





■ Spoil Pile Location



CAUTION

To avoid personal injury:

- Do not place spoil close to the edge of the excavation where its weight could cause a cave-in.

Carefully preplan the location for the spoil that will be removed from the excavation. The location will vary depending on the excavation being dug.

The height of spoil pile can be controlled without moving the tractor. Approach the pile with the backhoe bucket full and ready to empty. Instead of dumping on top, lower the full bucket into the top of the pile. Begin dumping and crowding out at the same time. As the bucket opens and dumps, the bottom of the bucket will push the top of the pile off and behind its location, safely away from the excavation.

■ Dipperstick Digging

Lower the bucket to the ground, the same as with bucket digging, then curl until the bucket teeth are flat on the ground.


Using only the crowd cylinder, retract the dipperstick, dragging the bucket through the trench until it is approximately half full. Begin to curl the bucket in while continuing to crowd in, until the bucket is completely full. Raise and swing the boom and dump the bucket in the spoil area on the high side of the trench or excavation.

■ Straight Wall or Cemetery Digging


Strip the top soil off the ground, within the confines of the straight hole or grave to be dug. Clean out as much material, within the same confines, as possible with normal digging methods.

Finish the far wall by crowding out while forcing the bucket down with the boom.

Curl the bucket out to keep the bottom of the bucket vertical while making the down cut.




To finish the near wall, raise the boom while crowding in. The bucket will have to be curled in to keep the cutting edge horizontal with the wall during the up cut.




When finishing straight wall, or digging graves, in sandy soil, use a platform under the rear tires and stabilizers. The platform distributes the backhoe load over a large area and lessens the possibility of a cave-in.

■ Stabilizer pads


The stabilizer pads can be reversed without the use of tools. Change the pads depending on the job.



◆ When operating in dirt to prevent slippage.



◆ When operating on street to prevent damage to work area.



(1) Rubber shoes (option)

IMPORTANT :

- Always lower stabilizers slightly when changing stabilizer pads from one position to another in order to avoid soil splash.

TRANSPORTING


■ Driving to the Job-site




CAUTION

To avoid personal injury:

- Before transporting the machine, raise and center the boom, close the dipperstick, curl the bucket and engage the boom and swing locks.



Before driving or transporting from one job-site to another, or when using the loader such as stockpiling and backfilling, always engage the boom and swing locks.



- (1) Boom lock lever
(2) Swing lock pin

■ Trailer Transporting



CAUTION

To avoid personal injury:

- Always securely fasten the tractor / loader / backhoe, with chains and chain binders, to transport vehicle. Determine and note the load height of the backhoe, for underpass clearance, before transporting.

When loading or off-loading the machine on or from trailer / truck, use strong, secure ramps long enough to provide a low angle to the transport vehicle.

After loading the machine, release the boom lock, lower the backhoe bucket to the bed of the transport vehicle, lower the loader bucket, set the parking brake of the tractor, shut the engine off and then remove the key.

Check the hood for proper securement, and remove SMV sign from holder driving transport to avoid damage, reinstall after transport.

Check the local codes or regulations that may apply to tractor / loader / backhoe operation on public streets or highways, before transporting or traveling. Use SMV emblem and warning flashers as required.

(SMV: Slow Moving Vehicle)

AUXILIARY HYDRAULIC VALVE SYSTEM (if equipped)

■ Remote Control Valve Coupler Connecting and Disconnecting



CAUTION

To avoid personal injury:

- Stop the engine and relieve pressure before connecting or disconnecting lines.
- Do not use your hand to check for leaks.

◆ Connecting

1. Clean both couplers.
2. Remove dust plugs.
3. Insert the implement coupler to the tractor hydraulic coupler.
4. Pull the implement coupler slightly to make sure couplers are firmly connected.

◆ Disconnecting

1. Lower the implement to the ground to release hydraulic pressure in the hoses.
2. Clean the couplers.
3. Relieve pressure by moving hydraulic control pedal with engine shut off. Pull the collar back then, pull the hose straight from the hydraulic coupler to release it.
4. Clean oil and dust from the coupler, then replace the dust plugs.

NOTE :



- Your local KUBOTA dealer can supply parts to adapt couplers to hydraulic hoses.

■Auxiliary Hydraulic Valve Pedal

Move the pedal to the "FORWARD" or "REARWARD" position and hold. This will raise or lower the implement. Pedal will return to neutral when released.

IMPORTANT :

- Do not hold the pedal in the "REARWARD" or "FORWARD" position once the remote cylinder has reached the end of the stroke, as this will cause oil to flow through the relief valve. Forcing oil through the relief valve for extended periods will overheat the oil.



(1) Auxiliary hydraulic valve pedal (X) "FORWARD" (Y) "REARWARD"

Pressure →
Returning ←

Pedal		Forward		Rearward	
Port	[LH]	In	←	Out	→
	[RH]	Out	→	In	←
		Coupler size			
Port [LH, RH]		PT 3/8			

MAINTENANCE

DAILY CHECKS



CAUTION

To avoid personal injury:


- Never make any repairs, service or adjustments when the hydraulic system is under pressure, when the engine is running or when any backhoe cylinder is under load.
- Escaping hydraulic fluid under pressure can have sufficient force to penetrate skin, causing serious personal injury.



- Before disconnecting lines, be sure to relieve all pressure. Before applying pressure to system, be sure all connections are tight and that lines, pipes and hoses are not damaged.


- Fluid escaping from a very small hole can be almost invisible. Do not use hands to search for suspected leak, use a piece of cardboard or wood. If injured by escaping fluid, see a doctor at once.

Serious infection or allergic reaction will develop if proper medical treatment is not administered immediately.




- (1) Cardboard
(2) Hydraulic line
(3) Magnifying glass


- The backhoe is run by the tractor hydraulic system. Daily before operation, check the tractor hydraulic level. If low, replenish the oil as described in the tractor operator's manual. Also check the filter screen and change the hydraulic fluid as recommended in the tractor operator's manual.



(1) Gauge (A) Oil level is acceptable within this range.
(2) Oil inlet




(1) Dipstick (A) Oil level is acceptable within this range.
(2) Oil inlet




(1) Gauge (A) Oil level is acceptable within this range.
(2) Oil inlet

L3240(-3), L3540(-3), L3940(-3), L4240(-3)
L4740(-3), L5040(-3), L5240(-3), L5740(-3)
L3560, L4060, L4760, L5060, L5460, L6060



(1) Oil port
(2) Dipstick

- Check all hardware before daily operation. Tighten hardware to torque values as specified in the "General torque specification".
- With the engine off and the bucket on the ground, inspect all hoses for cuts or wear. Check for signs of leaks and make sure all fittings are tight.
- For safe operation, check that the mounting pin slide bar is inserted into the hole of the main frame before operation.



(1) Mounting pin
(2) Slide bar

EVERY 50 HOURS

■ Checking Sub Frame Bolt Torque




CAUTION

To avoid personal injury:


- Never operate backhoe and front loader with a loose sub frame.
- Any time bolts and nuts are loosened, retighten to specified torque.
- Check all bolts and nuts frequently and keep them tight.

Check sub frame bolts and nuts regularly especially when new. If they are loose, tighten them as follows.



(1) Sub frame

M16 bolt and nut
Tightening torque: 196-225 N·m
(20.0-23.0 kgf·m, 145-166 lbf·ft)
M14 bolt and nut
Tightening torque: 124-147 N·m
(12.6-15.0 kgf·m, 91.5-108.4 lbf·ft)




(1) Cab spacer
(2) Bolt


M20 bolt and nut
Tightening torque: 368-431 N·m
(37.6-44.0 kgf·m, 272-318 lbf·ft)

LUBRICATION


Lubricate all grease fittings every 10 hours of operation. High quality grease designated "extreme pressure" and containing Molybdenum disulfide is recommended. This grease may specify "Moly Ep" on it's label.



1AJABALAP011A



1AJABALAP012A




1AJABALAP021A

[For Auxiliary Hydraulic Valve System]

NOTE :

- If the pedal operation is hard, then disassemble, clean, and add grease on the shaft.



(1) Auxiliary hydraulic valve pedal (A) Apply grease
(2) Pedal shaft

TIRE INFLATION

Ensure the tractor tires are properly inflated. Refer to the tractor operator's manual for optional tires.

BUCKET SERVICE



CAUTION

To avoid personal injury:

- When servicing or repairing pins in cylinder ends, bucket, etc., always use a brass drift and hammer. Failure to do so could result in injury from flying metal fragments.

■ Changing the Backhoe Bucket

Changing the backhoe bucket becomes necessary as the type of job to be accomplished changes. In most backhoe operations, this is a common occurrence.


By using the following instructions, this job will be quick and easy. Always select a smooth level area to change buckets.

Place the bucket to be installed on its bottom, near the backhoe dipperstick and the bucket to be removed.

Position the bucket to be removed, hydraulically, into this "natural" position, just touching the ground.

■ Changing the Bucket Teeth

The bucket teeth are locked with spring pins on the bucket. Even though the teeth are heat-treated and hard, they will eventually need replacement. As the teeth become worn, the resistance of digging will increase. When the teeth are worn, install new teeth using new spring pins.



(1) Bucket
(2) Bucket teeth
(3) Spring pin

REMOVING THE BACKHOE

REMOVAL OF THE BACKHOE



CAUTION


To avoid personal injury:

- Before starting the engine, always sit in the tractor operator's seat.
- Before getting off the tractor, make sure that PTO lever is off and range gear shift lever is in neutral. Then set the parking brake.
- Keep hands, feet and body from between tractor and backhoe. Never allow any part of body under the machine.
- Before leaving the backhoe operator's seat, fully lower the boom to the ground.
- Before removing the backhoe, set the swing lock pin.

IMPORTANT :

- Before removing the backhoe, set the engine speed low idle.
- For removing the backhoe, locate the tractor / loader / backhoe on a flat level and hard surface, preferably concrete. If the surface is soft, place a board on the ground for the bucket and stabilizers.


1. Set the swing lock pin to prevent the pivoting of the boom before removing the backhoe.



(1) Swing lock pin


2. Stand beside the rear tire, fully close the dipperstick, curl the bucket and lower the boom until the back of bucket contacts the ground.

3. Keep the stabilizer pads at about 381 mm (15.0 in.) high.




(A) 381 mm (15.0 in.)

4. Raise the rear wheels slightly with the boom and remove the mounting pins.




(1) Mounting pin

5. Slowly raise the boom to disengage the backhoe from the tractor.



6. Raise the backhoe by operating the stabilizers to the lowering direction until the mount bars hit the guide stopper on the support hooks.




- (1) Guide stop
(2) Mount bar
(3) Support hook

7. Move the tractor forward away from the backhoe about 8 inches.

IMPORTANT :

- Be careful not to damage or break the hoses when moving the tractor.

8. Lower the main frame and swing frame onto the ground by operating the boom and stabilizer control levers.




- (1) Main frame
(2) Swing frame

9. Shut off the engine and set the parking brake.
10. Slowly release all hydraulic pressure by moving the backhoe hydraulic control levers in all directions.
11. Disconnect hydraulic hoses in the following manner:
(1) Disconnect the inlet and outlet hoses from the tractor.
(2) Connect tractor's outlet hose to the coupler of return hose.

NOTE :

- Failure to reconnect the hose can result in severe damage to Hydraulic Pump and seals.
Do not start tractor with hose disconnected.



- (1) Outlet hose (tractor) (A) To be connected
(2) Return hose (tractor)

12. Restart the engine.

Then drive the tractor / loader slowly away from the backhoe.

13. Shut off the engine and remove the key from the tractor. Set the parking brake.


NOTE :

- The entire 3 point hitch can now be reinstalled on the tractor for use with other rear mount implements.
- Be sure that there is sufficient ballast in the rear tires and an implement is attached to the 3 point hitch before using the loader with backhoe removed.


**[L3560,L4060,L4760,L5060,L5460,L6060
ROPS MODEL ONLY]**

NOTE :

- Move the tool box to the bracket.




- (1) Tool box
(2) Tool box stay
(3) 2 - M8 x 16 bolts
2 - M8 Flange nuts
(4) 2 - M8 x 25 bolts



- (1) Tool box
(2) Tool box stay
(3) Floor seat


- After detaching the tool box, secure its stay back in position in order not to lose it.



- (1) Tool box stay
(2) Floor seat

STORAGE OF THE BACKHOE

1. Store the backhoe in a dry place.
2. Apply a coat of grease to all exposed cylinder rods to prevent rusting.
3. If the backhoe is being stored outside, cover the backhoe with suitable weather cover. This will keep moisture, dirt and other airborne debris from getting into the system.
4. Repair or replace any worn, damaged or missing parts.



IMPORTANT :

- When storing the backhoe, install the dust caps onto the backhoe's hydraulic nipples to prevent contamination.

REINSTALLING THE BACKHOE



WARNING

To avoid personal injury or death:

- Before starting the engine, always sit in the operator's seat.
- Before getting off the tractor, make sure that PTO lever is off and range gear shift lever is in neutral. Set the parking brake.
- Keep hands, feet and body from between tractor and backhoe. Never allow any part of body under the machine.
- Before mounting backhoe, use caution and do not use any controls as handholds.




CAUTION

To avoid personal injury:

- Make sure the tractor PTO is disengaged.

IMPORTANT :

- Before reinstalling the backhoe, set the engine speed to low idle.
1. Remove the 3-point hitch and / or drawbar. (if equipped)
 2. Make sure the swing lock pin is installed.
 3. Slowly back the tractor / loader, centering to the backhoe main frame.
Stop the tractor 254 to 304 mm (10.0 to 12.0 in.) away from the backhoe.
 4. Shut the engine off and set the parking brake.
 5. Connect the inlet and outlet hoses of the backhoe to the outlet hose and return hose of the tractor.



- (1) Inlet hose
(2) Return hose

IMPORTANT :

- Make sure both hoses are firmly connected before starting the engine.
6. Restart the engine.



WARNING


To avoid personal injury or death:

- Do not move the joystick control lever to the swing position.

7. Stand beside the rear tire. Move the boom to fully raising position and raise the backhoe by operating the stabilizers until the mount bars on the backhoe main frame are slightly higher than the tractor main frame support hooks.


NOTE :

- If the support hooks are not parallel to the mount bars, adjust with the stabilizers.




- (1) Mount bar
(2) Support hook

8. Move the tractor backward until the support hooks on the tractor main frame are just beneath the mount bars on the backhoe main frame.



- (1) Guide stop
(2) Mount bar
(3) Support hook

9. Lower the mount bar onto the support hooks by operating the stabilizer and boom control levers.
10. Move the boom slowly to the lowering position, and engage the guide plates of the main frame to the bosses of sub frame. Then raise the rear wheels slightly by operating the boom to the lowering direction.
11. Shut off the engine. Reinstall the mounting pins, and insert the slide bar of the mounting pins to the hole of the main frame.



(1) Mounting pin
(2) Slide bar


NOTE :

- Move the tractor / loader / backhoe to an open area and cycle all backhoe functions. This will check their operation and flow oil back through the system, filtering it and refilling each circuit. Check the hydraulic oil level before putting the backhoe into full operation. See "MAINTENANCE" section of the tractor operator's manual for oil type and correct level.

**[L3560,L4060,L4760,L5060,L5460,L6060
ROPS MODEL ONLY]**


NOTE :

- Move the tool box to the left side of the tractor ROPS.




(1) Tool box
(2) Tool box stay
(3) Floor Seat

- After detaching the tool box, secure its stay back in position in order not to lose it.



(1) Tool box stay
(2) Floor seat




(1) Tool box
(2) Tool box stay
(3) 2 - M8 x 16 bolts
2 - M8 Flange nuts
(4) 2 - M8 x 25 bolts

GENERAL TORQUE SPECIFICATION

If the torque levels are specified in the text, follow that specification.

American standard screws, bolts and nuts with UNC or UNF threads				Metric cap screws 	
SAE grade No.	SAE GR.5 	SAE GR.8 	property class	8.8 Approx. SAE GR 5	
1/4 (N·m) (kgf·m) (lbf·ft)	11.7 to 15.8 1.19 to 1.61 8.6 to 11.6	16.3 to 19.8 1.66 to 2.02 12.0 to 14.6	M6 (N·m) (kgf·m) (lbf·ft)	9.8 to 11.2 1.0 to 1.1 7.2 to 8.3	
5/16 (N·m) (kgf·m) (lbf·ft)	23.1 to 27.8 2.35 to 2.83 17.0 to 20.5	32.5 to 39.3 3.31 to 4.01 24.0 to 29.0	M8 (N·m) (kgf·m) (lbf·ft)	23.6 to 27.4 2.4 to 2.8 17.4 to 20.2	
3/8 (N·m) (kgf·m) (lbf·ft)	47.5 to 57.0 4.84 to 5.81 35.0 to 42.0	61.0 to 73.2 6.22 to 7.46 45.0 to 54.0	M10 (N·m) (kgf·m) (lbf·ft)	48.1 to 55.8 4.9 to 5.7 35.5 to 41.2	
1/2 (N·m) (kgf·m) (lbf·ft)	108.5 to 130.2 11.06 to 13.28 80.0 to 96.0	149.2 to 179.0 15.21 to 18.25 110.0 to 132.0	M12 (N·m) (kgf·m) (lbf·ft)	77.5 to 90.1 7.9 to 9.2 57.2 to 66.5	
9/16 (N·m) (kgf·m) (lbf·ft)	149.2 to 179.0 15.21 to 18.25 110.0 to 132.0	217.0 to 260.4 22.13 to 26.55 160.0 to 192.0	M14 (N·m) (kgf·m) (lbf·ft)	124 to 147 12.6 to 15.0 91.5 to 108.4	
5/8 (N·m) (kgf·m) (lbf·ft)	203.4 to 244.1 20.74 to 24.89 150.0 to 180.0	298.3 to 358.0 30.42 to 36.51 220.0 to 264.0	M16 (N·m) (kgf·m) (lbf·ft)	197 to 225 20.0 to 23.0 145 to 166	
			M18 (N·m) (kgf·m) (lbf·ft)	275 to 318 28.0 to 32.5 203 to 235	
			M20 (N·m) (kgf·m) (lbf·ft)	368 to 431 37.6 to 44.0 272 to 318	

Top of bolt



M6

M8


M10

M12

M14

M16




Length



M18 M20

ADAPTERS, ELBOWS AND OTHERS

If the torque levels are specified in the text, follow that specification.

Item	Shape	Thread size	Tightening torque		
			N·m	kgf·m	lbf·ft
Adjustable elbow, Adaptor (O-ring port) (UNF)	 [A] Nut Type [B] No Nut Type a: O-ring 4FBAAAKAP064A	7/16	18 to 20	1.84 to 2.00	13.3 to 14.7
		9/16	37 to 44	3.8 to 4.5	27 to 33
		3/4	48 to 54	4.9 to 5.5	35 to 40
		7/8	77 to 85	7.9 to 8.6	57 to 62
Hose fitting, Flare nut (UNF)	 4FBAAAKAP065A	9/16	25 to 28	2.55 to 2.85	18.5 to 20.6
		3/4	49 to 53	5.00 to 5.40	36.2 to 39.0
		7/8	77 to 85	7.86 to 8.67	56.8 to 62.6
		1-1/16	107 to 119	10.8 to 12.0	79 to 88
		1-3/16	127 to 141	13.0 to 14.4	94 to 104
Adaptor (NPT)	 4FBAAAKAP066A	1/4	30 to 50	3.1 to 5.0	23 to 36
		3/8	39 to 60	4.0 to 6.1	29 to 44
		1/2	49 to 58	5.0 to 5.9	36 to 43