

WSM

WORKSHOP MANUAL **TRACTOR, ROTARY MOWER, FRONT LOADER**

**BX2350D, RCK48-23BX-EU,
RCK54-23BX-EU, RCK60B-23BX-EU,
RCK48-23BX-EU-F, RCK54-23BX-EU-F,
RCK60-23BX-EU-F, LA243**

Kubota

TO THE READER

This Workshop Manual has been prepared to provide servicing personnel with information on the mechanism, service and maintenance of KUBOTA Tractor BX2350D, KUBOTA Rotary Mower RCK48-23BX-EU, RCK54-23BX-EU, RCK60B-23BX-EU, RCK48-23BX-EU-F, RCK54-23BX-EU-F, RCK60-23BX-EU-F and KUBOTA Front Loader LA243. It is divided into three parts, "General", "Mechanism" and "Servicing".

■ General

Information on the tractor identification, the general precautions, maintenance check list, check and maintenance and special tools are described.

■ Mechanism

Information on the construction and function are included. This part should be understood before proceeding with troubleshooting, disassembling and servicing.

Refer to Diesel Engine / Tractor Mechanism Workshop Manual (Code No. 9Y021-01870 / 9Y021-18200) for the one which has not been described to this workshop manual.

■ Servicing

Information on the troubleshooting, servicing specification lists, tightening torque, checking and adjusting, disassembling and assembling, and servicing which cover procedures, precautions, factory specifications and allowable limits.

All information illustrations and specifications contained in this manual are based on the latest product information available at the time of publication.

The right is reserved to make changes in all information at any time without notice.

Due to covering many models of this manual, information or picture being used, have not been specified as one model.

July 2010

© KUBOTA Corporation 2010



SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully.

It is essential that you read the instructions and safety regulations before you attempt to repair or use this unit.



DANGER

: Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION


: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

■ IMPORTANT

: Indicates that equipment or property damage could result if instructions are not followed.


■ NOTE

: Gives helpful information.




BEFORE SERVICING AND REPAIRING

- Read all instructions and safety instructions in this manual and on your machine safety decals.
- Clean the work area and machine.
- Park the machine on a firm and level ground, and set the parking brake.
- Lower the implement to the ground.
- Stop the engine, and remove the key.
- Disconnect the battery negative cable.
- Hang a "**DO NOT OPERATE**" tag in operator station.





SAFETY STARTING


- Do not start the engine by shorting across starter terminals or bypassing the safety start switch.
- Do not alter or remove any part of machine safety system.
- Before starting the engine, make sure that all shift levers are in neutral positions or in disengaged positions.
- Never start the engine while standing on ground. Start the engine only from operator's seat.



SAFETY WORKING


- Do not work on the machine while under the influence of alcohol, medication, or other substances or while fatigued.
- Wear close fitting clothing and safety equipment appropriate to the job.
- Use tools appropriate to the work. Makeshift tools, parts, and procedures are not recommended.
- When servicing is performed together by two or more persons, take care to perform all work safely.
- Do not work under the machine that is supported solely by a jack. Always support the machine by safety stands.
- Do not touch the rotating or hot parts while the engine is running.
- Never remove the radiator cap while the engine is running, or immediately after stopping. Otherwise, hot water will spout out from radiator. Only remove radiator cap when cool enough to touch with bare hands. Slowly loosen the cap to first stop to relieve pressure before removing completely.
- Escaping fluid (fuel or hydraulic oil) under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or fuel lines. Tighten all connections before applying pressure.
- Do not open high-pressure fuel system. High-pressure fluid remaining in fuel lines can cause serious injury. Do not disconnect or attempt repair fuel lines, sensors, or any other components between the high-pressure fuel pump and injectors on engines with high pressure common rail fuel system.
- High voltage exceeding 100 V is generated in the ECU, and is applied to the injector. Pay sufficient caution to electric shock when performing work activities.






AVOID FIRES

- Fuel is extremely flammable and explosive under certain conditions. Do not smoke or allow flames or sparks in your working area.
- To avoid sparks from an accidental short circuit, always disconnect the battery negative cable first and connect it last.
- Battery gas can explode. Keep sparks and open flame away from the top of battery, especially when charging the battery.
- Make sure that no fuel has been spilled on the engine.




VENTILATE WORK AREA

- If the engine must be running to do some work, make sure the area is well ventilated. Never run the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.




PREVENT ACID BURNS

- Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, clothing and cause blindness if splashed into eyes. Keep electrolyte away from eyes, hands and clothing. If you spill electrolyte on yourself, flush with water, and get medical attention immediately.



DISPOSE OF FLUIDS PROPERLY

- Do not pour fluids into the ground, down a drain, or into a stream, pond, or lake. Observe relevant environmental protection regulations when disposing of oil, fuel, coolant, electrolyte and other harmful waste.



PREPARE FOR EMERGENCIES


- Keep a first aid kit and fire extinguisher handy at all times.
- Keep emergency numbers for doctors, ambulance service, hospital and fire department near your telephone.

SAFETY DECALS

The following safety decals are installed on the machine.

If a decal becomes damaged, illegible or is not on the machine, replace it. The decal part number is listed in the parts list.


(1) Part No. K2581-6548-1




1AGAJAXAP042E

(2) Part No. K2581-6552-1



Do not put hands
under the rear fender



(3) Part No. K2586-6557-1




1AGAJBAAP054E



3TAAAAHCP002A

(1) Part No. K2581-6554-1




1AGAJAXAP044E

(2) Part No. K2561-6556-1



1AGAJAXAP046E


(3) Part No. K2583-6555-1





(4) Part No. K2581-6549-1

Diesel fuel
only

No fire



1AGAMAAAP2480



3TAAAAHCP003A

(1) Part No. K2581-6541-1



1AGAJAXAP048E

! DANGER

TO AVOID POSSIBLE INJURY OR DEATH FROM A MACHINE RUNAWAY:

1. Do not start engine by shorting across starter terminals or bypassing the safety start switch. Machine may start in gear and move if normal starting circuitry is bypassed.
2. Start engine only from operator's seat with transmission and PTO off. Never start engine while standing on the ground.

(2) Part No. K2581-6547-1


Stay clear of engine fan and fanbelt



1AGAJAXAP049E

(3) Part No. K2581-6542-1


Do not touch hot surface like muffler, etc..





1AGAJAXAP050E

(4) Part No. K2581-6543-1

Stay clear of engine fan and fanbelt.



1AGAJAXAP052E




3TAAAHCP004A

(1) Part No. K1211-6116-1




1AGAJAXAP053E

(2) Part No. K1211-6115-1



1AGAJAXAP054E



CARE OF DANGER, WARNING AND CAUTION LABELS

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels.
4. If a component with danger, warning or caution label (s) affixed is replaced with new part, make sure new label (s) is (are) attached in the same location (s) as the replaced component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

3TAAAAHCP005A

SPECIFICATIONS

Model			BX2350D (without OPC)		BX2350D (with OPC)	
PTO power			13.2 kW (17.9 HP)*			
Engine	Maker		KUBOTA			
	Model		D902-E2-BX-2		D902-E3-BX-2	
	Type		Indirect Injection, vertical, water-cooled, 4-cycle diesel			
	Number of cylinders		3			
	Bore and stroke		72 × 73.6 mm (2.83 × 2.90 in.)			
	Total displacement		898 cm ³ (54.8 cu.in.)			
	Engine gross power		17.1 kW (23.3 HP)			
	Rated revolution		3200 min ⁻¹ (rpm)			
	Maximum torque		56.1 N·m (5.7 kgf·m, 41.4 lbf·ft)			
	Battery		12 V, CCA : 535 A, RC : 80 min.			
	Starting system		Electric starting with cell starter, 12 V, 1.4 kW			
	Lubrication system		Forced lubrication by trochoidal pump			
	Cooling system		Pressurized radiator, forced circulation with water pump			
	Fuel		Diesel fuel No. 2-D [above –10 °C (14 °F)], Diesel fuel No. 1 [below –10 °C (14 °F)]			
	Capacities	Fuel tank		25 L (6.6 U.S.gals, 5.5 Imp.gals)		
Engine crankcase (with filter)		3.1 L (3.3 U.S.qts, 2.7 Imp.qts)				
Engine coolant (with recovery tank)		3.1 L (3.3 U.S.qts, 2.7 Imp.qts)				
Transmission case		11.6 L (3.06 U.S.gals, 2.55 Imp.gals)				
Front axle case		4.7 L (5.0 U.S.qts, 4.1 Imp.qts)				
Dimensions	Overall length (with 3P)		2425 mm (95.5 in.)			
	Overall width (min. tread)		1145 mm (45.1 in.)			
	Overall height (with ROPS)		2140 mm (84.3 in.)			
	Overall height (Top of steering handle)		1305 mm (51.4 in.)			
	Wheel base		1400 mm (55.1 in.)			
	Minimum ground clearance		170 mm (6.7 in.)			
	Tread	Front	910 mm (35.8 in.)			
		Rear	820 mm (32.2 in.)			
Weight (with ROPS)			665 kg (1466.3 lbs)			
Travelling system	Tires	Front	18 × 8.50 – 10 (Turf)			
		Rear	26 × 12.00 – 12 (Turf)			
	Steering		Hydrostatic power steering			
	Transmission		Main-hydrostatic transmission, Range gear shift (2 forward and 2 reverse)			
	Brake		Wet disk type			
	Min. turning radius (without brake)		2.3 m (7.5 feet)			
	Differential		Bevel gear			
Hydraulic system	Hydraulic control system		Directional control, auto-return lever system			
	Pump capacity		23.5 L/min. (6.2 U.S.gals/min., 5.2 Imp.gals/min.)			
	Three point hitch		SAE Category I			
	Max. lift force		5390 N (550 kg, 1374 lbs)			
PTO system	Clutch		Wet type, multiple disks			
	Rear	PTO shaft	SAE 1-3/8, 6 splines			
		Revolution	1 speed (540 min ⁻¹ (rpm) at engine 3142 min ⁻¹ (rpm))			
	Mid	PTO shaft	USA No. 5 (KUBOTA 10-tooth) involute spline			
		Revolution	1 speed (2500 min ⁻¹ (rpm) at engine 3043 min ⁻¹ (rpm))			

NOTE: * Manufacture's estimate

The company reserves the right to change the specifications without notice.

W1028103


TRAVELLING SPEEDS

Model		BX2350D	
Tire size (Rear)		26 × 12.00 – 12	
	Range gear shift lever	km/h	mph
Forward	Low	0 to 6.0	0 to 3.7
	High	0 to 13.0	0 to 8.1
Reverse	Low	0 to 4.5	0 to 2.8
	High	0 to 10.0	0 to 6.2

The company reserves the right to change the specifications without notice.

W1035065

DIMENSIONS



G GENERAL

GENERAL

CONTENTS

1. TRACTOR IDENTIFICATION	G-1
2. GENERAL PRECAUTIONS	G-2
3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING ..	G-3
[1] WIRING	G-3
[2] BATTERY	G-5
[3] FUSE	G-5
[4] CONNECTOR	G-5
[5] HANDLING OF CIRCUIT TESTER	G-6
4. LUBRICANTS FUEL AND COOLANT	G-7
5. TIGHTENING TORQUES	G-8
[1] GENERAL USE SCREWS, BOLTS AND NUTS	G-8
[2] STUD BOLTS	G-8
[3] AMERICAN STANDARD SCREWS, BOLTS AND NUTS WITH UNC OR UNF THREADS	G-9
[4] PLUGS	G-9
6. MAINTENANCE CHECK LIST	G-10
7. CHECK AND MAINTENANCE	G-11
[1] DAILY CHECK	G-11
[2] CHECK POINTS OF INITIAL 50 HOURS	G-12
[3] CHECK POINTS OF EVERY 50 HOURS	G-14
[4] CHECK POINTS OF EVERY 100 HOURS	G-17
[5] CHECK POINTS OF EVERY 200 HOURS	G-24
[6] CHECK POINTS OF EVERY 300 HOURS	G-26
[7] CHECK POINT OF EVERY 400 HOURS	G-27
[8] CHECK POINT OF EVERY 500 HOURS	G-27
[9] CHECK POINT OF EVERY 800 HOURS	G-28
[10] CHECK POINT OF EVERY 1500 HOURS	G-28
[11] CHECK POINT OF EVERY 3000 HOURS	G-28
[12] CHECK POINT OF EVERY 1 YEAR	G-28
[13] CHECK POINTS OF EVERY 2 YEARS	G-28
[14] OTHERS	G-32
8. SPECIAL TOOLS	G-35
[1] SPECIAL TOOLS FOR ENGINE	G-35
[2] SPECIAL TOOLS FOR TRACTOR	G-40
9. TIRES	G-44
[1] TIRE PRESSURE	G-44
[2] WHEEL TREAD	G-45
(1) Front Wheels	G-45
(2) Rear Wheels	G-46
[3] BALLAST	G-47
(1) Front Ballast	G-47
(2) Rear Ballast	G-48
10. IMPLEMENT LIMITATIONS	G-49




1. TRACTOR IDENTIFICATION

When contacting your local KUBOTA distributor, always specify engine serial number, tractor serial number and hour meter reading.


- (1) Tractor Identification Plate
- (2) Tractor Serial Number

- (3) Engine Serial Number
- (4) Hour Meter

W1010590



2. GENERAL PRECAUTIONS




- During disassembly, carefully arrange removed parts in a clean area to prevent confusion later. Screws, bolts and nuts should be installed in their original position to prevent reassembly errors.
- When special tools are required, use KUBOTA genuine special tools. Special tools which are not frequently used should be made according to the drawings provided.
- Before disassembling or servicing electrical wires, always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before measuring.
- Use only KUBOTA genuine parts for parts replacement to maintain machine performance and to assure safety.
- Gaskets and O-rings must be replaced during reassembly. Apply grease to new O-rings or oil seals before assembling. See the figure left side.
- When reassembling external snap rings or internal snap rings, they must be positioned so that sharp edge faces against the direction from which a force is applied. See the figure left side.
- When inserting spring pins, their splits must face the direction from which a force is applied. See the figure left side.
- To prevent damage to the hydraulic system, use only specified fluid or equivalent.

- (1) Grease
(2) Force
(3) Sharp Edge
(4) Axial Force
(5) Rotating Movement

- (A) External Snap Ring
(B) Internal Snap Ring

W10109040

3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING



To ensure safety and prevent damage to the machine and surrounding equipment, heed the following precautions in handling electrical parts and wiring.

■ IMPORTANT


- Check electrical wiring for damage and loosened connection every year. To this end, educate the customer to do his or her own check and at the same time recommend the dealer to perform periodic check for a fee.
- Do not attempt to modify or remodel any electrical parts and wiring.
- When removing the battery cables, disconnect the negative cable first. When installing the battery cables, connect the positive cable first.

(1) Negative Terminal

(2) Positive Terminal

W10111140

[1] WIRING




- Securely tighten wiring terminals.

(1) Correct
(Securely Tighten)

(2) Incorrect
(Loosening Leads to Faulty Contact)

W10112160




- Do not let wiring contact dangerous part.

(1) Dangerous Part
(2) Wiring (Incorrect)

(3) Wiring (Correct)
(4) Dangerous Part

W10113130




- Securely insert grommet.

(1) Grommet

(A) Correct
(B) Incorrect


W10113880



- Securely clamp, being careful not to damage wiring.

- (1) Clamp
 • Wind Clamp Spirally
 (2) Wire Harness
 (3) Clamp
 (4) Welding Dent


W10114580



- Clamp wiring so that there is no twist, unnecessary sag, or excessive tension, except for movable part, where sag be required.

- (1) Wiring
 (2) Clamp
 (A) Correct
 (B) Incorrect


W10115870



- In installing a part, take care not to get wiring caught by it.

- (1) Wiring
 (A) Incorrect

W10116700




- After installing wiring, check protection of terminals and clamped condition of wiring, only connect battery.

- (1) Cover
 • Securely Install Cover

W10117350

[2] BATTERY




- Take care not to confuse positive and negative terminal posts.
- When removing battery cables, disconnect negative cable first. When installing battery cables, check for polarity and connect positive cable first.
- Do not install any battery with capacity other than is specified (Ah).
- After connecting cables to battery terminal posts, apply high temperature grease to them and securely install terminal covers on them.
- Do not allow dirt and dust to collect on battery.

CAUTION

- Take care not to let battery liquid spill on your skin and clothes. If contaminated, wash it off with water immediately.
- Before recharging the battery, remove it from the machine.
- Before recharging, remove cell caps.
- Do recharging in a well-ventilated place where there is no open flame nearby, as hydrogen gas and oxygen are formed.

W10118160

[3] FUSE




- Use fuses with specified capacity. Neither too large or small capacity fuse is acceptable.
- Never use steel or copper wire in place of fuse.
- Do not install working light, radio set, etc. on machine which is not provided with reserve power supply.
- Do not install accessories if fuse capacity of reserve power supply is exceeded.

(1) Fuse
(2) Fusible Link

(3) Slow Blow Fuse

W10120920


[4] CONNECTOR



- For connector with lock, push lock to separate.

(A) Push

W10122110




- In separating connectors, do not pull wire harnesses.
- Hold connector bodies to separate.

(A) Correct

(B) Incorrect


W10122720



- Use sandpaper to remove rust from terminals.
- Repair deformed terminal. Make certain there is no terminal being exposed or displaced.

(1) Exposed Terminal (3) Sandpaper
(2) Deformed Terminal (4) Rust


W10123460



- Make certain that there is no female connector being too open.

(A) Correct (B) Incorrect

W10124300




- Make certain plastic cover is large enough to cover whole connector.

(1) Cover (A) Correct
(B) Incorrect

W10125190

[5] HANDLING OF CIRCUIT TESTER



- Use tester correctly following manual provided with tester.
- Check for polarity and range.

W10126840

4. LUBRICANTS FUEL AND COOLANT

No.	Place	Capacity	Lubricants, fuel and coolant	
		BX2350D		
1	Fuel tank	25.0 L 6.6 U.S.gals 5.5 Imp.gals	No. 2-D diesel fuel No. 1-D diesel fuel if temperature is below –10 °C (14 °F)	
2	Cooling system with recovery tank	3.1 L 3.3 U.S.qts 2.7 Imp.qts	Fresh clean water with anti-freeze	
3	Engine crankcase	3.1 L 3.3 U.S.qts 2.7 Imp.qts	Engine oil : API Service CD, CE or CF Below 0 °C (32 °F) : SAE10W, 10W-30 or 10W-40 0 to 25 °C (32 to 77 °F): SAE20, 10W-30 or 10W-40 Above 25 °C (77 °F): SAE30, 10W-30 or 10W-40	
4	Transmission case	11.6 L 3.1 U.S.gals 2.6 Imp.gals	KUBOTA SUPER UDT fluid*	
5	Front axle case	4.7 L 5.0 U.S.qts 4.1 Imp.qts	KUBOTA SUPER UDT fluid or SAE80, SAE90 gear oil	
Greasing				
	Place	No. of greasing point	Capacity	Type of grease
6	Battery terminal	2	Moderate amount	Multipurpose type Grease NLGI-2 or NLGI-1 (GC-LG)
7	Speed control pedal	1	Until grease overflows	

* KUBOTA original transmission hydraulic fluid.

5. TIGHTENING TORQUES

[1] GENERAL USE SCREWS, BOLTS AND NUTS

Screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual should be tightened according to the table below.

Indication on top of bolt	 4 No-grade or 4T						 7 7T						 9 9T		
Indication on top of nut	  No-grade or 4T												   6T		
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness		
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M6	7.9	0.80	5.8	7.9	0.80	5.8	9.81	1.00	7.24	7.9	0.80	5.8	12.3	1.25	9.05
	to 9.3	to 0.95	to 6.8	to 8.8	to 0.90	to 6.5	to 11.2	to 1.15	to 8.31	to 8.8	to 0.90	to 6.5	to 14.2	to 1.45	to 10.4
M8	18	1.8	13	17	1.7	13	24	2.4	18	18	1.8	13	30	3.0	22
	to 20	to 2.1	to 15	to 19	to 2.0	to 14	to 27	to 2.8	to 20	to 20	to 2.1	to 15	to 34	to 3.5	to 25
M10	40	4.0	29	32	3.2	24	48	4.9	36	40	4.0	29	61	6.2	45
	to 45	to 4.6	to 33	to 34	to 3.5	to 25	to 55	to 5.7	to 41	to 44	to 4.5	to 32	to 70	to 7.2	to 52
M12	63	6.4	47	—	—	—	78	7.9	58	63	6.4	47	103	10.5	76.0
	to 72	to 7.4	to 53	—	—	—	to 90	to 9.2	to 66	to 72	to 7.4	to 53	to 117	to 12.0	to 86.7
M14	108	11.0	79.6	—	—	—	124	12.6	91.2	—	—	—	167	17.0	123
	to 125	to 12.8	to 92.5	—	—	—	to 147	to 15.0	to 108	—	—	—	to 196	to 20.0	to 144
M16	167	17.0	123	—	—	—	197	20.0	145	—	—	—	260	26.5	192
	to 191	to 19.5	to 141	—	—	—	to 225	to 23.0	to 166	—	—	—	to 304	to 31.0	to 224
M18	246	25.0	181	—	—	—	275	28.0	203	—	—	—	344	35.0	254
	to 284	to 29.0	to 209	—	—	—	to 318	to 32.5	to 235	—	—	—	to 402	to 41.0	to 296
M20	334	34.0	246	—	—	—	368	37.5	272	—	—	—	491	50.0	362
	to 392	to 40.0	to 289	—	—	—	to 431	to 44.0	to 318	—	—	—	to 568	to 58.0	to 419

W1034542

[2] STUD BOLTS

Material of opponent part	Ordinariness			Aluminum		
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M8	12 to 15	1.2 to 1.6	8.7 to 11	8.9 to 11	0.90 to 1.2	6.5 to 8.6
M10	25 to 31	2.5 to 3.2	18 to 23	20 to 25	2.0 to 2.6	15 to 18
M12	30 to 49	3.0 to 5.0	22 to 36	31	3.2	23
M14	62 to 73	6.3 to 7.5	46 to 54	—	—	—
M16	98.1 to 112	10.0 to 11.5	72.4 to 83.1	—	—	—
M18	172 to 201	17.5 to 20.5	127 to 148	—	—	—

W1048139

[3] AMERICAN STANDARD SCREWS, BOLTS AND NUTS WITH UNC OR UNF THREADS

Grade	 SAE GR.5			 SAE GR.8		
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
1/4	11.7 to 15.7	1.20 to 1.60	8.63 to 11.5	16.3 to 19.7	1.67 to 2.00	12.0 to 14.6
5/16	23.1 to 27.7	2.36 to 2.82	17.0 to 20.5	33 to 39	3.4 to 3.9	25 to 28
3/8	48 to 56	4.9 to 5.7	36 to 41	61 to 73	6.3 to 7.4	45 to 53
1/2	110 to 130	11.3 to 13.2	81.2 to 95.8	150 to 178	15.3 to 18.1	111 to 131
9/16	150 to 178	15.3 to 18.1	111 to 131	217 to 260	22.2 to 26.5	160 to 191
5/8	204 to 244	20.8 to 24.8	151 to 179	299 to 357	30.5 to 36.4	221 to 263

W1014870

[4] PLUGS

Shape	Size	Material of opponent part					
		Ordinariness			Aluminum		
		N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
Tapered screw 	R1/8	13 to 21	1.3 to 2.2	9.4 to 15	13 to 19	1.3 to 2.0	9.4 to 14
	R1/4	25 to 44	2.5 to 4.5	18 to 32	25 to 34	2.5 to 3.5	18 to 25
	R3/8	49 to 88	5.0 to 9.0	37 to 65	49 to 58	5.0 to 6.0	37 to 43
	R1/2	58.9 to 107	6.00 to 11.0	43.4 to 79.5	59 to 78	6.0 to 8.0	44 to 57
Straight screw 	G1/4	25 to 34	2.5 to 3.5	18 to 25	—	—	—
	G3/8	62 to 82	6.3 to 8.4	46 to 60	—	—	—
	G1/2	49 to 88	5.0 to 9.0	37 to 65	—	—	—

0000001666E

6. MAINTENANCE CHECK LIST

No.	Period Item		Service Interval																				After purchase		Important	Ref. page
			50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	1500	3000	1 year	2 years				
1	Engine oil	Change	★	☆		☆		☆		☆		☆		☆		☆										G-12
2	Engine oil filter	Replace	★			☆				☆				☆				☆								G-12
3	Transmission oil filter	Replace	★							☆					☆											G-13
4	Transmission fluid	Change	★							☆					☆											G-13
5	Transmission strainer	Clean								☆					☆											G-26
6	Front axle case oil	Change								☆					☆											G-26
7	Front axle pivot	Adjust									☆										☆					G-27
8	Engine start system	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆								G-14
9	Greasing	—	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆								G-16
10	Wheel bolt torque	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆								G-16
11	Battery condition	Check		☆		☆		☆		☆		☆		☆		☆		☆						*4		G-17
12	Air cleaner element	Clean		☆		☆		☆		☆		☆		☆		☆		☆						*1	@	G-19
		Replace																			☆			*2	@	G-19
13	Fuel filter element	Check		☆		☆		☆		☆		☆		☆		☆		☆							@	G-20
		Replace										☆													@	G-20
14	Fan belt	Adjust		☆		☆		☆		☆		☆		☆		☆		☆								G-21
15	HST neutral spring	Adjust		☆		☆		☆		☆		☆		☆		☆		☆								G-22
16	Brake pedal	Adjust		☆		☆		☆		☆		☆		☆		☆		☆								G-23
17	Emergency hand brake	Adjust		☆		☆		☆		☆		☆		☆		☆		☆								G-23
18	Radiator hose and clamp	Check				☆				☆				☆				☆								G-24
		Replace																					☆			G-24
19	Power steering oil line	Check				☆				☆				☆				☆								G-24
		Replace																					☆			G-24
20	Fuel line	Check		☆		☆		☆		☆		☆		☆		☆		☆							@	G-20
		Replace																					☆		@	G-20
21	Intake air line	Check				☆				☆				☆				☆							@	G-25
		Replace																					☆	*3	@	G-25
22	Toe-in	Adjust				☆				☆				☆				☆								G-25
23	Engine valve clearance	Adjust																☆								1-S13
24	Fuel injection nozzle injection pressure	Check																	☆	☆				@		1-S20
25	Injection pump	Check																		☆				@		1-S19
26	Cooling system	Flush																				☆				G-29
27	Coolant	Change																					☆			G-29
28	Fuel system	Bleed																			Service as required					G-32
29	Fuse	Replace																			Service as required					G-32
30	Light bulb	Replace																			Service as required					G-34

■ IMPORTANT

- The jobs indicated by ★ must be done after the first 50 hours of operation.
- *1 : Air cleaner should be cleaned more often in dusty conditions than in normal conditions.
- *2 : Every year or every 6 times of cleaning.
- *3 : Replace only if necessary.
- *4 : When the battery is used for less than 100 hours per year, check the fluid level annually.
- The items listed above (@ marked) are registered as emission related critical parts by KUBOTA in the U.S.EPA nonroad emission regulation. As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the above instruction.

Please see the Warranty Statement in detail.

W1035769

7. CHECK AND MAINTENANCE



CAUTION

- **Be sure to check and service the tractor on a level surface with the engine shut off and the parking brake "ON" and implement lowered to the ground.**

[1] DAILY CHECK

To prevent trouble from occurring, it is important to know the condition of the tractor. Check the following items before starting.



■ Walk Around Inspection

Look around the under the tractor for such items as loose bolts, trash build-up, oil or coolant leaks, broken or worn parts.

Checking

1. Checking and refueling.
2. Check the engine oil level.
3. Check the transmission fluid level.
4. Check the coolant level.
5. Clean panel and radiator screen.
6. Check the brake pedal.
7. Check the gauge, the meters and easy checkers.
8. Check the head light, the hazard light etc..
9. Check and clean the electrical wiring and the battery cables.
10. Check the seat belt and ROPS.

[2] CHECK POINTS OF INITIAL 50 HOURS



Changing Engine Oil

⚠ CAUTION

- **Be sure to stop the engine before changing engine oil.**
1. Start and warm up the engine for approx. 5 minutes.
 2. Place an oil pan underneath the engine.
 3. To drain the used oil, remove the drain plug (1) at the bottom of the engine and drain the oil completely.
 4. Screw in the drain plug (1).
 5. Fill new oil up to upper line on the dipstick (3).

■ IMPORTANT

- **When using an oil of different manufacture or viscosity from the previous one, remove all of the old oil.**
- **Never mix two different types of oil.**
- **Use the proper SAE Engine Oil according to ambient temperatures.**
- **Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7.)**

Engine oil	Capacity	3.1 L 3.3 U.S.qts 2.7 Imp.qts
------------	----------	-------------------------------------


(1) Drain Plug

(2) Oil Inlet

(3) Dipstick

(A) Oil level is acceptable within this range.

W1014065



Replacing Engine Oil Filter

⚠ CAUTION


- **Be sure to stop the engine before changing oil filter cartridge.**
1. Remove the oil filter.
 2. Put a film of clean engine oil on the rubber seal of the new filter.
 3. Tighten the filter quickly until it contacts the mounting surface. Tighten filter by hand an additional 1/2 turn only.
 4. After the new filter has been replaced, the engine oil normally decrease a little. Make sure that the engine oil does not leak through the seal and be sure to check the oil level on the dipstick. Then, replenish the engine oil up to the specified level.
 5. Properly dispose of used oil.

■ IMPORTANT

- **To prevent serious damage to the engine, replacement element must be highly efficient. Use only a KUBOTA genuine filter or its equivalent.**

(1) Engine Oil Filter Cartridge

W1014316



Replacing Transmission Oil Filter

CAUTION


- **Allow engine to cool down sufficiently, oil can be hot and can burn.**
1. Remove the oil filter.
 2. Put a film of clean transmission oil on the rubber seal of the new filter.
 3. Tighten the filter quickly until it contacts the mounting surface. Tighten filter by hand an additional 1/2 turn only.
 4. After the new filter has been replaced, the transmission fluid level will decrease a little. Make sure that the transmission fluid does not leak through the seal, and check the fluid level. Top off if necessary.
 5. Properly dispose of used oil.

IMPORTANT

- **To prevent serious damage to the hydraulic system, use only a KUBOTA genuine filter.**

(1) Transmission Oil Filter

W1014458




Changing Transmission Fluid

CAUTION

- **Allow engine to cool down sufficiently, oil can be hot and can burn.**
1. To drain the used oil, remove the drain plug at the bottom of the transmission case and drain the oil completely into the oil pan.
 2. After draining reinstall the drain plug.
 3. Clean the transmission strainer.
 4. Fill with new KUBOTA SUPER UDT fluid up to the upper notch on the dipstick.
 5. After running the engine for a few minutes, stop it and check the oil level again, add oil to prescribed level.
 6. Properly dispose of used oil.

IMPORTANT

- **Use only multi-grade transmission oil. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7.)**




Transmission fluid	Capacity	11.6 L 3.1 U.S.gals 2.6 Imp.gals
--------------------	----------	--

- (1) Drain Plug
(2) Filling Plug
(3) Dipstick

(A) Oil level is acceptable within this range.

W1014665

[3] CHECK POINTS OF EVERY 50 HOURS



Checking Engine Start System (BX2350D without OPC)



CAUTION

To avoid personal injury :

- Do not allow anyone near the tractor while testing.
- If the tractor does not pass the test do not operate the tractor.

■ Preparation before testing.

1. Sit on the operator's seat.
2. Set the parking brake and stop the engine.
3. Shift the range gear shift lever (1) to "NEUTRAL" position.
4. Check the speed control pedal "NEUTRAL" position
5. Shift the PTO clutch lever (2) to "OFF" position.

■ Test 1 : Switch for the speed control pedal

1. Shift the range gear shift lever (1) to "NEUTRAL" position.
2. Depress the speed control pedal (3).
3. Turn the key to "START" position.
4. The engine must not crank.

■ Test 2 : Switch for the PTO clutch lever


1. Shift the range gear shift lever (1) to "NEUTRAL" position.
2. Check the speed control pedal (3) "NEUTRAL" position.
3. Shift the PTO clutch lever (2) to "ON" position.
4. Turn the key to "START" position.
5. The engine must not crank.

(1) Range Gear Shift Lever (Hi-Lo)

(3) Speed Control Pedal

(2) PTO Clutch Lever

W1014904



Checking Safety Devices (BX2350D with OPC) (To be continued)

⚠ CAUTION

To avoid personal injury :

- **Do not allow anyone near the tractor while testing.**
- **If the tractor does not pass the test do not operate the tractor.**

■ Preparation before testing.

1. Sit on the operator's seat.
2. Set the parking brake and stop the engine.
3. Shift the range gear shift lever (5) to "**NEUTRAL**" position.
4. Check the speed control pedal "**NEUTRAL**" position
5. Shift the PTO clutch lever (3) to "**OFF**" position.

[Engine Start System]

■ Test 1 : Switch for the speed control pedal

1. Shift the range gear shift lever (5) to "**NEUTRAL**" position.
2. Shift the PTO clutch lever to "**OFF**" position.
3. Depress the speed control pedal (6).
4. Turn the key to "**START**" position.
5. The engine must not crank.

■ Test 2 : Switch for the PTO clutch lever

1. Shift the range gear shift lever (5) to "**NEUTRAL**" position.
2. Check the speed control pedal (6) "**NEUTRAL**" position.
3. Shift the PTO clutch lever (3) to "**ON**" position.
4. Turn the key to "**START**" position.
5. The engine must not crank.

[OPC System]

■ Test 3 : Switches for the operator's seat, PTO select lever and parking pedal

1. Sit on the operator's seat.
2. Shift the range gear shift lever (6) to "**NEUTRAL**" position.
3. Start the engine.
4. Release the parking brake pedal (7).
5. Shift the PTO select lever to any positions.
6. Stand up. (Do not get off the machine.)
7. The engine must shut off.


■ Test 4 : Switches for the operator's seat, PTO select lever and parking pedal

1. Sit on the operator's seat.
2. Start the engine.
3. Set the parking brake pedal (7) to "**LOCK**" position.
4. Engage the PTO clutch lever (3).
5. Shift the PTO select lever (2) to "**Mid-PTO**" or "**Mid/Rear-PTO**" position.
6. Stand up. (Do not get off the machine.)
7. The engine must shut off.

- (1) Parking Brake Lock Pedal
- (2) PTO Select Lever
- (3) PTO Clutch Lever
- (4) Seat

- (5) Range Gear Shift Lever (Hi-Lo)
- (6) Speed Control Pedal
- (7) Parking Brake Pedal

W1029696




Checking Safety Devices (BX2350D with OPC) (Continued)

■ Test 5 : Switches for the operator's seat , PTO select lever and parking pedal

1. Sit on the operator's seat.
2. Set the parking brake pedal (7) to "LOCK" position.
3. Start the engine.
4. Shift the PTO select lever (2) to "Rear-PTO" position.
5. Stand up. (Do not get off the machine.)
6. The engine must not shut off.

- | | |
|------------------------------|------------------------------------|
| (1) Parking Brake Lock Pedal | (5) Range Gear Shift Lever (Hi-Lo) |
| (2) PTO Select Lever | (6) Speed Control Pedal |
| (3) PTO Clutch Lever | (7) Parking Brake Pedal |
| (4) Seat | |

W1044396





Greasing

1. Apply a small amount of multipurpose grease to the following points.

- | | |
|----------------------|-------------------------|
| (1) Battery Terminal | (2) Speed Control Pedal |
|----------------------|-------------------------|

W1015242



Checking Wheel Mounting Screws Tightening Torque



CAUTION


- **Never operate tractor with a loose rim, wheel, or axle.**
 - **Any time screws are loosened, retighten to specified torque.**
 - **Check all screws frequently and keep them tight.**
1. Check wheel screws regularly especially when new. If there are loosened, tighten as follows.

Tightening torque	Front wheel mounting screws	149.2 to 179.0 N·m 15.2 to 18.3 kgf·m 110 to 132 lbf·ft
	Rear wheel mounting screws	108.5 to 130.2 N·m 11.1 to 13.3 kgf·m 80 to 96 lbf·ft

- (1) Front Wheel Mounting Screw
- (2) Rear Wheel Mounting Screw

[A] Front
[B] Rear

W1015311




[4] CHECK POINTS OF EVERY 100 HOURS

Changing Engine Oil

1. See page G-12.

W1015501

Checking Battery Condition



To avoid the possibility of battery explosion:

For the refillable type battery, follow the instructions below.

- Do not use or charge the refillable type battery if the fluid level is below the LOWER (lower limit level) mark. Otherwise, the battery component parts may prematurely deteriorate, which may shorten the battery's service life or cause an explosion. Check the fluid level regularly and add distilled water as required so that the fluid level is between the UPPER and LOWER levels.




CAUTION

- Never remove the vent plugs while the engine is running.
 - Keep electrolyte away from eyes, hands and clothes. If you are spattered with it, wash it away completely with water immediately and get medical attention.
 - Wear eye protection and rubber gloves when working around battery.
1. Mishandling the battery shortens the service life and adds to maintenance costs.
 2. The original battery is maintenance free type battery, but need some servicing.
If the battery is weak, the engine is difficult to start and the lights become dim. It is important to check the battery periodically.

(1) Battery

W1015551



Checking Battery Condition (To be continued)

■ Battery Charging



CAUTION

- When the battery is being activated, hydrogen and oxygen gases in the battery are extremely explosive. Keep open sparks and flames away from the battery at all times, especially when charging the battery.
- When charging battery, remove battery vent caps are securely in place (if equipped).
- When disconnecting the cable from the battery, start with the negative terminal first.
When connecting the cable to the battery, start with the positive terminal first.
- Never check battery charge by placing a metal object across the posts.

Use a voltmeter or hydrometer. (For accessible maintainable type batteries with removable vent caps.)

1. Make sure each electrolyte level is to the bottom of vent wells, if necessary add distilled water in a well-ventilated area.
2. The water in the electrolyte evaporates during recharging. Liquid shortage damages the battery. Excessive liquid spills over and damages the tractor body.
3. To slow charge the battery, connect the battery positive terminal to the charger positive terminal and the negative to the negative, then recharge in the normal manner.
4. A boost charge is only for emergencies. It will partially charges the battery at a high rate and in a short time.
When using a boost-charged battery, it is necessary to recharge the battery as early as possible.
Failure to do this will shorten the battery's service life.
5. When the specific gravity of electrolyte become between 1.27 and 1.29 charge has completed.
6. When exchanging an old battery for a new one, use battery of equal specification shown in table 1.

Table 1

Battery Type	Volts (V)	Reserve Capacity (min.)	Cold Cranking Amps
526RA	12	80	535

- (1) Lowest Level
(2) Highest Level
(2) Electrolyte

- (4) Vent Well
(5) Separator

W1019057


Checking Battery Condition (Continued)

■ Battery for storage

1. When storing the tractor for a long period, remove the battery from tractor, adjust the electrolyte to the proper level and store in a dry place out of direct sunlight.
2. The battery self-discharges while it is stored.
Recharge it once every three months in hot seasons and once every six months in cold seasons.
3. (For non-accessible maintenance-free type batteries.)
Maintenance-free, non-accessible batteries are designed to eliminate the need to add water. Yet the volume of electrolyte above plates may eventually become depleted due to abnormal conditions such as high heat or improper regulator setting. Use a voltmeter to check the state of charge. (See reference chart below to determine if charging is necessary.)

Battery voltage	Reference state of charge
12.6	100 % (Full charge)
12.4	75 %
12.2	50 %
12.0	25 %
11.8	0 %

W1033625



Cleaning Air Cleaner Element

⚠ CAUTION

- **Be sure to stop the engine and remove the key before cleaning air cleaner element.**
1. Remove the air cleaner cover (2) and the element (1).
 - Undo the hook.
 - Turn the cover clockwise and detach it.
 2. Clean the element:
 - When dry dust adheres to the element, blow compressed air from the inside, turning the element. Pressure of compressed air must be under 205 kPa (2.1 kgf/cm², 30 psi).
 - When carbon or oil adheres to the element, soak the element in detergent for 15 minutes then wash it several times in water, rinse with clean water and dry it naturally. After element is fully dried, inspect inside of the element with a light and check if it is damaged or not. (referring to the instructions on the label attached to the case.)
 3. Replace air cleaner element:
Once yearly or after every sixth cleaning, whichever comes first.

■ NOTE

- **Check to see if the evacuator valve is blocked with dust.**

■ IMPORTANT

- **The air cleaner uses a dry element, never apply oil.**
- **Do not run the engine with filter element removed.**
- **Align the arrow marks when reinstalling the cover. If the cover is improperly fitted, dust passes by the baffle and directly adheres to the element.**



■ Evacuator Valve

Open the evacuator valve once a week under ordinary conditions or daily when used in a dusty place to get rid of large particles of dust and dirt.

(1) Element
(2) Cover

(3) Evacuator Valve

W1017166



Checking Fuel Lines and Fuel Filter

CAUTION

- Stop the engine and remove the key before checking fuel lines and fuel filter.
- Check the fuel lines periodically. The fuel lines are subject to wear and aging. Fuel may leak out onto the running engine, causing a fire.

The fuel line connections should be checked annually or every 100 service hours, whichever occurs first.

1. The fuel line is made of rubber and ages regardless of service period.
2. After inspection, if the fuel line and clamps are found damaged or deteriorated, replace them.
3. Check fuel filter, if it is clogged by debris or contaminated by water, replace it.

IMPORTANT


- When the fuel line is disconnected for maintenance or repair, plug both ends of the fuel line with a clean plug of suitable size to prevent dust and dirt from entering. Particular care must be taken not to admit dust and dirt into the fuel system. Entrance of dust and dirt causes malfunction of the fuel pump.

NOTE

- If the fuel line is removed, be sure to properly bleed the fuel system (see "Bleeding Fuel System" in service as required).

- | | |
|-----------------|-----------------|
| (1) Pipe Clamps | (4) Fuel Pump |
| (2) Fuel Line | (5) Fuel Filter |
| (3) Fuel Filter | |

W1017546



Checking Fan Belt Tension

⚠ CAUTION

- **Be sure to stop engine and remove the key before checking belt tension.**



1. Stop the engine and remove the key.
2. Apply moderate thumb pressure to belt between pulleys.
3. If tension is incorrect, loosen the alternator mounting bolts and using a lever placed between the alternator and the engine block, pull the alternator out until the deflection of the belt falls within acceptable limits.
4. Replace fan belt if it is damaged.

Fan belt tension	Factory specification	A deflection of between 7 to 9 mm (0.28 to 0.34 in.) when the belt is pressed in the middle of the span.
------------------	-----------------------	--

(1) Mounting Bolt

(A) Check the belt tension

W1017708



Checking and Adjusting HST Neutral Spring (for Dynamic Braking)

⚠ WARNING

- Do not operate if tractor move on level ground with foot off speed control pedal.
- If tractor moves on level ground with foot off the pedal, or, if the pedal is too slow in returning to “NEUTRAL” position when removing the foot from the pedal, adjust the HST neutral spring.

The HST neutral spring located under the front right side of the fender can adjust returning speed of speed control pedal.

Since the HST neutral spring tension is weakened, the HST tension should be checked and adjusted every 100 hours.

1. Checking the HST neutral spring : Dynamic braking

- Start the engine and hold the maximum engine speeds.
- Operate the machine on the concrete level ground.
- Shift the range gear shift lever to “High” position.
- Depress the speed control pedal to “Forward”.
- Release the foot from the speed control pedal.
- Check the distance between the foot releasing point and the machine stopping point.
- If the distance is more than approximately 3 m (9.8 feet), strengthen the HST neutral spring tension so that the machine will stop in approximately 3 m (9.8 feet) after releasing the foot from the speed control pedal.

(Reference)

Distance (L) between the foot releasing point and the machine stopping point	Reference	Approx. 3 m (9.8 feet)
--	-----------	------------------------

2. Remove the step from the machine.

- Loosen the lock nut (2).
- Turn the adjusting nut (3) half turn to pull the HST neutral spring (1).
- Tighten and lock the lock nut (2).
- Start the engine and check dynamic brake as mentioned former.
- If the machine will not stop with dynamic brake in approximately 3 m (9.8 feet), adjust the neutral spring again.


(Reference)

Length (M) of adjusting rod at shipping the machine from the factory	Reference	10 mm 0.39 in.
--	-----------	-------------------

- (1) HST Neutral Spring
- (2) Lock Nut
- (3) Adjusting Nut
- (4) Adjusting Rod

- (A) Foot Releasing Point
- (B) Machine Stopping Point
- L : Distance between Foot Releasing Point and the Machine Stopping Point
- M : Length of Adjusting Rod from Stay

W1079634



Adjusting Brake Pedal Free Travel



CAUTION

- Stop the engine, remove the key, lower the implement to the ground, and chock the wheels before checking brake pedal.
- Even if the brake pedal free travel is within the limitation, adjust the brake pedal following the procedure below.


1. Release the parking brake.
2. Loosen the lock nut and turn the turnbuckle to adjust the rod length so that the brake pedal free travel is 10 mm (0.4 in.).
3. Extend the turnbuckle one additional turn.
4. Retighten the lock nut.
5. Depress the brake pedal several times and make sure the brake pedal free travel is from 25 to 35 mm (1.0 to 1.4 in.).

Brake pedal free travel	Factory specification	25 to 35 mm 1.0 to 1.4 in.
-------------------------	-----------------------	-------------------------------

- (1) Lock Nut
- (2) Turnbuckle

A : Free Travel

W1018144



Adjusting Emergency Hand Brake Lever


1. Release the parking brake.
2. Check if the free travel at the top of the hand brake lever is from 0 to 10 mm (0 to 0.4 in.). If not, adjust as follows.
 - Loosen nut (4) and tighten nut (3) of the hand brake lever cable so that the free travel of the hand brake lever is 0 mm (0 in.). Retighten nut (4)
3. Make sure that the free travel at the top of the hand brake lever is 0 to 10 mm (0 to 0.4 in.).

Emergency hand brake lever free travel	Factory specification	0 to 10 mm 0 to 0.4 in.
--	-----------------------	----------------------------

- (1) Emergency Hand Brake Lever
- (2) Hand Brake Lever Cable
- (3) Nut
- (4) Nut

A : Free Travel

W1030221




[5] CHECK POINTS OF EVERY 200 HOURS

Replacing Engine Oil Filter

1. See page G-12.

W1018516



Checking Radiator Hoses and Hose Clamps

Check to see if radiator hoses are properly fixed every 200 hours of operation or six months, whichever comes first.

1. If hose clamps are loose or water leaks, tighten clamps securely.
2. Replace hoses and tighten hose clamps securely, if radiator hoses are swollen, hardened or cracked.
3. Properly dispose of used coolant.

Replace hoses and hose clamps every 2 years or earlier if checked and found that hoses are swollen, hardened or cracked.

■ Precaution at Overheating


Take the following actions in the event the coolant temperature be nearly or more than the boiling point, what is called "Overheating".

1. Stop the machine operation in a safe place and keep the engine idling unloaded.
2. Don't stop the engine suddenly, but stop it after about 5 minutes of unloaded idling.
3. Keep yourself well away from the machine for an additional 10 minutes or until the steam has blown out.
4. Checking that there is no danger such as burn, get rid of the cause of overheating according to the manual, see "ENGINE" section, and then, start the engine again.

(1) Radiator Hose

(2) Hose Clamp

W1018562



Checking Power Steering Line


⚠ CAUTION


- Be sure to stop the engine and remove the key before checking power steering line.

1. Check to see that all lines are tight and not damaged.
2. If hoses are found to be worn or damaged, replace or repair them at once.

(1) Power Steering Hose

W1018751






Checking Intake Air Line

1. Check to see that hose and hose clamps are tight and not damaged.
2. If hose and clamps are found to be worn or damaged, replace or repair them at once.

(1) Hose

(2) Clamp

W1018915



Adjusting Toe-in


1. Park tractor on a firm, flat and level place.
2. Turn steering wheel so front wheels are in the straight ahead position.
3. Lower the implement to the ground, lock the parking brake, stop the engine and remove the key.
4. Measure distance between tire beads at front of tire at hub height.
5. Measure distance between tire beads at rear of tire at hub height.
6. Front distance should be 0 to 5 mm (0 to 0.19 in.) less that rear distance. If not, adjust tie rod length.

Toe-in ((B) – (A))	Factory specification	0 to 5 mm 0 to 0.19 in.
--------------------	-----------------------	----------------------------

Adjusting

1. Loosen the lock nuts and turn the steering tie-rod to adjust the rod length until the proper toe-in measurement is obtained.
2. Retighten the lock nuts.

(1) Lock Nut
(2) Tie-rod

(A) Wheel to Wheel Distance at Front
(B) Wheel to Wheel Distance at Rear
(C) Front


W1019009

[6] CHECK POINTS OF EVERY 300 HOURS

Replacing Transmission Oil Filter

1. See page G-13.

W1019345

Changing Transmission Fluid

1. See page G-13.

W1019295

Cleaning Transmission Oil Strainer

1. When changing the transmission fluid, disassemble and rinse the strainer with nonflammable solvent to completely clean off fillings.
2. When reassembling, be careful not to damage the parts.




■ NOTE

- Since the fine fillings in the oil can damage the precision component parts of the hydraulic system, the end of the suction line is provided with an oil strainer.

(1) Strainer

(2) Filter Plate

W1019390



Changing Front Axle Case Oil

1. Park the machine on a firm, flat and level surface.
2. To drain the used oil, remove the right and left drain plugs and oil gauge at the front axle case and drain the oil completely into the oil pan.
3. After draining, reinstall the drain plugs.
4. Remove the right and left breather plugs.
5. Fill with new oil up to the upper notch on the dipstick.

■ IMPORTANT

- After ten minutes, check the oil level again; add oil to prescribed level.
6. After filling, reinstall the oil gauge and breather plugs.

Front axle case oil	Capacity	4.7 L 5.0 U.S.qts 4.1 Imp.qts
---------------------	----------	-------------------------------------

(1) Breather Plug


(2) Oil Gauge with Dipstick

(3) Drain Plug

(A) Oil level is acceptable within this range.

W1019508

[7] CHECK POINT OF EVERY 400 HOURS



Adjusting Front Axle Pivot

1. Remove the split pin (2), tighten the adjusting nut (1).
2. Make sure that one of the nut slots aligns with the split pin hole, tighten the nut slightly if necessary to align.
3. Replace the split pin.


Tightening torque	Factory specification	20 N·m 2.0 kgf·m 15 lbf·ft
-------------------	-----------------------	----------------------------------

(1) Adjusting Nut

(2) Split Pin

W1019713

[8] CHECK POINT OF EVERY 500 HOURS



Replacing Fuel Filter Element

1. Disconnect the fuel hoses and replace the fuel filter (2).
2. Disconnect the fuel hoses and loosen the pipe clamp to replace the fuel filter (5).

■ NOTE

- If the fuel line is removed, be sure to properly bleed the fuel system. (See page G-31.)

(1) Fuel Pump


(4) Hose Clamp

(2) Fuel Filter

(5) Fuel Filter

(3) Fuel Line

W1019858



[9] CHECK POINT OF EVERY 800 HOURS**Adjusting Engine Valve Clearance**

1. See page 1-S13.

W1019995

[10] CHECK POINT OF EVERY 1500 HOURS**Checking Fuel Injection Nozzle Injection Pressure**

1. See page 1-S20.

W1020203

[11] CHECK POINT OF EVERY 3000 HOURS**Checking Injection Pump**

1. See page 1-S19.

W1020260

[12] CHECK POINT OF EVERY 1 YEAR**Replacing Air Cleaner Element**

1. See page G-18.

W1020343

[13] CHECK POINTS OF EVERY 2 YEARS**Replacing Radiator Hoses (Water Pipes)**

1. Replace the hoses and clamps.
Refer to “**Checking Radiator Hoses and Hose Clamps**”.
(See page G-23.)

W1020468

Replacing Power Steering Hoses

1. Replace the hoses.
Refer to “**Checking Power Steering Line**”.
(See page G-23.)

W1020513

Replacing Fuel Line



1. Replace the hoses and clamps.
Refer to “**Checking Fuel Line and Fuel Filter**”.
(See page G-19.)

W1020558

Replacing Intake Air Line

1. Replace the intake hose.
2. Refer to “**Checking Intake Air Line**”.
(See page G-24.)

W1020422



Flushing Cooling System and Changing Coolant

CAUTION

- Be sure to stop the engine and remove the key before checking coolant level.
- Do not remove the radiator cap when the engine is hot. Then loosen cap slightly to the stop to relieve any excess pressure before removing cap completely.

1. Stop the engine, remove the key and let cool down.
2. To drain the coolant, open the radiator drain plug, and remove radiator cap. The radiator cap must be removed to completely drain the coolant.
3. After all coolant is drained, close the drain plug.
4. Fill with clean water and cooling system cleaner.
5. Follow directions of the cleaner instruction.
6. After flushing, fill with clean water and anti-freeze until the coolant level is just below the radiator cap. Install the radiator cap securely.
7. Fill with coolant up to "H" mark on the recovery tank.
8. Start and operate the engine for few minutes.
9. Stop the engine, remove the key and let cool.
10. Check coolant level of recovery tank and add coolant if necessary.
11. Properly dispose of used coolant.

IMPORTANT

- Do not start engine without coolant.
- Use clean, fresh water and anti-freeze to fill the radiator.
- When the anti-freeze is mixed with water, the anti-freeze mixing ratio must be less than 50 %.
- Securely tighten radiator cap. If the cap is loose or improperly fitted, water may leak out and the engine could overheat.

Coolant (with recovery tank)	Capacity	3.1 L 3.3 U.S.qts 2.7 Imp.qts
---------------------------------	----------	-------------------------------------

(1) Radiator Cap

(2) Drain Plug

W1021307

Flushing Cooling system and Changing Coolant (To be continued)**■ Anti-Freeze****CAUTION**

- When using antifreeze, put on some protection such as rubber gloves (Antifreeze contains position.).
- If should drink antifreeze, throw up at once and take medical attention.
- When antifreeze comes in contact with the skin or clothing, wash it off immediately.
- Do not mix different types of Antifreeze.
The mixture can produce chemical reaction causing harmful substances.
- Antifreeze is extremely flammable and explosive under certain conditions. Keep fire and children away from antifreeze.
- When draining fluids from the engine, place some container underneath the engine body.
- Do not pour waste onto the grounds, down a drain, or into any water source.
- Also, observe the relevant environmental protection regulations when disposing of antifreeze.

If it freezes, coolant can damage the cylinders and radiator. If the ambient temperature falls below 0 °C (32 °F) or before a long-term storage, let out cooling water completely, or mix fresh water with long-life coolant and fill the radiator and reserve tank with the mixture.

1. Long-life coolant (hereafter LLC) comes in several types. Use ethylene glycol (EG) type for this engine.
2. Before employing LLC-mixed cooling water, fill the radiator with fresh water and empty it again.
Repeat this procedure 2 or 3 times to clean up the inside.
3. Mixing the LLC.
Put the LLC in cooling water in the percentage (%) for a target temperature. When mixing, stir it up well, and then fill into the radiator.
4. The procedure for the mixing of water and antifreeze differs according to the make of the antifreeze and the ambient temperature. Refer to SAE J1034 standard, more specifically also to SAE J814c.

■ IMPORTANT

- When the antifreeze is mixed with water, the antifreeze mixing ratio must be less than 50 %.

Vol % Anti-freeze	Freezing Point		Boiling Point*	
	°C	°F	°C	°F
40	-24	-12	106	222
50	-37	-34	108	226

* At 1.013×10^5 Pa (760 mm Hg) pressure (atmospheric).

A higher boiling point is obtained by using a radiator pressure cap which permits the development of pressure within the cooling system.


W1022492

Flushing Cooling system and Changing Coolant (Continued)

5. Adding the LLC.
 - Add only water if the mixture reduces in amount by evaporation.
 - If there is a mixture leak, add the LLC of the same manufacture and type in the same mixture percentage.
 - * Never add any long-life coolant of different manufacture. (Different brands may have different additive components, and the engine may fail to perform as specified.)
6. When the LLC is mixed, do not employ any radiator cleaning agent. The LLC contains anticorrosive agent. If mixed with the cleaning agent, sludge may build up, adversely affecting the engine parts.
7. KUBOTA's genuine long-life coolant has a service life of 2 years. Be sure to change the coolant every 2 years.

W1032576

[14] OTHERS



Bleeding Fuel System

Air must removed:

1. When the fuel filter (2) or lines are removed.
2. When tank is completely empty.
3. After the tractor has not been used for a long period of time.


■ Bleeding procedure is as follows:

1. Fill the fuel tank with fuel.
2. Turn the key switch to “ON” position for about 30 seconds. Doing so allows fuel pump (1) to work and pump air out of the fuel system.
3. Start the engine and run for about 30 seconds, and then stop the engine.

(1) Fuel Pump

(2) Fuel Filter

W1021149



Replacing Fuse (BX2350D without OPC)

1. The tractor electrical system is protected from potential damage by fuses.
A blown fuse indicates that there is an overload or short somewhere in the electrical system.
2. If any of the fuses should blow, replace with a new one of the same capacity.

■ IMPORTANT

- Before replacing a blown fuse, determine why the fuse blew and make any necessary repairs. Failure to follow this procedure may result in serious damage to the tractor electrical system.

If any of the fuses should blow, replace with a new one of the same capacity.


■ Protected Circuit



[Fuse Box]

Fuse No.	Capacity	Protected circuit
(1)	10 A	Parking
(2)	15 A	Solenoid
(3)	15 A	Hazard Light
(4)	10 A	ACC
(5)	20 A	Working Light
(6)	10 A	Beacon
(7)	10 A	Outlet
(8)	15 A	Head Light
(9)	10 A	Brake Light
(10)	Slow Blow Fuse (50A)	Check circuit against wrong battery connection

(B) Fuse Box

W1023430





Replacing Fuse (BX2350D with OPC)

1. The tractor electrical system is protected from potential damage by fuses.
A blown fuse indicates that there is an overload or short somewhere in the electrical system.
2. If any of the fuses should blow, replace with a new one of the same capacity.

■ IMPORTANT

- Before replacing a blown fuse, determine why the fuse blew and make any necessary repairs. Failure to follow this procedure may result in serious damage to the tractor electrical system.

If any of the fuses should blow, replace with a new one of the same capacity.




■ Protected Circuit

[Fuse Box]

Fuse No.	Capacity	Protected circuit
(1)	10 A	Parking
(2)	15 A	Solenoid
(3)	15 A	Hazard Light
(4)	10 A	ACC
(5)	20 A	Working Light
(6)	10 A	Timer Relay
(7)	10 A	Beacon
(8)	10 A	Outlet
(9)	15 A	Head Light
(10)	10 A	Brake Light
(11)	Slow Blow Fuse (50A)	Check circuit against wrong battery connection

(B) Fuse Box

W1029150



Replacing Light Bulb

- 1. Head lights:
Take the bulb out of the light body and replace with a new one.
- 2. Other lights:
Detach the lens and replace the bulb.


Light	Capacity
Head light	40 W / 45 W
Turn signal / Hazard light	21 W
Front position light	10 W
Stop light / Tail light	21 W / 5 W
Number plate light	5 W

- (1) Head Light
- (2) Turn signal / Hazard light
- (3) Front position light
- (4) Stop light / Tail light
- (5) Number plate light

W1023802

8. SPECIAL TOOLS

[1] SPECIAL TOOLS FOR ENGINE




3TMABAB0P049A

Special Use Puller Set

Code No.: 07916-09032

Application: Use exclusively for pulling out bearing, gears and other parts with ease.

W1024050




3TMABAB0P050A

Piston Ring Compressor

Code No.: 07909-32111

Application: Use exclusively for pushing in the piston with piston rings into the cylinder.

W1024100




3TMABAB0P051A

Piston Ring Tool

Code No.: 07909-32121

Application: Use exclusively for removing or installing the piston ring with ease.

W1024150



3EEABAE0P002A

Diesel Engine Compression Tester (for Injection Nozzle)

Code No.: 07909-30208 (Assembly) 07909-31251 (G)

07909-30934 (A to F) 07909-31271 (I)

07909-31211 (E and F) 07909-31281 (J)


07909-31231 (H)

Application: Use to measure diesel engine compression and diagnostics of need for major overhaul.

- (1) Gauge
- (2) L Joint
- (3) Adaptor A
- (4) Adaptor B
- (5) Adaptor C
- (6) Adaptor E

- (7) Adaptor F
- (8) Adaptor G
- (9) Adaptor H
- (10) Adaptor I
- (11) Adaptor J

W1024200




Diesel Engine Compression Tester (for Glow Plug)

Code No.: 07909-39081 (Assembly) 07909-31301 (L)
07909-31291 (K) 07909-31311 (M)

Application: Use to measure diesel engine compression and diagnostics of need for major overhaul.

- | | |
|---------------|---------------|
| (1) Gauge | (4) Adaptor L |
| (2) L Joint | (5) Adaptor M |
| (3) Adaptor K | |

0000001398E




Oil Pressure Tester

Code No.: 07916-32032

Application: Use to measure lubricating oil pressure.

- | | |
|--------------------|---------------|
| (1) Gauge | (5) Adaptor 2 |
| (2) Cable | (6) Adaptor 3 |
| (3) Threaded Joint | (7) Adaptor 4 |
| (4) Adaptor 1 | (8) Adaptor 5 |

W1024318



Valve Seat Cutter


Code No.: 07909-33102

Application: Use to reseal valves.

Angle: 0.785 rad (45°)
0.262 rad (15°)

Diameter: 28.6 mm (1.126 in.)	38.0 mm (1.496 in.)
31.6 mm (1.244 in.)	41.3 mm (1.626 in.)
35.0 mm (1.378 in.)	50.8 mm (2.000 in.)

W1024458




Radiator Tester

Code No.: 07909-31551

Application: Use to check of radiator cap pressure, and leaks from cooling system.

Remarks: Adaptor (1) BANZAI Code No. RCT-2A-30S

W1024532




Connecting Rod Alignment Tool

Code No.: 07909-31661

Application: Use to check the connecting rod alignment.

Applicable: Connecting rod big end I.D.
range 30 to 75 mm (1.18 to 2.95 in.) dia.
Connecting rod length
65 to 300 mm (2.56 to 11.81 in.)

W1024583



3TLABAB1P041A


Nozzle Tester

Code No.: 07909-31361

Application: Use to check the fuel injection pressure and spray pattern of nozzle.

Measuring: 0 to 50 MPa
range (0 to 500 kgf/cm², 0 to 7000 psi)

W1024653



3TMABAB0P058A


Plastigage

Code No.: 07909-30241

Application: Use to check the oil clearance between crankshaft and bearing, etc..

Measuring: Green 0.025 to 0.076 mm (0.001 to 0.003 in.)
range Red 0.051 to 0.152 mm (0.002 to 0.006 in.)
Blue 0.102 to 0.229 mm (0.004 to 0.009 in.)

W1024719




3TMABAB0P059A

Red Check

Code No.: 07909-31371

Application: Use to check cracks on cylinder head, cylinder block, etc..

W1024909




3TMABAB0P063A

Valve Guide Replacing Tool




Application: Use to press out and press fit the valve guide.

A	20 mm dia. (0.79 in. dia.)
B	11.7 to 11.9 mm dia. (0.460 to 0.468 in. dia.)
C	6.5 to 6.6 mm dia. (0.256 to 0.259 in. dia.)
D	225 mm (8.86 in.)
E	70 mm (2.76 in.)
F	45 mm (1.77 in.)
G	25 mm (0.98 in.)
H	5 mm (0.197 in.)
I	6.7 to 7.0 mm dia. (0.263 to 0.275 in. dia.)
J	20 mm dia. (0.787 in. dia.)
K	12.5 to 12.8 mm dia. (0.492 to 0.504 in. dia.)
L	8.9 to 9.1 mm (0.350 to 0.358 in.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)

W1025017



3TMABAB0P064A



Valve Guide Replacing Tool

Application: Use to press out and press fit the valve guide.

A	20 mm dia. (0.79 in. dia.)
B	9.96 to 9.98 mm dia. (0.3921 to 0.3929 in. dia.)
C	5.5 to 5.7 mm dia. (0.2165 to 0.2244 in. dia.)
D	220 mm (8.66 in.)
E	80 mm (3.15 in.)
F	40 mm (1.58 in.)
G	25 mm dia. (0.98 in. dia.)
H	5 mm (0.197 in.)
I	6.0 to 6.1 mm dia. (0.236 to 0.240 in. dia.)
J	18 mm dia. (0.71 in. dia.)
K	10.6 to 10.7 mm dia. (0.417 to 0.421 in. dia.)
L	6.9 to 7.1 mm (0.272 to 0.280 in.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)

W12345689

Bushing Replacing Tool

Application: Use to press out and press fit the bushing.


1. For small end bushing

A	145 mm (5.71 in.)
B	20 mm (0.79 in.)
C	100 mm (3.94 in.)
D	19.90 to 19.95 mm dia. (0.7835 to 0.7854 in. dia.)
E	21.90 to 21.95 mm dia. (0.8622 to 0.8642 in. dia.)
F	25 mm dia. (0.98 in. dia.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)
a	6.3 μ m (250 μ in.)
b	6.3 μ m (250 μ in.)

2. For idle gear bushing

A	150 mm (5.91 in.)
B	23 mm (0.91 in.)
C	100 mm (3.94 in.)
D	19.90 to 19.95 mm dia. (0.7835 to 0.7854 in. dia.)
E	21.90 to 21.95 mm dia. (0.8622 to 0.8642 in. dia.)
F	25 mm dia. (0.98 in. dia.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)
a	6.3 μ m (250 μ in.)
b	6.3 μ m (250 μ in.)

W12358870




Flywheel Stopper

Application: Use to loosen and tighten the flywheel screw.

A	200 mm (7.87 in.)
B	30 mm (1.18 in.)
C	20 mm (0.79 in.)
D	15 mm (0.59 in.)
E	8 mm (0.31 in.)
F	10 mm dia. (0.39 in. dia.)

W98765423



Crankshaft Bearing 1 Replacing Tool

Application: Use to press out and press fit the crankshaft bearing 1.

[Press Out]


A	135 mm (5.31 in.)
B	72 mm (2.83 in.)
C	40 mm radius (1.57 in. radius)
D	10 mm (0.39 in.)
E	22 mm (0.87 in.)
F	20 mm dia. (0.79 in. dia.)
G	47.90 to 47.95 mm dia. (1.8858 to 1.8878 in. dia.)
H	43.90 to 43.95 mm dia. (1.7283 to 1.7303 in. dia.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)

[Press Fit] for D902-E2B

A	130 mm (5.12 in.)
B	72 mm (2.83 in.)
C	40 mm radius (1.57 in. radius)
D	9 mm (0.35 in.)
E	24 mm (0.95 in.)
F	20 mm dia. (0.79 in. dia.)
G	68 mm dia. (2.68 in. dia.)
H	43.90 to 43.95 mm dia. (1.7283 to 1.7303 in. dia.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)

W56478912

[2] SPECIAL TOOLS FOR TRACTOR




Tie-rod End Lifter

Code No.: 07909-39051

Application: Use for removing the tie-rod end with ease

W1026472




Relief Valve Pressure Tester

Code No.: 07916-50045

Application: This allows easy measurement of relief set pressure.

- | | |
|---|--|
| (1) Gauge (07916-50322) | (6) Adaptor C (PS3/8) (07916-50371) |
| (2) Cable (07916-50331) | (7) Adaptor D (PT1/8) (07916-50381) |
| (3) Threaded Joint (07916-50401) | (8) Adaptor E (PS3/8) (07916-50392) |
| (4) Threaded Joint (07916-50341) | (9) Adaptor F (PF1/2) (07916-62601) |
| (5) Adaptor B (M18 × P1.5) (07916-50361) | (10) Adaptor 58 (PT1/4) (07916-52391) |

W1026741



Hydrostatic Transmission Tester and HST Adaptor Set



Code No.: 07916-52040 (Hydrostatic Transmission Tester)

07916-53072 (HST Adaptor Set)

Application: This allows easy measurement of hydrostatic transmission pressure.

- | | |
|--|---|
| (1) Hydrostatic Transmission Tester (07916-52040) | (8) Valve Seat Driver (07916-60841) |
| (2) Gasket (04714-00200) | (9) Connector 1 (07916-60811) |
| (3) Connector 3 (07916-51331) | (10) Connector 2 (07916-60821) |
| (4) Vacuum Gauge (07916-51331) | (11) Long Connector (07916-60831) |
| (5) Pressure Gauge (Low Pressure) (07916-51301) | (12) Adaptor 1 (07916-52621) |
| (6) Pressure Gauge (High Pressure) (in Relief Valve Set Pressure Tester) (07916-50321) | (13) Adaptor 2 with Collar (07916-52632) |
| (7) HN Tube (in Relief Valve Set Pressure Tester) (07916-50331) | (14) Adaptor 3 with Collar (07916-52642) |
| | (15) HST Adaptor Set (07916-53072) |

W1023682




Independent PTO Clutch Spring Compression Tool

Application: Use for compressing the spring into the spline boss.
This tool can be used for B30 series and BX50 series.

A	12 mm (0.47 in.)
B	25.4 mm (1.00 in.)
C	19 mm radius (0.75 in.) Hex.
D	2.7 mm (0.11 in.)
E	8 mm (0.31 in.)
F	15 mm dia. (0.59 in. dia.)
G	37 mm (1.46 in.)
H	70 mm (2.76 in.)
I	M14 ×1.5
J	R 3 mm (0.12 in.)
K	30 mm (1.18 in.)
L	17 mm (0.67 in.)
M	38 mm (1.50 in.)


W10301570

Disassembling and Assembling Stand (1/2)

3TAAAAG0P023A

Application: Use to disassembling transaxle assembly and to assembling transaxle assembly.

A	φ 9 mm (φ 0.35 in.) 3 Holes	L	30.5 to 31.5 mm (1.21 to 1.24 in.)
B	225 mm (8.86 in.)	M	226 mm (8.90 in.)
C	φ 13 mm (φ 0.51 in.) 3 Holes	N	125.5 to 126.5 mm (4.95 to 4.98 in.)
D	140 mm (5.51 in.)	O	352 mm (13.86 in.)
E	99.5 to 100.5 mm (3.92 to 3.95 in.)	P	25 mm (0.98 in.)
F	59.5 to 60.5 mm (2.35 to 2.38 in.)	Q	9.5 mm (0.37 in.)
G	92.5 to 93.5 mm (3.65 to 3.68 in.)	R	397 mm (15.63 in.)
H	12.5 to 13.5 mm (0.50 to 0.53 in.)	S	46 mm (1.81 in.)
I	55 mm (2.17 in.)	T	R 25 mm (0.98 in.)
J	20 mm (0.79 in.)	U	11 mm (0.43 in.)
K	17 mm (0.67 in.)	W	20 mm (0.79 in.)

Disassembling and Assembling Stand (2/2)

Application: Use to disassembling transaxle assembly and to assembling transaxle assembly.

A	311 mm (12.24 in.)	L	38.1 mm (1.50 in.)
B	40 mm (1.57 in.)	M	1.9 mm (0.07 in.)
C	38.1 mm (1.50 in.)	N	4.8 mm (0.19 in.)
D	235 mm (9.25 in.)	O	200 mm (7.87 in.)
E	170 mm (6.69 in.)	P	φ 9 mm (φ 0.35 in.), 3 Holes
F	9.5 mm (0.37 in.)	Q	25 mm (0.98 in.)
G	6.4 mm (0.25 in.)	R	39.5 to 40.5 mm (1.56 to 1.59 in.)
H	365 mm (14.37 in.)	S	140 mm (5.51 in.)
I	377.8 mm (14.87 in.)	T	260 mm (10.24 in.)
J	50.8 mm (2.00 in.)	U	99.5 to 100.5 mm (3.92 to 3.95 in.)
K	40 mm (1.57 in.)	V	45 mm (1.77 in.)

9. TIRES

[1] TIRE PRESSURE



WARNING

- Do not attempt to mount a tire on a rim. This should be done by a qualified person with the proper equipment.
- Always maintain the correct tire pressure.
Do not inflate tires above the recommended pressure shown in the operator's manual.

■ IMPORTANT

- Do not use tires larger than specified.
- When you intend to mount different size of tires from equipped ones, consult your distributor about front drive gear ratio for detail.
Excessive wear of tires may occur due to improper gear ratio.

	Tire sizes	Inflation pressure
Rear	26 × 12.00 – 12 Turf	100 kPa (1.0 kgf/cm ² , 14 psi)
	26 × 12.00 – 12 Bar	120 kPa (1.2 kgf/cm ² , 17 psi)
	26 × 12.00 – 12 Ind.	120 kPa (1.2 kgf/cm ² , 17 psi)
Front	18 × 8.50 – 10 Turf	120 kPa (1.2 kgf/cm ² , 17 psi)
	18 × 8.50 – 10 Bar	150 kPa (1.5 kgf/cm ² , 22 psi)
	18 × 8.50 – 10 Ind.	150 kPa (1.5 kgf/cm ² , 22 psi)

Though the tire pressure is factory-set to the prescribed level, it naturally drops slowly in the course of time. Thus, check it everyday and inflate as necessary.

■ NOTE

- Maintain the maximum pressure in front tires, if using a front loader or when equipped with a full load of front weights.

[2] WHEEL TREAD

(1) Front Wheels


Front tread can not be adjusted.

■ IMPORTANT


- Do not turn discs to obtain wider tread.

■ NOTE

- Use the tapered bolts for wheels with beveled or tapered holes.

Tire	18 × 8.50 – 10 Turf 18 × 8.50 – 10 Bar 18 × 8.50 – 10 Ind.
Tread	 3TAAAAG0P025A

A : 910 mm (35.8 in.)



Tightening torque	Front wheel	149.2 to 179.0 N·m 15.2 to 18.3 kgf·m 110 to 132 lbf·ft
-------------------	-------------	---

(1) Wheel Mounting Screw

W1045824

(2) Rear Wheels


Rear tread can not be adjusted.

■ IMPORTANT


- Do not turn discs to obtain wider tread.
- Always attach tires as shown in the drawing.
- If not attached as illustrated, transmission parts may be damaged.
- When re-fitting or adjusting a wheel, tighten the bolts to the following torques then recheck after driving the tractor 200 m (200 yards) and thereafter daily check service.

■ NOTE

- Use the tapered bolts for wheels with beveled or tapered holes.

Tire	26 × 12.00 – 12 Turf 26 × 12.00 – 12 Bar 26 × 12.00 – 12 Ind.
Tread	 3TAAAAG0P006B

A : 820 mm (32.2 in.)



Tightening torque	Rear wheel	108.5 to 130.2 N·m 11.1 to 13.3 kgf·m 80 to 96 lbf·ft
-------------------	------------	---

(1) Wheel Mounting Screw

W1031345


[3] BALLAST

(1) Front Ballast

Add weights needed for stability and improve traction.

Heavy pulling and heavy rear mounted implements tend to lift front wheels. Add enough ballast to maintain steering control and prevent tip over.

Remove weight when no longer needed.



Front End Weights (Option)

1. The front end weights can be attached to the bumper.

See your implement operator's manual for required number of weights.

■ NOTE

- Besides the weight, a front weight bracket and mounting bolt kit(s) are required for mounting the weight.

■ IMPORTANT

- Do not overload tires.
- Add no more weight than indicated in chart.

Maximum weight	125 kg (275 lbs)
----------------	------------------

(1) Front End Weights


(2) Front Weight Bracket (Option)

W1029958

(2) Rear Ballast

Add weights to rear wheels if needed to improve traction or for stability. The amount of rear ballast should be matched to job and the ballast should be removed when it is not needed.

The weight should be added to the tractor in the form of liquid ballast.



Liquid Ballast in Rear Tires

1. Water and calcium chloride solution provides safe economical ballast. Used properly, it will not damage tires, tubes or rims.
2. The addition of calcium chloride is recommended to prevent the water from freezing.
3. Use of this method of weighting the wheels has the full approval of the tire companies.

■ IMPORTANT


- Do not fill tires with water or solution more than 75 % of full capacity (to the level of valve stem at 12 o'clock position).
- To avoid damage of transmission, do not use rear wheel weights and liquid ballast at the same time.

Tire sizes	26 × 12.00 – 12
Slush free at –10 °C (14 °F) Solid at –30 °C (–22 °F) [Approx. 1 kg (2 lbs) CaCl ₂ per 4 L (1 gal.) of water]	45 kg (99 lbs)
Slush free at –24 °C (–11 °F) Solid at –47 °C (–52 °F) [Approx. 1.5 kg (3.5 lbs) CaCl ₂ per 4 L (1 gal.) of water]	50 kg (110 lbs)
Slush free at –47 °C (–53 °F) Solid at –52 °C (–62 °F) [Approx. 2.25 kg (5 lbs) CaCl ₂ per 4 L (1 gal.) of water]	56 kg (123 lbs)

- (1) Air
(2) Water
(3) Valve Stem

(A) Correct : 75 % Full Air
Compresses Like A Cushion
(B) Incorrect : 100 % Full
Water Can Not Be Compressed

W1033435



Attaching Injector

1. Lift the rear tires off the ground.
2. Turn the tire so that the air valve is at the top.
3. Remove the air valve, and attach the injector. (Code No. 07916-52511)

- (1) Injector

- (2) Hose

W1033331

10. IMPLEMENT LIMITATIONS

The KUBOTA Tractor has been thoroughly tested for proper performance with implements sold or approved by KUBOTA. Use with implements which exceed the maximum specifications listed below, or which are otherwise unfit for use with the KUBOTA Tractor may result in malfunctions or failures of the tractor, damage to other property and injury to the operator or others. [Any malfunctions or failures of the tractor resulting from use with improper implements are not covered by the warranty.]

	Tread (max. width) with farm tires		Lower link end max. loading weight W0
	Front	Rear	
BX2350D	910 mm (35.8 in.)	820 mm (32.2 in.)	550 kg (1210 lbs)


	Actual figures		
	Implement weight W1 and / or size	Max. Drawbar Load W2	Trailer loading weight W3 Max. capacity
BX2350D	As in the following list (Shown on the next page)	250 kg (550 lbs)	800 kg (1765 lbs)

Lower link end max. hydraulic lifting capacity**W0**

Implement weight.....The implement's weight which can be put on the lower link : **W1**

Max. drawbar load**W2**

Trailer loading weightThe max. loading weight for trailer (without trailer's weight) : **W3**



3TMABAB0P109A

■ NOTE

- Implement size may vary depending on soil operating conditions.

Implement		Remarks	BX2350D
Mower	Mid-Mount	Max. Cutting Width	1520 mm (60 in.)
		Max.Weight	115 kg (254 lbs)
	Rotary-Cutter (1 Blade)	Max. Cutting Width	1070 mm (42 in.)
		Max.Weight	140 kg (300 lbs)
	Rear-Mount (2 or 3 Blade)	Max. Cutting Width	1520 mm (60 in.)
		Max.Weight	140 kg (300 lbs)
	Flail Mower	Max. Cutting Width	1070 mm (42 in.)
	Sickle Bar	Max. Cutting Width	1220 mm (48 in.)
Rotary Tiller		Max. Tilling Width	1070 mm (42 in.)
		Max. Weight	170 kg (375 lbs)
Bottom Plow		Max. Size	360 mm (14 in.) × 1
Disc Plow		Max. Size	560 mm (22 in.) × 1
Cultivator		Max. Width	1220 mm (48 in.) 1 Row
Disc Harrow		Max. Harrowing Width	1370 mm (54 in.)
		Max. Weight	140 kg (300 lbs)
Sprayer		Max. Tank Capacity	150 L (40 U.S.gals, 33 Imp.gals)
Front Blade		Max. Cutting Width	1520 mm (60 in.)
		Sub Frame	Necessary
Rear Blade		Max. Cutting Width	1520 mm (60 in.)
		Max. Weight	160 kg (350 lbs)
Front Loader		Max. Lifting Capacity	240 kg (530 lbs)
		Max. Width	1220 mm (48 in.)
Box Blade		Max. Cutting Width	1220 mm (48 in.)
		Max. Weight	170 kg (375 lbs)
Snow Blower (Front)		Max. Working Width	1270 mm (50 in.)
		Max. Weight	160 kg (350 lbs)
		Sub Frame	Necessary
Post Hole Digger		Digging Depth	1140 mm (45 in.)
Rotary Broom		Cleaning Width	1190 mm (47 in.)
Trailer		Max. Load Capacity	800 kg (1765 lbs)

■ NOTE

- Backhoe cannot be attached.
- Implement size may vary depending on soil operating conditions.
- Reduce speed and trailer loads when operating in slippery conditions or when operating on slopes and utilize front wheel drive.

W1012736


1 ENGINE

MECHANISM

CONTENTS

1. LUBRICATING SYSTEM	1-M1
2. COOLING SYSTEM	1-M2
3. FUEL SYSTEM	1-M3

1. LUBRICATING SYSTEM




This engine's lubricating system consists of oil strainer (8), oil pump (7), relief valve (9), oil filter cartridge (15) and oil pressure switch (2).

The oil pump sucks lubricating oil from the oil pan through the oil strainer and the oil flows down to the filter cartridge, where it is further filtered. Then the oil is forced to crankshaft (6), connecting rods (14), idle gear (5), camshaft (12) and rocker arm shaft (3) to lubricate each part.

Some part of oil, splashed by the crankshaft or leaking and dropping from gaps of each part, lubricates these parts: piston (13), cylinders, small ends or connecting rods, tappets (11), push rods (10), inlet and exhaust valves (4) and timing gears.

2. COOLING SYSTEM




- (1) Radiator
- (2) Water Pump
- (3) Cooling Fan
- (4) Thermostat
- (5) Cylinder Head
- (6) Cylinder Block

The cooling system consists of a radiator (1), a centrifugal water pump (2), a cooling fan (3) and a thermostat (4). The coolant is cooled through the radiator core, and the cooling fan (3) set behind the radiator (1) pulls cooling air through the radiator core to improve cooling.

The water pump receives water from the radiator or from the cylinder head and force it into the cylinder block.

The thermostat opens or closes according to the water temperature. When the water temperature is high, the thermostat opens to allow the water to flow from the cylinder head to the radiator. When the water temperature is low, the thermostat close to flow the water only to the water pump.

3. FUEL SYSTEM



- (1) Injection Nozzle
- (2) Fuel Overflow Pipe
- (3) Fuel Tank
- (4) Fuel Filter
- (5) Fuel Feed Pump
- (6) Fuel Filter
- (7) Injection Pump
- (8) Injection Pipe

3TAAAF1P013A

Fuel from the fuel tank (3) passes through the fuel filter (4), and then enters the injection pump (7) after impurities such as dirt, water, etc. are removed.

The fuel pressurized by the injection pump to the opening pressure (13.7 to 14.7 MPa, 140 to 150 kgf/cm², 1990 to 2133 psi), of the injection nozzle (1) is injected into the combustion chamber.

Part of the fuel fed to the injection nozzle (1) lubricates the moving parts of the needle valve inside the nozzle, then returns to the fuel tank through the fuel overflow pipe (2) from the upper part of the nozzle holder.

SERVICING

CONTENTS

1. TROUBLESHOOTING	1-S1
2. SERVICING SPECIFICATIONS	1-S4
3. TIGHTENING TORQUES	1-S10
4. CHECKING, DISASSEMBLING AND SERVICING.....	1-S11
[1] CHECKING AND ADJUSTING	1-S11
(1) Engine Body.....	1-S11
(2) Lubricating System	1-S14
(3) Cooling System.....	1-S15
(4) Fuel System	1-S17
[2] DISASSEMBLING AND ASSEMBLING.....	1-S22
(1) Separating Engine	1-S22
(2) Removing Outer Parts	1-S24
(3) Cylinder Head and Valves	1-S25
(4) Gear Case and Timing Gears	1-S30
(5) Piston and Connecting Rod	1-S34
(6) Flywheel and Crankshaft	1-S37
(7) Injection Nozzle.....	1-S40
[3] SERVICING	1-S41
(1) Cylinder Head and Valves	1-S41
(2) Timing Gears	1-S46
(3) Piston and Connecting Rod	1-S49
(4) Crankshaft.....	1-S51
(5) Cylinder.....	1-S55
(6) Oil Pump	1-S56

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Engine Does Not Start	No fuel	Replenish fuel	G-7
	Air in the fuel system	Bleed	G-32
	Water in the fuel system	Change fuel and repair or replace fuel system	–
	Fuel pipe clogged	Clean	G-20
	Fuel filter clogged	Change	G-20
	Excessively high viscosity of fuel or engine oil at low temperature	Use specified fuel or engine oil	G-7
	Fuel with low cetane number	Use specified fuel	G-7
	Fuel leak due to loose injection pipe retaining nut	Tighten retaining nut	1-S25
	Incorrect injection timing	Adjust	1-S17
	Fuel camshaft worn	Replace	1-S34
	Injection nozzle clogged	Clean or replace	1-S25
	Injection pump malfunctioning	Replace	1-S31
	Seizure of crankshaft, camshaft, piston, cylinder or bearing	Repair or replace	1-S34
	Compression leak from cylinder	Replace head gasket, tighten cylinder head screw, glow plug and nozzle holder	1-S26, S27
	Improper valve timing	Correct or replace timing gear	1-S33
	Piston ring and cylinder worn	Replace	1-S35 to S36
	Excessive valve clearance	Adjust	1-S13
Starter Does Not Run	Battery discharged	Charge	G-18
	Starter malfunctioning	Repair or replace	6-S35
	Main switch malfunctioning	Repair or replace	6-S10
	Safety switches malfunctioning	Adjust or replace	6-S12 to S16
	Wiring disconnected	Connect	–
Engine Revolution Is Not Smooth	Fuel filter clogged or dirty	Replace	G-27
	Air cleaner clogged	Clean or replace	G-19
	Fuel leak due to loose injection pipe retaining nut	Tighten retaining nut	1-S25
	Injection pump malfunctioning	Replace	1-S31
	Incorrect nozzle injection pressure	Adjust	1-S20
	Injection nozzle stuck or clogged	Repair or replace	1-S25
	Governor malfunctioning	Repair	1-S34

W1014322

Symptom	Probable Cause	Solution	Reference Page
Either White or Blue Exhaust Gas Is Observed	Excessive engine oil	Reduce to specified level	G-12
	Piston ring and cylinder worn or stuck	Repair or replace	1-S36
	Incorrect injection timing	Adjust	1-S17
	Deficient compression	Check	1-S11, S12
Either Black or Dark Gray Exhaust Gas Is Observed	Overload	Reduce the load	–
	Low grade fuel used	Use specified fuel	G-7
	Fuel filter clogged	Replace	G-27
	Air cleaner clogged	Clean or replace	G-19
	Deficient nozzle injection	Repair or replace nozzle	1-S25
Deficient Output	Incorrect injection timing	Adjust	1-S17
	Engine's moving parts seem to be seizing	Repair or replace	–
	Uneven fuel injection	Replace injection pump	1-S31
	Deficient nozzle injection	Repair or replace nozzle	1-S25
	Compression leak	Replace head gasket, tighten cylinder head screws, glow plug and nozzle holder	1-S26, S27
Excessive Lubricant Oil Consumption	Piston ring's gap facing the same direction	Shift ring gap direction	1-S36
	Oil ring worn or stuck	Replace	1-S36
	Piston ring groove worn	Replace piston	1-S36
	Valve stem and valve guide worn	Replace	1-S43
	Oil leaking due to defective seals or packing	Replace	–
Fuel Mixed into Lubricant Oil	Injection pump's plunger worn	Repair or replace	1-S31
	Deficient nozzle injection	Repair or replace nozzle	1-S25
	Injection pump broken	Replace	1-S31
Water Mixed into Lubricant Oil	Head gasket defective	Replace	1-S27
	Cylinder block or cylinder head flawed	Replace	1-S27

W1014322

Symptom	Probable Cause	Solution	Reference Page
Low Oil Pressure	Engine oil insufficient	Replenish	G-7
	Oil strainer clogged	Clean	1-S29
	Oil filter clogged	Replace	G-12
	Relief valve stuck with dirt	Clean	1-S14
	Relief valve spring weaken or broken	Replace	1-S14
	Excessive oil clearance of crankshaft bearing	Replace	1-S52 to S55
	Excessive oil clearance of crankpin bearing	Replace	1-S54
	Excessive oil clearance of rocker arm	Replace	1-S26
	Oil passage clogged	Clean	–
	Different type of oil	Use specified type of oil	G-7
	Oil pump defective	Repair or replace	1-S34
High Oil Pressure	Different type of oil	Use specified type of oil	G-7
	Relief valve defective	Replace	1-S14
Engine Overheated	Engine oil insufficient	Replenish	1-S22
	Fan belt broken or tensioned improperly	Replace or adjust	G-21
	Coolant insufficient	Replenish	G-7
	Radiator net and radiator fin clogged with dust	Clean	–
	Inside of radiator corroded	Clean or replace	–
	Coolant flow route corroded	Clean or replace	G-24
	Radiator cap defective	Replace	1-S16
	Radiator hose damaged	Replace	G-23
	Overload running	Reduce the load	–
	Head gasket defective	Replace	1-S27
	Incorrect injection timing	Adjust	1-S17
	Unsuitable fuel used	Use specified fuel	G-7

W1014322

2. SERVICING SPECIFICATIONS

ENGINE BODY

Item		Factory Specification	Allowable Limit
Valve Clearance (Cold)		0.145 to 0.185 mm 0.00571 to 0.00728 in.	—
Compression Pressure		3.53 to 4.02 MPa 36.0 to 41.0 kgf/cm ² 512 to 583 psi	2.55 MPa 26.0 kgf/cm ² 370 psi
Difference among Cylinders		—	10 % or less
Top Clearance		0.50 to 0.70 mm 0.0197 to 0.0276 in.	—
Cylinder Head Surface	Flatness	—	0.05 mm 0.0020 in.
Valve Recessing	Intake and Exhaust	−0.10 to 0.10 mm −0.0039 to 0.0039 in.	0.30 mm 0.0118 in.
Valve Stem to Valve Guide	Clearance	0.030 to 0.057 mm 0.00118 to 0.00224 in.	0.10 mm 0.0039 in.
Valve Stem	O.D.	5.968 to 5.980 mm 0.23496 to 0.23543 in.	—
Valve Guide	I.D.	6.010 to 6.025 mm 0.23661 to 0.23720 in.	—
Valve Face	Angle	0.785 rad 45 °	—
Valve Seat	Angle	0.785 rad 45 °	—
	Width	2.12 mm 0.0835 in.	—
Valve Spring	Free Length	31.3 to 31.8 mm 1.232 to 1.252 in.	28.4 mm 1.118 in.
	Tilt	—	1.2 mm 0.047 in.
	Setting Load	64.7 N / 27.0 mm 6.6 kgf / 27.0 mm 14.6 lbf / 1.063 in.	54.9 N / 27.0 mm 5.6 kgf / 27.0 mm 12.3 lbf / 1.063 in.

W10138740

ENGINE BODY (Continued)

Item		Factory Specification	Allowable Limit
Rocker Arm Shaft to Rocker Arm	Clearance	0.016 to 0.045 mm 0.00063 to 0.00177 in.	0.15 mm 0.0059 in.
Rocker Arm Shaft	O.D.	10.473 to 10.484 mm 0.41232 to 0.41276 in.	—
Rocker Arm	I.D.	10.500 to 10.518 mm 0.41339 to 0.41410 in.	—
Push Rod	Alignment	—	0.25 mm 0.0098 in.
Tappet to Tappet Guide	Oil Clearance	0.016 to 0.052 mm 0.00063 to 0.00205 in.	0.10 mm 0.0039 in.
Tappet	O.D.	17.966 to 17.984 mm 0.70732 to 0.70803 in.	—
Tappet Guide	I.D.	18.000 to 18.018 mm 0.70866 to 0.70937 in.	—
Timing Gear			
Crank Gear to Idle Gear	Backlash	0.043 to 0.124 mm 0.00169 to 0.00488 in.	0.15 mm 0.0059 in.
Idle Gear to Cam Gear	Backlash	0.047 to 0.123 mm 0.00185 to 0.00484 in.	0.15 mm 0.0059 in.
Idle Gear to Injection Pump Gear	Backlash	0.046 to 0.124 mm 0.00181 to 0.00488 in.	0.15 mm 0.0059 in.
Crank Gear to Oil Pump Drive Gear	Backlash	0.041 to 0.123 mm 0.00161 to 0.00484 in.	0.15 mm 0.0059 in.
Idle Gear	Side Clearance	0.20 to 0.51 mm 0.0079 to 0.0201 in.	0.80 mm 0.0315 in.
Camshaft	Side Clearance	0.15 to 0.31 mm 0.0059 to 0.0122 in.	0.50 mm 0.0197 in.
	Alignment	—	0.01 mm 0.0004 in.
Cam Height	Intake and Exhaust	26.88 mm 1.0583 in.	26.83 mm 1.0563 in.
Camshaft Journal to Cylinder Block Bore	Oil Clearance	0.050 to 0.091 mm 0.00197 to 0.00358 in.	0.15 mm 0.0059 in.
Camshaft Journal	O.D.	32.934 to 32.950 mm 1.29661 to 1.29724 in.	—
Cylinder Block Bore	I.D.	33.000 to 33.025 mm 1.29921 to 1.30020 in.	—

W1013874

ENGINE BODY (Continued)

Item		Factory Specification	Allowable Limit
Idle Gear Shaft to Idle Gear Bushing	Oil Clearance	0.020 to 0.084 mm 0.00079 to 0.00331 in.	0.10 mm 0.0039 in.
Idle Gear Shaft	O.D.	19.967 to 19.980 mm 0.78610 to 0.78661 in.	—
Idle Gear Bushing	I.D.	20.000 to 20.051 mm 0.78740 to 0.78941 in.	—
Piston Pin Bore	I.D.	20.000 to 20.013 mm 0.78740 to 0.78791 in.	20.05 mm 0.7894 in.
Piston Pin to Small End Bushing	Clearance	0.014 to 0.038 mm 0.00055 to 0.00150 in.	0.10 mm 0.0039 in.
Piston Pin	O.D.	20.002 to 20.011 mm 0.78748 to 0.78783 in.	—
Small End Bushing	I.D.	20.025 to 20.040 mm 0.78839 to 0.78897 in.	—
Piston Pin to Small End Bushing (Spare Parts)	Oil Clearance	0.015 to 0.075 mm 0.00059 to 0.00295 in.	0.15 mm 0.0059 in.
Small End Bushing	I.D.	20.026 to 20.077 mm 0.78843 to 0.79043 in.	—
Connecting Rod	Alignment	—	0.05 mm 0.0020 in.
Piston Ring Gap [D902-E2-BX-2, D902-E3-BX-2]	Top Ring	0.20 to 0.35 mm 0.0079 to 0.0138 in.	1.25 mm 0.0492 in.
	Second Ring	0.35 to 0.50 mm 0.0138 to 0.0197 in.	1.25 mm 0.0492 in.
	Oil Ring	0.20 to 0.35 mm 0.0079 to 0.0138 in.	1.25 mm 0.0492 in.
Piston Ring to Piston Ring Groove Second Ring	Clearance	0.090 to 0.120 mm 0.00354 to 0.00472 in.	0.15 mm 0.0059 in.
Oil Ring	Clearance	0.04 to 0.08 mm 0.0016 to 0.0031 in.	0.15 mm 0.0059 in.
Crankshaft	Side Clearance	0.15 to 0.31 mm 0.0059 to 0.0122 in.	0.50 mm 0.0197 in.
Crankshaft	Alignment	—	0.02 mm 0.0008 in.

W10138740

ENGINE BODY (Continued)

Item		Factory Specification	Allowable Limit
Crankpin to Crankpin Bearing	Oil Clearance	0.020 to 0.051 mm 0.00079 to 0.00201 in.	0.15 mm 0.0059 in.
Crankpin	O.D.	33.959 to 33.975 mm 1.33697 to 1.33760 in.	—
Crankpin Bearing	I.D.	33.995 to 34.010 mm 1.33839 to 1.33898 in.	—
Crankshaft Journal to Crankshaft Bearing 1 [D902-E2-BX-2, D902-E3-BX-2]	Oil Clearance	0.034 to 0.106 mm 0.00134 to 0.00417 in.	0.20 mm 0.0079 in.
Crankshaft Journal	O.D.	43.934 to 43.950 mm 1.72968 to 1.73031 in.	—
Crankshaft Bearing 1	I.D.	43.984 to 44.040 mm 1.73165 to 1.73386 in.	—
Crankshaft Bearing Dimension	Clearance	0.0 to 0.3 mm 0.0 to 0.0118 in.	—
Crankshaft Journal to Crankshaft Bearing 2 (Flywheel Side)	Oil Clearance	0.028 to 0.059 mm 0.00110 to 0.00232 in.	0.20 mm 0.0079 in.
Crankshaft Journal	O.D.	43.934 to 43.950 mm 1.72968 to 1.73031 in.	—
Crankshaft Bearing 2	I.D.	43.978 to 43.993 mm 1.73142 to 1.73201 in.	—
Crankshaft Journal to Crankshaft Bearing 3 (Intermediate) [D902-E2-BX-2, D902-E3-BX-2]	Oil Clearance	0.028 to 0.059 mm 0.00110 to 0.00232 in.	0.20 mm 0.0079 in.
Crankshaft Journal	O.D.	43.934 to 43.950 mm 1.72968 to 1.73031 in.	—
Crankshaft Bearing 3	I.D.	43.978 to 43.993 mm 1.73142 to 1.73201 in.	—
Cylinder Liner [D902-E2-BX-2, D902-E3-BX-2]	I.D.	72.000 to 72.019 mm 2.83464 to 2.83539 in.	72.150 mm 2.84055 in.
Cylinder Liner [Oversize : 0.25 mm (0.0098 in.)] [D902-E2-BX-2, D902-E3-BX-2]	I.D.	72.250 to 72.269 mm 2.84449 to 2.84524 in.	72.400 mm 2.85040 in.

W10138740

LUBRICATING SYSTEM

Item		Factory Specification	Allowable Limit
Engine Oil Pressure	At Idle Speed	More than 49 kPa 0.5 kgf/cm ² 7 psi	—
	At Rated Speed	196 to 441 kPa 2.0 to 4.5 kgf/cm ² 28 to 64 psi	147 kPa 1.5 kgf/cm ² 21 psi
Relief Valve Spring	Free Length	32 mm 1.26 in.	28 mm 1.10 in.
Inner Rotor to Outer Rotor	Clearance	0.03 to 0.14 mm 0.0012 to 0.0055 in.	—
Outer Rotor to Pump Body	Clearance	0.07 to 0.15 mm 0.0028 to 0.0059 in.	—
Inner Rotor to Cover	Clearance	0.075 to 0.135 mm 0.00295 to 0.00531 in.	—

W10139730

COOLING SYSTEM

Item		Factory Specification	Allowable Limit
Fan Belt	Tension	7.0 to 9.0 mm / 98 N 0.28 to 0.35 in. / 98 N (10 kgf, 22 lbf)	—
Radiator Cap	Pressure Falling Time	10 seconds or more 88 → 59 kPa 0.9 → 0.6 kgf/cm ² 13 → 9 psi	—
Radiator	Water Leakage Test Pressure	No leak at specified pressure 157 kPa 1.6 kgf/cm ² 23 psi	—
Thermostat	Valve Opening Temperature (At Beginning)	69.5 to 72.5 °C 157.1 to 162.5 °F	—
	Valve Opening Temperature (Opened Completely)	85 °C 185 °F	—

W10135990

FUEL SYSTEM

Item		Factory Specification	Allowable Limit
Injection Pump [D902-E2-BX-2]	Injection Timing	—	0.30 to 0.33 rad (17 to 19 °) before T.D.C.
Injection Pump [D902-E3-BX-2]	Injection Timing	—	0.30 to 0.32 rad (17.25 to 18.75 °) before T.D.C.
Pump Element	Fuel Tightness	—	13.7 MPa 140 kgf/cm ² 1991 psi
Delivery Valve	Fuel Tightness	10 seconds 13.7 → 12.8 MPa 140 → 130 kgf/cm ² 1991 → 1849 psi	5 seconds 13.7 → 12.8 MPa 140 → 130 kgf/cm ² 1991 → 1849 psi
Injection Nozzle	Injection Pressure	13.7 to 14.7 MPa 140 to 150 kgf/cm ² 1991 to 2134 psi	—
Injection Nozzle Valve Seat	Valve Seat Tightness	When the pressure is 12.8 MPa (130 kgf/cm ² , 1849 psi), the valve seat must be fuel tightness.	—

W10139730

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(Tractor section for general use screws, bolts and nuts : See page G-8.)

Tractor Section

Item	N·m	kgf·m	lbf·ft
Front coupling mounting bolt	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2
Engine mounting nut	3.6 to 27.4	2.4 to 2.8	17.4 to 20.2
Cushion mounting nut	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2

W1012736

Engine Section

Item	Size x Pitch	N·m	kgf·m	lbf·ft
*Cylinder head screw	M8 x 1.25	37.3 to 42.2	3.8 to 4.3	27.5 to 31.1
Oil pressure switch	PT 1/8	14.7 to 19.6	1.5 to 2.0	10.8 to 14.5
Engine oil filter joint	—	39.2 to 49.0	4.0 to 5.0	29.0 to 36.3
Nozzle holder	—	34.3 to 39.2	3.5 to 4.0	25.3 to 28.9
Overflow pipe retaining nut	M12 x 1.5	19.6 to 24.5	2.0 to 2.5	14.5 to 18.1
Nozzle holder assembly	M20 x 1.5	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
*Cylinder head cover screw	M6 x 1	6.86 to 11.3	0.7 to 1.15	5.1 to 8.3
Injection pipe retaining nut	M12 x 1.5	24.5 to 34.3	2.5 to 3.5	18.1 to 25.3
Glow plug	M8 x 1	7.8 to 14.7	0.8 to 1.5	5.8 to 10.8
*Rocker arm bracket nut	M6 x 1	9.8 to 11.3	1.00 to 1.15	7.2 to 8.3
*Fan drive pulley screw	M12 x 1.5	117.7 to 127.5	12.0 to 13.0	86.8 to 94.0
*Idle gear shaft mounting screw	M6 x 1	9.8 to 11.3	1.00 to 1.15	7.2 to 8.3
*Connecting rod screw	M7 x 0.75	26.5 to 30.4	2.7 to 3.1	19.5 to 22.4
*Flywheel screw	M10 x 1.25	53.9 to 58.8	5.5 to 6.0	39.8 to 43.4
Bearing case cover mounting screw	M6 x 1	9.8 to 11.3	1.00 to 1.15	7.2 to 8.3
*Main bearing case screw 2	M7 x 1	26.5 to 30.4	2.7 to 3.1	19.5 to 22.4
*Main bearing case screw 1	M6 x 1	12.7 to 15.7	1.3 to 1.6	9.4 to 11.6

NOTE

- In removing and applying the bolts and nuts marked with “*”, a pneumatic wrench or similar pneumatic tool, if employed, must be used with enough care not to get them seized.
- For * marked screws, bolts and nuts on the table, apply engine oil to their threads and seats before tightening.
- The letter “M” in Size × Pitch means that the screw, bolt or nut dimension stands for metric. The size is the nominal outside diameter in mm of the threads. The pitch is the nominal distance in mm between two threads.

W1013236

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING

(1) Engine Body



Compression Pressure (by Glow Plug Hole Adaptor Setting)



1. Run the engine until it is warmed up.
2. Stop the engine.
3. Remove the air cleaner, the muffler, the breather tube, the head cover and all glow plugs.
4. Set a compression tester (Code No. 07909-30208) with the adaptor (Adaptor L, code No. 07909-31301) to the glow plug hole.
5. After making sure that the stop lever is set at the stop position (non-injection), run the engine with the starter and measure the compression pressure.
6. Repeat steps 4 and 5 for each cylinder.
7. If the measurement is below the allowable limit, apply a small amount of oil to the cylinder wall through the glow plug hole (or nozzle hole) and measure the compression pressure again.
8. If the compression pressure is still less than the allowable limit, check the top clearance, valve clearance and cylinder head.
9. If the compression pressure increases after applying oil, check the cylinder wall and piston rings.

■ NOTE

- Check the compression pressure with the specified valve clearance.
- Always use a fully charged battery for performing this test.
- Variances in cylinder compression values should be under 10 %.

Compression pressure	Factory specification	3.53 to 4.02 MPa 36 to 41 kgf/cm ² 512 to 583 psi
	Allowable limit	2.55 MPa 26 kgf/cm ² 370 psi

W10178940



Top Clearance

1. Remove the cylinder head. (Do not attempt to remove the cylinder head gasket.)
2. Move the piston up and stick a strip of fuse [1.5 mm dia. (0.059 in. dia.), 5 to 7 mm long (0.197 to 0.276 in. long)] on the piston head at three positions with grease so as to avoid the intake and exhaust valves and the combustion chamber ports.
3. Lower the piston, and install the cylinder head and tighten the cylinder head screws to the specified torque.
4. Turn the flywheel until the piston exceeds top dead center.
5. Remove the cylinder head, and measure the thickness of the squeezed fuses.
6. If the measurement is not within the factory specifications, check the oil clearance between the crankpin and crankpin bearing and between the piston pin and small end bushing.




■ **NOTE**

- **After checking the top clearance, be sure to assemble the cylinder head with a new cylinder head gasket.**

Top clearance	Factory specification	0.50 to 0.70 mm 0.0197 to 0.0276 in.
Tightening torque	Cylinder head screws	37.3 to 42.2 N·m 3.8 to 4.3 kgf·m 27.5 to 31.1 lbf·ft

(1) Fuse

W1020190



Checking Valve Clearance

■ IMPORTANT

- Valve clearance must be checked and adjusted when engine is cold.

- Remove the cylinder head cover and the glow plugs.
- Align the "1TC" mark (1) on the flywheel and alignment mark (2) on the rear end plate so that the No. 1 piston comes to the compression top dead center.
- Check the following valve clearance marked with "★" using a feeler gauge.
- If the clearance is not within the factory specifications, adjust with the adjusting screw.
- Then turn the flywheel 6.28 rad (360 °), and align the "1TC" mark (1) on the flywheel and alignment mark (3) on the rear end plate so that the No. 1 piston comes to the overlap position.
- Check the following valve clearance marked with "☆" using a feeler gauge.
- If the clearance is not within the factory specifications, adjust with the adjusting screw.

Number of cylinders Valve arrangement Adjustable cylinder location of piston	Intake valve	Exhaust valve
No. 1	★	★
No. 2	☆	★
No. 3	★	☆

★ : When No. 1 piston is at the compression top dead center position, valve clearance is adjustable.

☆ : When No. 1 piston is at the overlap position, valve clearance is adjustable.

Intake and exhaust valve clearance (cold)	Factory specification	0.145 to 0.185 mm 0.00571 to 0.00728 in.
---	-----------------------	---

■ NOTE


- The sequence of cylinder numbers is given as No. 1, No. 2 and No. 3 starting from the gear case side.
- After adjusting the valve clearance, secure the adjusting screw with the lock nut.

- (1) "1TC" Mark
(2) Alignment Mark

A : Gear Case Side

W10172470

(2) Lubricating System



Engine Oil Pressure

1. Remove the engine oil pressure switch, and set an oil pressure tester. (Code No. : 07916-32032.)
2. Start the engine. After warming up, measure the oil pressure of both idling and rated speeds.
3. If the oil pressure is less than the allowable limit, check the following.
 - Engine oil insufficient
 - Oil pump defective
 - Oil strainer clogged
 - Oil filter cartridge clogged
 - Oil gallery clogged
 - Excessive oil clearance
 - Foreign matter in the relief valve



Engine oil pressure	At idle speed	Factory specification	More than 49 kPa 0.5 kgf/cm ² 7 psi
	At rated speed	Factory specification	196 to 441 kPa 2.0 to 4.5 kgf/cm ² 28 to 64 psi
		Allowable limit	147 kPa 1.5 kgf/cm ² 21 psi

(When reassembling)

- After checking the engine oil pressure, tighten the engine oil pressure switch to the specified torque.

Tightening torque	Oil pressure switch	14.7 to 19.6 N·m 1.5 to 2.0 kgf·m 10.8 to 14.5 lbf·ft
-------------------	---------------------	---

W10349520



Relief Valve

1. Remove the oil filter base
2. Check the relief valve for dirt, and the seat and ball for damage.
3. If damaged, replace.
4. Check the free length of spring.
5. If less than the allowable limit, replace.

Relief valve spring	Factory specification	32 mm 1.26 in.
	Allowable limit	28 mm 1.10 in.


Tightening torque	Joint	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 29.0 to 36.3 lbf·ft
-------------------	-------	---

(1) Relief Valve
(2) Joint

(3) Spring

W10756890

(3) Cooling System




Fan Belt Tension

1. Measure the deflection **(A)**, depressing the belt halfway between the fan drive pulley and alternator pulley at specified force 98 N (10 kgf, 22 lbf).
2. If the measurement is not within the factory specifications, loosen the alternator mounting screws and relocate the alternator to adjust.

Deflection (A)	Factory specification	7.0 to 9.0 mm 0.28 to 0.35 in.
-----------------------	-----------------------	-----------------------------------

(A) Deflection

W10356670




Fan Belt Damage and Wear

1. Check the fan belt for damage.
2. If the fan belt is damaged, replace it.
3. Check if the fan belt is worn and sunk in the pulley groove.
4. If the fan belt is nearly worn out and deeply sunk in the pulley groove, replace it.

(A) Good


(B) Bad

W1016443



CAUTION

- When removing the radiator cap, wait at least ten minutes after the engine has stopped and cooled down. Otherwise, hot water may gush out, scalding nearby people.



Radiator Cap Air Leakage


- Set a radiator tester (1) and an adaptor (2) on the radiator cap.
- Apply the specified pressure (88 kPa, 0.9 kgf/cm², 13 psi), and measure the time for the pressure to fall to 59 kPa (0.6 kgf/cm², 9 psi).
- If the measurement is less than the factory specification, replace the radiator cap.

Pressure falling time	Factory specification	More than 10 seconds for pressure fall from 88 to 59 kPa (from 0.9 to 0.6 kgf/cm ² , from 13 to 9 psi)
-----------------------	-----------------------	---

(1) Radiator Tester

(2) Adaptor

W1054156



Radiator Water Leakage


- Pour a specified amount of water into the radiator.
- Set a radiator tester (1) and an adapter (2) and raise the water pressure to the specified pressure.
- Check the radiator for water leaks.
- For water leak from the pinhole, repair with the radiator cement. When water leak is excessive, replace the radiator.

Radiator water leakage test pressure	Factory specification	157 kPa 1.6 kgf/cm ² 23 psi
--------------------------------------	-----------------------	--

(1) Adaptor

(2) Radiator Tester

W1016903






Thermostat Valve Opening Temperature

- Suspend the thermostat in the water by a string with its end inserted between the valve and seat.
- Heating the water gradually, read the temperature when the valve opens and leaves the string.
- Continue heating and read the temperature when the valve opens approx. 8 mm (0.315 in.).
- If the measurement is not within the factory specifications, replace the thermostat.

Thermostat's valve opening temperature	Factory specification	69.5 to 72.5 °C 157.1 to 162.5 °F
Temperature at which thermostat completely opens	Factory specification	85 °C 185 °F

W1035849

(4) Fuel System



Injection Timing (To be continued)

1. Remove the injection pipes.
2. Remove the engine stop solenoid.
3. Turn the flywheel counterclockwise (viewed from flywheel side) until the fuel fills up to the hole of the delivery valve holder (3) for the No. 1 cylinder.
4. After the fuel fills up to the hole of the delivery valve holder for the No. 1 cylinder, turn back (clockwise) the flywheel around 1.57 rad (90 °).
5. Turn the flywheel counterclockwise to set at around 0.44 rad (25 °) before T.D.C..
6. Slowly turn the flywheel counterclockwise and stop turning when the fuel begins to come up, to get the present injection timing.
7. Check to see the degree on flywheel.
The flywheel has mark "1TC", "10" and "20" for the crank shaft angle before the top dead center of the No. 1 piston.
8. Check to see if the injection timing angle on the flywheel is aligned with the alignment mark (2).
9. If injection timing is out of adjustment, readjust the injection timing with shims.

[D902-E2-BX-2]

Injection timing	Factory specification	0.30 to 0.33 rad (17 to 19 °) before T.D.C.
------------------	-----------------------	--

[D902-E3-BX-2]

Injection timing	Factory specification	0.30 to 0.32 rad (17.25 to 18.75 °) before T.D.C.
------------------	-----------------------	--


- | | |
|--------------------------------------|---|
| (1) Injection Timing Line | (6) One-hole : 0.25 mm (0.0098 in.) |
| (2) Alignment Mark | (7) Without hole : 0.30 mm (0.0118 in.) |
| (3) Delivery Valve Holder | (8) "1TC" Mark |
| (4) Shim (Soft Metal Gasket Shim) | |
| (5) Two-holes : 0.20 mm (0.0079 in.) | a : Flywheel Rotation |

W1018724

Injection Timing (Continued)**■ NOTE**

- The sealant is applied to both sides of the shims (soft metal gasket shim). The liquid gasket is not required for assembling.
- Shims are available in thickness of 0.20 mm (0.0079 in.), 0.25 mm (0.0098 in.) and 0.30 mm (0.0118 in.). Combine these shims for adjustments.
- Addition or reduction of shim (0.05 mm, 0.0020 in.) delays or advances the injection timing by approx. 0.0087 rad (0.5 °).
- In disassembling and replacing the injection pump, be sure to use the same number of new shims with the same thickness.
- Refer to figure of the shim to check the thickness of the shims.

W1018986



Fuel Tightness of Pump Element

1. Remove the engine stop solenoid.
2. Remove the injection pipes and glow plugs.
3. Install the injection pump pressure tester to the injection pump.
4. Install the injection nozzle (1) jetted with the proper injection pressure to the injection pump pressure tester (2). (Refer to the photo.)
5. Set the speed control lever to the maximum speed position.
6. Run the starter to increase the pressure.
7. If the pressure can not reach the allowable limit, replace the pump with new one or repair with a KUBOTA-authorized pump service shop.

Fuel tightness of pump element	Allowable limit	13.7 MPa 140 kgf/cm ² 1991 psi
--------------------------------	-----------------	---

NOTE


- **Never try to disassemble the injection pump assembly. For repairs, you are strongly requested to contact a KUBOTA-authorized pump service shop.**

(1) Injection Nozzle

(3) Protection Cover for Jetted Fuel

(2) Injection Pump Pressure Tester

W1017430



Fuel Tightness of Delivery Valve

1. Remove the engine stop solenoid.
2. Remove the injection pipes and glow plugs.
3. Set a pressure tester to the fuel injection pump.
4. Install the injection nozzle (1) jetted with the proper injection pressure to the injection pump pressure tester (2).
5. Run the starter to increase the pressure.
6. Stop the starter when the fuel jets from the injection nozzle. After that, turn the flywheel by hands and raise the pressure to approx. 13.7 MPa (140 kgf/cm², 1991 psi).
7. Now turn the flywheel back about half a turn (to keep the plunger free). Maintain the flywheel at this position and clock the time taken for the pressure to drop from 13.7 to 12.8 MPa (from 140 to 130 kgf/cm², from 1991 to 1849 psi).
8. Measure the time needed to decrease the pressure from 13.7 to 12.8 MPa (140 to 130 kgf/cm², 1991 to 1849 psi).
9. If the measurement is less than allowable limit, replace the pump with new one or repair with a KUBOTA-authorized pump service shop.

Fuel tightness of delivery valve	Factory specification	10 seconds 13.7 → 12.8 MPa 140 → 130 kgf/cm ² 1991 → 1849 psi
	Allowable limit	5 seconds 13.7 → 12.8 MPa 140 → 130 kgf/cm ² 1991 → 1849 psi

NOTE

- **Never try to disassemble the injection pump assembly. For repairs, you are strongly requested to contact a KUBOTA-authorized pump service shop.**

(1) Injection Nozzle


(3) Protection Cover for Jetted Fuel

(2) Injection Pump Pressure Tester

W1017786

CAUTION

- Check the nozzle injection pressure and condition after confirming that there is nobody standing in the direction the fume goes.
- If the fume from the nozzle directly contacts the human body, cells may be destroyed and blood poisoning may be caused.




Nozzle Spraying Condition

1. Set the injection nozzle to a nozzle tester, and check the nozzle spraying condition.
2. If the spraying condition is defective, replace the nozzle piece.

(a) Good

(b) Bad

W10181310



Fuel Injection Pressure

1. Set the injection nozzle to a nozzle tester.
2. Slowly move the tester handle to measure the pressure at which fuel begins jetting out from the nozzle.
3. If the measurement is not within the factory specifications, replace the adjusting washer (1) in the nozzle holder to adjust it.


(Reference)

- Pressure variation with 0.025 mm (0.0010 in.) difference of adjusting washer thickness.
Approx. 588 kPa (6.0 kgf/cm², 85 psi)

Fuel injection pressure	Factory specification	13.7 to 14.7 MPa 140 to 150 kgf/cm ² 1991 to 2134 psi
-------------------------	-----------------------	--

(1) Adjusting Washer

W10182100





Valve Seat Tightness

1. Set the injection nozzle to a nozzle tester.
2. Raise the fuel pressure, and keep at 12.8 MPa (130 kgf/cm², 1849 psi) for 10 seconds.
3. If any fuel leak is found, replace the nozzle piece.

Valve seat tightness	Factory specification	No fuel leak at 12.8 MPa 130 kgf/cm ² 1849 psi
----------------------	-----------------------	--

W10183690





Nozzle Holder

1. Secure the nozzle retaining nut (7) with a vise.
2. Remove the nozzle holder (1), and take out parts inside.

(When reassembling)

- Assemble the nozzle in clean fuel oil.
- Install the push rod (4), noting its direction.
- After assembling the nozzle, be sure to adjust the fuel injection pressure.

Tightening torque	Nozzle holder	34.3 to 39.2 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 lbf·ft
	Overflow pipe retaining nut	19.6 to 24.5 N·m 2.0 to 2.5 kgf·m 14.5 to 18.1 lbf·ft
	Nozzle holder assembly	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 lbf·ft





- (1) Nozzle Holder
(2) Adjusting Washer
(3) Nozzle Spring
(4) Push Rod

- (5) Distance Piece
(6) Nozzle Piece
(7) Nozzle Retaining Nut

W1018491

[2] DISASSEMBLING AND ASSEMBLING

(1) Separating Engine



Draining Engine Oil

1. Start and warm up the engine for approx. 5 minutes.
2. Place an oil pan underneath the engine.
3. Remove the drain plug (1) to drain oil.
4. After draining, screw in the drain plug (1).

(When refilling)

- Fill the engine oil up to the upper line on the dipstick (3).

■ IMPORTANT

- **Never mix two different type of oil.**
- **Use the proper SAE Engine Oil according to ambient temperature.**

Refer to “LUBRICANTS, FUEL AND COOLANT” (See page G-7.).

Engine oil	Capacity	3.1 L 3.3 U.S.qts 2.7 Imp.qts
------------	----------	-------------------------------------

- (1) Drain Plug
(2) Oil Inlet
(3) Dipstick

(A) Oil level is acceptable within this range

W1023464

Battery Cables and Battery

⚠ CAUTION


- **When disconnecting the battery cables, disconnect the negative cable from the battery first. When connecting, connect the positive cable to the battery first.**

1. Remove the under panel and the battery cover.
2. Disconnect the negative cable (2) from the battery (1).
3. Disconnect the positive cable (3) from the battery (1) and remove the battery (1).

- (1) Battery
(2) Negative cable

(3) Positive Cable

W1045893





Bonnet and Under Cover

1. Open the bonnet (1), and then loosen the bolts and pull forward to remove the under cover (2).
2. Disconnect the connectors (3) for head light and remove the bonnet bracket (4) with bonnet.

(1) Bonnet
(2) Under Cover

(3) Connector
(4) Bonnet Bracket

W1064425




Accelerator Wire, Bonnet Post, Fuel Hoses, Wiring Harness and Others


1. Disconnect the wiring harness (3) from coolant temperature switch, stop solenoid, glow plug, starter motor, engine oil switch, alternator and ground cable.
2. Disconnect the accelerator wire (2).
3. Remove the bonnet post (1).

(1) Bonnet Post
(2) Accelerator Wire

(3) Wiring Harness

W1023496





Engine Assembly

1. Disconnect the ground cable.
2. Disconnect the front coupling (1).
3. Remove the engine mounting nuts (3).
4. Hook the engine and separate the engine assembly with the radiator from the frame.

(When reassembling)



Tightening torque	Front coupling mounting bolt	23.6 to 27.4 N·m 2.4 to 2.8 kgf·m 17.4 to 20.2 lbf·ft
	Engine mounting nut	23.6 to 27.4 N·m 2.4 to 2.8 kgf·m 17.4 to 20.2 lbf·ft
	Cushion mounting nut	23.6 to 27.4 N·m 2.4 to 2.8 kgf·m 17.4 to 20.2 lbf·ft

- (1) Front Coupling
(2) Front Coupling Mounting Bolt

- (3) Engine Mounting Nut

W1049824

(2) Removing Outer Parts



Draining Coolant and Removing Engine Outer Parts



CAUTION

- **Never open the radiator cap while operating or immediately after stopping. Otherwise, hot water will spout out from the radiator. Wait for more than ten minutes to cool the radiator, before opening the cap**

1. Set the engine stands (9) to the crankcase.
2. Open the radiator drain plug, and remove radiator cap to completely drain the coolant.
3. After all coolant is drained, close the drain plug.
4. Loosen the inlet hose band and the radiator hose bands, and remove the radiator (1) with the radiator hoses (2) and the air cleaner (3).
5. Loosen the fan belt. Remove the alternator (6), the starter motor (8), the fan and the fan belt.
6. Remove the heat proof cover (7), the muffler (5) and the exhaust muffler


Coolant	Capacity	Radiator	2.7 L 2.85 U.S.qts 2.38 Imp.qts
		Radiator tank	0.4 L 0.42 U.S.qts 0.35 Imp.qts

- (1) Radiator
(2) Radiator Hose
(3) Air Cleaner
(4) Inlet Hose
(5) Muffler

- (6) Alternator
(7) Heat Proof Cover
(8) Starter Motor
(9) Engine Stand

W1051348

(3) Cylinder Head and Valves



Cylinder Head Cover

1. Disconnect the breather hose (1).
2. Remove the cylinder head cover screws (2).
3. Remove the cylinder head cover (3).

(When reassembling)

- Check to see if the cylinder head cover gasket is not defective.


Tightening torque	Cylinder head cover screw	6.86 to 11.3 N·m 0.7 to 1.15 kgf·m 5.1 to 8.3 lbf·ft
-------------------	---------------------------	--

(1) Breather Hose

(3) Cylinder Head Cover

(2) Cylinder Head Cover Screws

W1028468



Injection Pipes

1. Loosen the screws to the pipe clamp (1).
2. Detach the injection pipes (2).

(When reassembling)


- Send compressed air into the pipes to blow out dust. Then, reassemble the pipes in the reverse order.

Tightening torque	Injection pipe retaining nut	24.5 to 34.3 N·m 2.5 to 3.5 kgf·m 18.1 to 25.3 lbf·ft
-------------------	------------------------------	---

(1) Pipe Clamp

(2) Injection Pipe

W1028640



Nozzle Holder Assembly and Glow Plug

1. Remove the overflow pipe (1).
2. Remove the nozzle holder assemblies (2).
3. Remove the copper gasket (5) and the heat seal (6).
4. Remove the lead (3) from the glow plugs (4).
5. Remove the glow plugs (4).

(When reassembling)

- Replace the copper gasket and the heat seal with new one.

Tightening torque	Overflow pipe retaining nut	19.6 to 24.5 N·m 2.0 to 2.5 kgf·m 14.5 to 18.1 lbf·ft
	Nozzle holder assembly	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 lbf·ft
	Glow plug	7.8 to 14.7 N·m 0.8 to 1.5 kgf·m 5.8 to 10.8 lbf·ft

(1) Overflow Pipe

(4) Glow Plug


(2) Nozzle Holder Assembly


(5) Copper Gasket

(3) Lead

(6) Heat Seal

W1024604





Nozzle Heat Seal Removal Procedure

■ IMPORTANT

- Use a plus (phillips head) screw driver (1) that has a diameter which is bigger than the heat seal hole (Approx. 6 mm (1/4 in.)).

1. Drive screw driver (1) lightly into the heat seal hole.
2. Turn screw driver three or four times each way.
3. While turning the screw driver, slowly pull the heat seal (4) out together with the injection nozzle gasket (3).
4. If the heat seal drops, repeat the above procedure.


(When reassembling)

- The heat seal and the injection nozzle gasket must be changed when the injection nozzle is removed for cleaning or for service.

- (1) Plus Screw Driver
(2) Injection Nozzle

- (3) Injection Nozzle Gasket
(Copper Gasket)
(4) Heat Seal

W1021255



Rocker Arm and Push Rod

1. Remove the rocker arm bracket screws (1).
2. Detach the rocker arm assembly (2).
3. Remove the push rods (3).

(When reassembling)

- When putting the push rods (3) onto the tappets (4), check to see if their ends are properly engaged with the dimples.

■ IMPORTANT


- After installing the rocker arm, be sure to adjust the valve clearance.






Tightening torque	Rocker arm bracket screw	9.8 to 11.3 N·m 1.00 to 1.15 kgf·m 7.2 to 8.3 lbf·ft
-------------------	--------------------------	--

- (1) Rocker Arm Bracket Screws
(2) Rocker Arm Assembly

- (3) Push Rod
(4) Tappet

W1021437





Cylinder Head

1. Loosen the pipe clamps (1), and remove the water return pipe (2).
2. Remove the cylinder head screw in the order of (n) to (a).
3. Lift up the cylinder head to detach.
4. Remove the cylinder head gasket and O-ring (3).

(When reassembling)

- Replace the cylinder head gasket with a new one.
- Securely fit the O-ring (3) to the pipe pin.
- Tighten the cylinder head screws after applying sufficient oil.
- Tighten the cylinder head screws in order of (a) to (n).
- Tighten them uniformly, or the head may deform in the long run.
- Retighten the cylinder head screws after running the engine for 30 minutes.

Tightening torque	Cylinder head screw	37.3 to 42.2 N·m 3.8 to 4.3 kgf·m 27.5 to 31.1 lbf·ft
-------------------	---------------------	---

- (1) Pipe Clamp
(2) Water Return Pipe
(3) O-ring

A : Gear Case Side
(n) to (a) : To Loosen
(a) to (n) : To Tighten

W1025645

Thermostat Assembly

1. Remove the thermostat cover mounting screws (1), and remove the thermostat cover (2).
2. Remove the thermostat assembly (4).

(When reassembling)

- Apply a liquid gasket (Three Bond 1215 or equivalent) only at the thermostat cover side of the gasket (3).

- (1) Thermostat Cover Mounting Screw (3) Thermostat Cover Gasket
(2) Thermostat Cover (4) Thermostat Assembly

W10363950

Tappets

1. Remove the tappets (1) from the crankcase.

(When reassembling)


- Visually check the contact between the tappets and the cams for proper rotation. If defect is found, replace the tappets.
- Before installing the tappets, apply engine oil thinly around them.

■ IMPORTANT

- Do not change the combination of the tappet and the tappet guide.

- (1) Tappet

W10209700



Valves

1. Remove the valve caps (2).
2. Remove the valve spring collet (3), pushing the valve spring retainer (4) by valve spring replacer (1).
3. Remove the valve spring retainer (4), the valve spring (5) and the valve stem seal (6).
4. Remove the valve (7).

(When reassembling)




- Wash the valve stem and valve guide hole, and apply engine oil sufficiently.
- After installing the valve spring collets, lightly tap the stem to assure proper fit with a plastic hammer.

■ IMPORTANT

- **Don't change the combination of the valve and the valve guide.**

- | | |
|---------------------------|---------------------|
| (1) Valve Spring Replacer | (5) Valve Spring |
| (2) Valve Cap | (6) Valve Stem Seal |
| (3) Valve Spring Collet | (7) Valve |
| (4) Valve Spring Retainer | |

W10211070



Oil Pan and Oil Strainer

1. Remove the oil pan mounting screws (1).
2. Remove the oil pan (2) by lightly tapping the rim of the pan with a wooden hammer.
3. Remove the oil strainer (3).

(When reassembling)

- After cleaning the oil strainer, check to see that the filter mesh is clean, and install it.
- Visually check the O-ring (4), apply engine oil, and install it.
- Securely fit the O-ring to the oil strainer.
- To avoid uneven tightening, tighten the oil pan mounting screws in diagonal order from the center.
- Using the hole (6) numbered “3”, install the oil strainer by mounting screw





■ IMPORTANT

- Scrape off the old adhesive completely. Wipe the sealing surface clean using waste cloth soaked with gasoline. Now apply new adhesive 3 to 5 mm (0.12 to 0.20 in.) thick all over the contact surface. Apply the adhesive also on the center of the flange as well as on the inner wall of each bolt hole.
- Cut the nozzle of the “liquid gasket” (Three Bond 1207D or equivalent) container at its second notch. Apply “liquid gasket” about 3 to 5 mm (0.12 to 0.20 in.) thick. Within 20 minutes after the application of fluid sealant, reassemble the components. Wait then for about 30 minutes, and pour oil in the crankcase.

- | | |
|----------------------------|-----------------------|
| (1) Oil Pan Mounting Screw | (4) O-ring |
| (2) Oil Pan | (5) Hole Numbered “2” |
| (3) Oil Strainer | (6) Hole Numbered “3” |

W10236610

(4) Gear Case and Timing Gears



Injection Pump, Fuel Feed Pump and Speed Control Plate (for Energize to Run Type Engine Stop Solenoid)

■ NOTE






- Governor Spring Hooking Special Tool (1) :
1.2 mm diameter hard wire with its end hooked, overall length 200 mm (7.87 in.).

The tip of wire is bent like the hook to hang governor springs.

1. Remove the socket head screws (2), and remove the engine stop solenoid (4).
2. Remove the screws and separate the speed control plate (5), taking care not to damage the governor spring (6).
3. Disconnect the governor spring (6) and remove the speed control plate (5) using the governor spring hooking special tool (1).
4. Remove the fuel feed pump (3).
5. Disconnect the start spring (8) from the bracket (9) using the specific tool (1).
6. Remove the socket head screws and nuts, and remove the injection pump (7).

- | | |
|--|--------------------------------|
| (1) Governor Spring Hooking Special Tool | A : 200 mm (7.87 in.) |
| (2) Socket Head Screw | B : 1.2 mm (0.0472 in.) |
| (3) Fuel Feed Pump | |
| (4) Engine Stop Solenoid | |
| (5) Speed Control Plate | |
| (6) Governor Spring | |
| (7) Injection Pump | |
| (8) Start Spring | |
| (9) Bracket | |

W1148604



Injection Pump, Fuel Feed Pump and Speed Control Plate (for Energize to Run Type Engine Stop Solenoid) (Continued) (When reassembling)


1. Move the fork lever (1) to the gear case side.
2. Hook the start spring (7) to the injection pump control rack pin (5).
3. Put the specific tool (8) through the fork lever hole of cylinder block (9) and hook the start spring (7).
4. Keep this spring slightly extended and install the injection pump (4). Make sure the control rod (6) should be pushed by the idling adjusting spring (2) and the pin (5) on the rod engages with the fork lever (1).
5. Hook the start spring (7) to the bracket (3) using the specific tool (8).
6. Hook the governor springs (small and large) (14) to the governor lever (13) using the governor spring hooking special tool (8) and install the speed control plate (11). Be sure to place the copper washers underneath two screws (12) in the upper of the speed control plate.
7. Install the engine stop solenoid rod (15) to the guide hole of cylinder block (10) and fix the engine stop solenoid (16) with socket head screws.

NOTE

- Be careful not to stretch the start spring (7) too long. Otherwise it may get deformed permanently.
- Make sure the start spring (7) is tight on the bracket (3).
- The sealant is applied to both sides of the soft metal gasket shim. The liquid gasket is not required for assembling.
- Addition or reduction of shim (0.05 mm, 0.0020 in.) delays or advances the injection timing by approx. 0.0087 rad (0.5 °).
- In disassembling and replacing, be sure to use the same number of new gasket shims with the same thickness.

- | | |
|--|---------------------------------------|
| (1) Fork Lever | (9) Fork Lever Hole of Cylinder Block |
| (2) Idling Adjusting Spring | (10) Guide Hole of Cylinder Block |
| (3) Bracket | (11) Speed Control Plate |
| (4) Injection Pump | (12) Screw and Copper Washer |
| (5) Injection Pump Control Rack Pin | (13) Governor Lever |
| (6) Injection Pump Control Rod | (14) Governor Spring |
| (7) Start Spring | (15) Engine Stop Solenoid Rod |
| (8) Governor Spring Hooking Special Tool | (16) Engine Stop Solenoid |

W1028534



Fan Drive Pulley

- 1. Secure the flywheel to keep it from turning.
- 2. Remove the fan drive pulley screw.
- 3. Draw out the fan drive pulley with a puller.


(When reassembling)

- Install the pulley to crankshaft, aligning the mark (1) on them.
- Apply engine oil to the fan drive pulley retaining screws. And tighten them.

Tightening torque	Fan drive pulley screw	117.7 to 127.5 N·m 12.0 to 13.0 kgf·m 86.8 to 94.0 lbf·ft
-------------------	------------------------	---

(1) Alignment Mark

W10181950



Gear Case


- 1. Remove the screw (1) of inside the gear case and outside screws (6).
- 2. Disconnect the start spring (2) from the fork lever 1.
- 3. Remove the gear case (4).





(When reassembling)

- Apply a liquid gasket (Three Bond 1215 or equivalent) to both sides of the gear case gasket (4).
- Be sure to set three O-rings (5) inside the gear case.

- | | |
|--------------------|----------------------|
| (1) Screw (Inside) | (4) Gear Case Gasket |
| (2) Start Spring | (5) O-ring |
| (3) Gear Case | (6) Screw |

W1029858





Idle Gear

1. Remove the external snap ring (3), the collar (2) and the idle gear (1).
2. Remove the idle gear shaft mounting screws (4).
3. Remove the idle gear shaft (5).

(When reassembling)

- Apply engine oil to the idle gear shaft mounting screw (4). And tighten them.
- Install the idle gear, aligning the mark (6) on the gears referring to the photo.

Tightening torque	Idle gear shaft mounting screw	9.8 to 11.3 N·m 1.00 to 1.15 kgf·m 7.2 to 8.3 lbf·ft
-------------------	--------------------------------	--

(1) Idle Gear

(2) Idle Gear Collar

(3) External Snap Ring

(4) Idle Gear Shaft Mounting Screw

(5) Idle Gear Shaft

(6) Alignment Mark

W1030437

Camshaft

1. Remove the camshaft mounting screws (1) and draw out the camshaft with camshaft gear (2) on it.




(When reassembling)

- When installing the camshaft, apply engine oil to the camshaft journals.
- Apply engine oil to the camshaft mounting screws. And tighten them.

(1) Camshaft Mounting Screw

(2) Camshaft Gear

W1030808



Fuel Camshaft

1. Remove the retaining plate (1).
2. Remove the fork lever holder mounting screws (8), then draw out the injection pump gear (3) and the fuel camshaft (2) with the governor fork assembly.

(When reassembling)

- Hook the governor spring (7) to the fork lever 2 (6) as shown in the figure before installing the fork lever assembly to the crankcase.

- | | |
|-------------------------|--------------------------------------|
| (1) Retaining Plate | (5) Fork Lever 1 |
| (2) Fuel Camshaft | (6) Fork Lever 2 |
| (3) Injection Pump Gear | (7) Governor Spring |
| (4) Governor Sleeve | (8) Fork Lever Holder Mounting Screw |

W10178820

Oil Pump and Crankshaft Gear

1. Remove the oil pump gear (6).
2. Remove the oil pump (5).
3. Remove the collar (4), the O-ring (3) and the crankshaft oil slinger (2).
4. Remove the crankshaft gear (1) with a puller.



(When reassembling)

- Install the collar (4) after aligning the marks on the gears. (See page 1-S32 "Idle Gear".)

- | | |
|----------------------------|-----------------------|
| (1) Crankshaft Gear | (4) Crankshaft Collar |
| (2) Crankshaft Oil Slinger | (5) Oil Pump |
| (3) O-ring | (6) Oil Pump Gear |

W10180290

(5) Piston and Connecting Rod



Connecting Rod Cap

1. Remove the connecting rod caps (1) using a bihexagonal 8 mm socket.

(When reassembling)

- Align the marks (a) with each other. (Face the marks toward the injection pump.)
 - Apply engine oil to the connecting rod screws and lightly screw it in by hand, then tighten it to the specified torque.
- If the connecting rod screw won't be screwed in smoothly, clean the threads.





If the connecting rod screw is still hard to screw in, replace it.

Tightening torque	Connecting rod screw	26.5 to 30.4 N·m 2.7 to 3.1 kgf·m 19.5 to 22.4 lbf·ft
-------------------	----------------------	---

- (1) Connecting Rod Cap

(a) Mark

W10275480



Piston

1. Turn the flywheel and bring the piston to top dead center.
2. Draw out the piston upward by lightly tapping it from the bottom of the crankcase with the grip of a hammer.
3. Draw out the other pistons after the same method as above.

(When reassembling)

- Before inserting the piston into the cylinder, apply enough engine oil to the cylinder.
- When inserting the piston into the cylinder, face the mark on the connecting rod to the injection pump.

■ IMPORTANT

- Do not change the combination of cylinder and piston. Make sure of the position of each piston by marking. For example, mark "1" on the No. 1 piston.
- When installing the piston into the cylinder, place the gaps of all of the piston rings as shown in the figure.
- Carefully insert the piston using a piston ring compressor (1). Otherwise, their chrome-plated section may be scratched, causing trouble inside the cylinder.

Models	Mark
D902-E2-BX-2 (BX2350D)	2A
D902-E3-BX-2 (BX2350D)	2C

(1) Piston Ring Compressor

(a) 0.785 rad (45 °)

(b) 0.785 rad (45 °)

[X] D902-E2-BX-2 (BX2350D)

(c) 1.57 rad (90 °)

[Y] D902-E3-BX-2 (BX2350D)

(d) Mark





(A) Top Ring Gap

(B) Second Ring Gap

(C) Oil Ring Gap

(D) Piston Pin Hole

W10277450



Piston Ring and Connecting Rod

1. Remove the piston rings using a piston ring tool.
2. Remove the piston pin (7), and separate the connecting rod (6) from the piston (5).

(When reassembling)

- When installing the ring, assemble the rings so that the manufacturer's mark (12) near the gap faces the top of the piston.
- When installing the oil ring onto the piston, place the expander joint (10) on the opposite side of the oil ring gap (11).
- Apply engine oil to the piston pin.
- When installing the connecting rod to the piston, immerse the piston in 80 °C (176 °F) oil for 10 to 15 minutes and insert the piston pin to the piston.
- When installing the connecting rod to the piston, align the mark (8) on the connecting rod to the fan-shaped concave (9).






■ IMPORTANT

- **Mark the same number on the connecting rod and the piston so as not to change the combination.**

- | | |
|--------------------------|--------------------------|
| (1) Top Ring | (7) Piston Pin |
| (2) Second Ring | (8) Mark |
| (3) Oil Ring | (9) Fan-Shaped Concave |
| (4) Piston Pin Snap Ring | (10) Expander Joint |
| (5) Piston | (11) Oil Ring Gap |
| (6) Connecting Rod | (12) Manufacturer's Mark |

W10281670

(6) Flywheel and Crankshaft



Flywheel

1. Secure the flywheel to keep it from turning using a flywheel stopper. (Refer to **"SPECIAL TOOLS"**.)
2. Remove all flywheel screws (1) and then remove the flywheel (2).

(When reassembling)

- Align the **"1TC"** mark (a) on the outer surface of the flywheel horizontally with the alignment mark (b) on the rear end plate. Now fit the flywheel in position.
- Apply engine oil to the threads and the undercut surface of the flywheel screw and fit the screw.

Tightening torque	Flywheel screw	53.9 to 58.8 N·m 5.5 to 6.0 kgf·m 39.8 to 43.4 lbf·ft
-------------------	----------------	---

(1) Flywheel Screw

(2) Flywheel

(a) 1TC Mark

(b) Alignment Mark

W1030810

Bearing Case Cover

1. Remove the bearing case cover mounting screws. First, remove inside screws (1) and then outside screws (2).
2. Remove the bearing case cover (6).

(When reassembling)

- Fit the bearing case gasket (3) and the bearing case cover gasket (4) with correct directions.
- Install the bearing case cover (6) to position the casting mark **"UP"** (a) on it upward.
- Apply engine oil to the oil seal (5) lip and take care that it is not rolled when installing.
- Tighten the bearing case cover mounting screws with even force on the diagonal line.

Tightening torque	Bearing case cover mounting screw	9.8 to 11.3 N·m 1.00 to 1.15 kgf·m 7.2 to 8.3 lbf·ft
-------------------	-----------------------------------	--

(1) Bearing Case Cover Mounting Screw (Inside)

(2) Bearing Case Cover Mounting Screw (Outside)

(3) Bearing Case Gasket

(4) Bearing Case Cover Gasket




(5) Oil Seal

(6) Bearing Case Cover

(a) Top Mark **"UP"**

(b) Upside

W1031168



Crankshaft Assembly

1. Remove the main bearing case screw 2 (1).
2. Turn the crankshaft to set the crankpin of the third cylinder to the bottom dead center. Then draw out the crankshaft until the crankpin of the second cylinder comes to the center of the third cylinder.
3. Turn the crankshaft by 2.09 rad (120 °) counterclockwise to set the crankpin of the second cylinder to the bottom dead center. Draw out the crankshaft until the crankpin of the first cylinder comes to the center of the third cylinder.
4. Repeat the above steps to draw out all the crankshaft.

(When reassembling)






- Clean the oil passage of the crankshaft with compressed air.
- Install the crankshaft assembly, aligning the screw hole of main bearing case screw 2 with the screw hole of crankcase.
- When tightening the main bearing case 2, apply oil to the main bearing case screw 2 (1) and screw by hand before tightening the specific torque. If not smooth to screw by hand, align the screw holes between the crankcase and the main bearing case.

Tightening torque	Main bearing case screw 2	26.5 to 30.4 N·m 2.7 to 3.1 kgf·m 19.5 to 22.4 lbf·ft
-------------------	---------------------------	---

(1) Main Bearing Case Screw 2

A : Cut place for removing and installing the crankshaft

W1031360



Main Bearing Case Assembly

1. Remove the two main bearing case screws 1 (9), and remove the main bearing case assembly 1 (1), being careful with crankshaft bearing 3 (4) (5).
2. Remove the main bearing case assembly 2 (2) and the main bearing case assembly (3) as above. Keep in mind, however, that the thrust bearing (8) is installed in the main bearing case assembly (3).

(When reassembling)

- Clean the oil passage in the main bearing cases.
- Apply clean engine oil to the bearings.
- Install the main bearing case assemblies in original positions. Since diameters of main bearing cases vary, install them in order of marking **(b)** from the gear case side. (Refer to the figure.).
- Be careful not to confuse the top and bottom of the crankshaft bearing 3 (4) (5). (Install the bearing with the oil groove **(c)** up.)
- Match the alignment numbers **(a)** on the main bearing case assembly 1.
- Do the same for the main bearing case assembly 2 (2) and the main bearing case assembly (3) too.
- When installing the main bearing case 1 and 2, face the mark **"FLYWHEEL"** to the flywheel.
- Install the thrust bearing (8) with its oil groove facing outward.
- Confirm that the main bearing case moves smoothly after tightening the main bearing case screw 1 to the specified torque.


Tightening torque	Main bearing case screw 1	12.7 to 15.7 N·m 1.3 to 1.6 kgf·m 9.4 to 11.6 lbf·ft
-------------------	---------------------------	--

- (1) Main Bearing Case Assembly 1
- (2) Main Bearing Case Assembly 2
- (3) Main Bearing Case Assembly
- (4) Crankshaft Bearing 3
(Upper, with Oil Groove)
- (5) Crankshaft Bearing 3 (Lower)
- (6) Crankshaft Bearing 2
(Upper, with Oil Groove)
- (7) Crankshaft Bearing 2 (Lower)
- (8) Thrust Bearing
- (9) Main Bearing Case Screw 1

- (a) Alignment Number**
- (b) Marking (1 or 2)**
- (c) Oil Groove**

W1034602

(7) Injection Nozzle



Nozzle Holder

- 1. Secure the nozzle retaining nut (7) with a vise.
- 2. Remove the nozzle holder (1), and take out parts inside.

(When reassembling)

- Assemble the nozzle in clean fuel oil.
- Install the push rod (4), noting its direction.
- After assembling the nozzle, be sure to adjust the fuel injection pressure.

Tightening torque	Nozzle holder	34.3 to 39.2 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 lbf·ft
	Overflow pipe retaining nut	19.6 to 24.5 N·m 2.0 to 2.5 kgf·m 14.5 to 18.1 lbf·ft
	Nozzle holder assembly	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 lbf·ft

- (1) Nozzle Holder

(2) Adjusting Washer

(3) Nozzle Spring

(4) Push Rod
- (5) Distance Piece




(6) Nozzle Piece

(7) Nozzle Retaining Nut

W1031928

[3] SERVICING

(1) Cylinder Head and Valves



Cylinder Head Surface Flatness

1. Clean the cylinder head surface.
2. Place a straightedge on the cylinder head's four sides and two diagonal as shown in the figure.
3. Measure the clearance with a thickness gauge.
4. If the measurement exceeds the allowable limit, correct it with a surface grinder.

■ IMPORTANT

- Do not place the straightedge on the combustion chamber.
- Be sure to check the valve recessing after correcting.

Cylinder head surface flatness	Allowable limit	0.05 mm 0.0020 in.
--------------------------------	-----------------	-----------------------

W1027737





Cylinder Head Flaw

1. Prepare an air spray red check.
2. Clean the surface of the cylinder head with detergent (2).
3. Spray the cylinder head surface with the red permeative liquid (1). Leave it five to ten minutes after spraying.
4. Wash away the red permeative liquid on the cylinder head surface with the detergent (2).
5. Spray the cylinder head surface with white developer (3).
6. If flawed, it can be identified as red marks.

- (1) Red Permeative Liquid
(2) Detergent

- (3) White Developer

W1076542



Valve Recessing

1. Clean the cylinder head surface, the valve face and the valve seat.
2. Insert the valve into the valve guide.
3. Measure the valve recessing with a depth gauge.
4. If the measurement exceeds the allowable limit, replace the valve.
5. If it still exceeds the allowable limit after replacing the valve, replace the cylinder head.

Valve recessing (Intake and exhaust)	Factory specification	0.10 (protrusion) to 0.10 (recessing) mm 0.0039 (protrusion) to 0.0039 (recessing) in.
	Allowable limit	0.30 (recessing) mm 0.0118 (recessing) in.

(1) Cylinder Head Surface

(A) Recessing

(B) Protrusion

W10768800


Clearance between Valve Stem and Valve Guide

1. Remove carbon from the valve guide section.
2. Measure the valve stem O.D. with an outside micrometer.
3. Measure the valve guide I.D. with a small hole gauge, and calculate the clearance.
4. If the clearance exceeds the allowable limit, replace the valves.
If it still exceeds the allowable limit, replace the valve guide.

Clearance between valve stem and valve guide	Factory specification	0.030 to 0.057 mm 0.00118 to 0.00224 in.
	Allowable limit	0.10 mm 0.0039 in.

Valve stem O.D.	Factory specification	5.968 to 5.980 mm 0.23496 to 0.23543 in.
Valve guide I.D.	Factory specification	6.010 to 6.025 mm 0.23661 to 0.23720 in.

W10311740



Replacing Valve Guide

(When removing)

1. Press out the used valve guide using a valve guide replacing tool.
(Refer to “**SPECIAL TOOLS**”.)

(When installing)

1. Clean a new valve guide and valve guide bore, and apply engine oil to them.
2. Press in a new valve guide using a valve guide replacing tool.
3. Ream precisely the I.D. of the valve guide to the specified dimension.

Valve guide I.D. (Intake and exhaust)	Factory specification	6.010 to 6.025 mm 0.23661 to 0.23720 in.
--	-----------------------	---


■ IMPORTANT

- Do not hit the valve guide with a hammer during replacement.

(A) When Removing

(B) When Installing

W10314690



Valve Seating


1. Coat the valve face lightly with prussian blue and put the valve on its seat to check the contact.
2. If the valve does not seat all the way around the valve seat or the valve contact is less than 70 %, correct the valve seating as follows.
3. If the valve contact does not comply with the reference value, replace the valve or correct the contact of valve seating.





Valve seat width	Factory specification	2.12 mm 0.0835 in.
------------------	-----------------------	-----------------------

- (1) Correct
(2) Incorrect

(3) Incorrect

W10282190





Correcting Valve and Valve Seat

NOTE

- Before correcting the valve and the seat, check the valve stem and the I.D. of valve guide section, and repair them if necessary.
- After correcting the valve seat, be sure to check the valve recessing.

1) Correcting Valve

1. Correct the valve with a valve refacer.

Valve face angle	Factory specification	0.785 rad 45 °
------------------	-----------------------	-------------------

2) Correcting Valve Seat

1. Slightly correct the seat surface with a 0.785 rad (45 °) valve seat cutter.
2. Fitting the valve, check the contact position of the valve face and the seat surface with prussian blue. (Visual check) [If the valve has been used for a long period, the seat tends to come in contact with the upper side of the valve face.]
3. Grind the upper surface of the seat with a 0.262 rad (15 °) valve seat cutter until the valve seat touches to the center of the valve face (so that (a) equals (b) as shown in the figure.)
4. Grind the seat with a 0.785 rad (45 °) valve seat cutter again, and visually recheck the contact between the valve and seat.
5. Repeat steps 3 and 4 until the correct contact is achieved.
6. Continue lapping until the seated rate becomes more than 70 % of the total contact area.

Valve seat angle	Factory specification	0.785 rad 45 °
------------------	-----------------------	-------------------

(1) Valve Seat Cutter

(a) Identical Dimensions

(A) Check Contact

(b) Valve Seat Width

(B) Correct Seat Width

(c) 0.262 rad (15 °)

(C) Check Seat Surface

(d) 0.785 rad (45 °)

(D) Check Contact

W10283500


Valve Lapping

1. Apply compound evenly to the valve lapping surface.
2. Insert the valve into the valve guide. Lap the valve onto its seat with a valve flapper or screwdriver.
3. After lapping the valve, wash the compound away and apply oil, then repeat valve lapping with oil.
4. Apply prussian blue to the contact surface to check the seated rate. If it is less than 70 %, repeat valve lapping again.

IMPORTANT

- When valve lapping is performed, be sure to check the valve recessing and adjust the valve clearance after assembling the valve.

W10288140



Free Length and Tilt of Valve Spring


1. Measure the free length **(A)** of the valve spring with a vernier caliper. If the measurement is less than the allowable limit, replace it.
2. Put the valve spring on a surface plate, place a square on the side of the valve spring.
3. Check to see if the entire side is in contact with the square. Rotate the valve spring and measure the maximum tilt **(B)**. If the measurement exceeds the allowable limit, replace it.
4. Check the entire surface of the valve spring for scratches. If there is any defect, replace it.

Free length (A)	Factory specification	31.3 to 31.8 mm 1.232 to 1.252 in.
	Allowable limit	28.4 mm 1.118 in.
Tilt (B)	Allowable limit	1.2 mm 0.047 in.

(A) Free Length

(B) Tilt

W11157830




Valve Spring Setting Load

1. Place the valve spring on a tester and compress it to the same length it is actually compressed the engine.
2. Read the compression load on the gauge.
3. If the measurement is less than the allowable limit, replace it.

Setting load / Setting length	Factory specification	64.7 N / 27.0 mm 6.6 kgf / 27.0 mm 14.6 lbf / 1.063 in.
	Allowable limit	54.9 N / 27.0 mm 5.6 kgf / 27.0 mm 12.3 lbf / 1.063 in.

W11177330




Oil Clearance between Rocker Arm and Rocker Arm Shaft

1. Measure the rocker arm shaft O.D. with an outside micrometer.
2. Measure the rocker arm I.D. with an inside micrometer, and then calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the rocker arm and measure the oil clearance again. If it still exceeds the allowable limit, replace also the rocker arm shaft.

Oil clearance between rocker arm and rocker arm shaft	Factory specification	0.016 to 0.045 mm 0.00063 to 0.00177 in.
	Allowable limit	0.15 mm 0.0059 in.

Rocker arm shaft O.D.	Factory specification	10.473 to 10.484 mm 0.41232 to 0.41276 in.
Rocker arm I.D.	Factory specification	10.500 to 10.518 mm 0.41339 to 0.41410 in.

W11199710




Push Rod Alignment

1. Place the push rod on V blocks.
2. Measure the push rod alignment.
3. If the measurement exceeds the allowable limit, replace the push rod.

Push rod alignment	Allowable limit	0.25 mm 0.0098 in.
--------------------	-----------------	-----------------------

W11220210



Oil Clearance between Tappet and Tappet Guide Bore


1. Measure the tappet O.D. with an outside micrometer.
2. Measure the I.D. of the tappet guide bore with a cylinder gauge, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit or the tappet is damaged, replace the tappet.

Oil clearance between tappet and tappet guide bore	Factory specification	0.016 to 0.052 mm 0.00063 to 0.00205 in.
	Allowable limit	0.10 mm 0.0039 in.

Tappet O.D.	Factory specification	17.966 to 17.984 mm 0.70732 to 0.70803 in.
Tappet guide bore I.D.	Factory specification	18.000 to 18.018 mm 0.70866 to 0.70937 in.

W11231410

(2) Timing Gears



Timing Gear Backlash

1. Set a dial indicator (lever type) with its tip on the gear tooth.
2. Move the gear to measure the backlash, holding its mating gear.
3. If the backlash exceeds the allowable limit, check the oil clearance of the shaft and the gear.
4. If the oil clearance is not proper, replace the gear.


Backlash between idle gear and crank gear	Factory specification	0.043 to 0.124 mm 0.00169 to 0.00488 in.
	Allowable limit	0.15 mm 0.0059 in.

Backlash between idle gear and cam gear	Factory specification	0.047 to 0.123 mm 0.00185 to 0.00484 in.
	Allowable limit	0.15 mm 0.0059 in.

Backlash between idle gear and injection pump gear	Factory specification	0.046 to 0.124 mm 0.00181 to 0.00488 in.
	Allowable limit	0.15 mm 0.0059 in.

Backlash between oil pump drive gear and crank gear	Factory specification	0.041 to 0.123 mm 0.00161 to 0.00484 in.
	Allowable limit	0.15 mm 0.0059 in.

W11264830




Idle Gear Side Clearance

1. Set a dial indicator with its tip on the idle gear.
2. Measure the side clearance by moving the idle gear to the front and the rear.
3. If the measurement exceeds the allowable limit, replace the idle gear collar.

Idle gear side clearance	Factory specification	0.20 to 0.51 mm 0.0079 to 0.0201 in.
	Allowable limit	0.80 mm 0.0315 in.

W11286770




Camshaft Side Clearance

1. Set a dial indicator with its tip on the camshaft.
2. Measure the side clearance by moving the cam gear to the front and rear.
3. If the measurement exceeds the allowable limit, replace the camshaft stopper.

Camshaft side clearance	Factory specification	0.15 to 0.31 mm 0.0059 to 0.0122 in.
	Allowable limit	0.50 mm 0.0197 in.

W11299720




Camshaft Alignment

1. Support the camshaft with V blocks on the surface plate at both end journals.
2. Set a dial indicator with its tip on the intermediate journal.
3. Measure the camshaft alignment.
4. If the measurement exceeds the allowable limit, replace the camshaft.

Camshaft alignment	Allowable limit	0.01 mm 0.0004 in.
--------------------	-----------------	-----------------------

W11312720






Cam Height

1. Measure the height of the cam at its highest point with an outside micrometer.
2. If the measurement is less than the allowable limit, replace the camshaft.

Cam height of intake and exhaust	Factory specification	26.88 mm 1.0583 in.
	Allowable limit	26.83 mm 1.0563 in.

W11324040



Oil Clearance of Camshaft Journal

1. Measure the camshaft journal O.D. with an outside micrometer.
2. Measure the cylinder block bore I.D. for camshaft with an inside micrometer, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the camshaft.

Oil clearance of camshaft journal	Factory specification	0.050 to 0.091 mm 0.00197 to 0.00358 in.
	Allowable limit	0.15 mm 0.0059 in.

Camshaft journal O.D.	Factory specification	32.934 to 32.950 mm 1.29661 to 1.29724 in.
Camshaft Bearing I.D. (Cylinder block bore I.D.)	Factory specification	33.000 to 33.025 mm 1.29921 to 1.30020 in.

W11335580


Oil Clearance between Idle Gear Shaft and Idle Gear Bushing

1. Measure the idle gear shaft O.D. with an outside micrometer.
2. Measure the idle gear bushing I.D. with an inside micrometer, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the bushing.
4. If it still exceeds the allowable limit, replace the idle gear shaft.

Oil clearance between idle gear shaft and idle gear bushing	Factory specification	0.020 to 0.084 mm 0.00079 to 0.00331 in.
	Allowable limit	0.10 mm 0.0039 in.

Idle gear shaft O.D.	Factory specification	19.967 to 19.980 mm 0.78610 to 0.78661 in.
Idle gear bushing I.D.	Factory specification	20.000 to 20.051 mm 0.78740 to 0.78941 in.

W11356150



Replacing Idle Gear Bushing

(When removing)

1. Press out the used idle gear bushing using an idle gear bushing replacing tool. (Refer to "SPECIAL TOOLS".)

(When installing)



1. Clean a new idle gear bushing and idle gear bore, and apply engine oil to them.
2. Press in a new bushing using an idle gear bushing replacing tool, until it is flush with the end of the idle gear.

(A) When Removing

(B) When Installing

W11373220

(3) Piston and Connecting Rod



Piston Pin Bore I.D.

1. Measure the piston pin bore I.D. in both the horizontal and vertical directions with a cylinder gauge.
2. If the measurement exceeds the allowable limit, replace the piston.

Piston pin bore I.D.	Factory specification	20.000 to 20.013 mm 0.78740 to 0.78791 in.
	Allowable limit	20.05 mm 0.7894 in.

W11406200


Oil Clearance between Piston Pin and Small End Bushing

1. Measure the piston pin O.D. where it contacts the bushing with an outside micrometer.
2. Measure the small end bushing I.D. with an inside micrometer, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the bushing. If it still exceeds the allowable limit, replace the piston pin.

Oil clearance between piston pin and small end bushing	Factory specification	0.014 to 0.038 mm 0.00055 to 0.00150 in.
	Allowable limit	0.10 mm 0.0039 in.

Piston pin O.D.	Factory specification	20.002 to 20.011 mm 0.78748 to 0.78783 in.
Small end bushing I.D.	Factory specification	20.025 to 20.040 mm 0.78839 to 0.78897 in.

W11420110



Replacing Small End Bushing

(When removing)

1. Press out the used bushing using a small end bushing replacing tool. (Refer to "SPECIAL TOOLS")

(When installing)

1. Clean a new small end bushing and small end hole, and apply engine oil to them.
2. Using a small end bushing replacing tool, press in a new bushing (service parts) taking care to see that the position of the connecting rod oil hole matches the bushing hole.


[Servicing parts dimension]

Oil clearance between piston pin and small end bushing (Spare parts)	Factory specification	0.015 to 0.075 mm 0.00059 to 0.00295 in.
	Allowable limit	0.15 mm 0.0059 in.


Small end bushing I.D. (Spare parts)	Factory specification	20.026 to 20.077 mm 0.78843 to 0.79043 in.
--------------------------------------	-----------------------	---

- (1) Seam
(2) Oil Hole

- (A) When Removing**
(B) When Installing
(a) 0.785 rad (45°)



W11437590



Connecting Rod Alignment


■ NOTE

- Since checking of the I.D. of the connecting rod small end bushing is the basis of this check, check bushing for wear beforehand.

1. Install the piston pin into the connecting rod.
2. Install the connecting rod on the connecting rod alignment tool.
3. Put a gauge over the piston pin, and move it against the face plate.
4. If the gauge does not fit squarely against the face plate, measure the space between the pin of the gauge and the face plate.
5. If the measurement exceeds the allowable limit, replace the connecting rod.

Connecting rod alignment	Allowable limit	0.05 mm 0.0020 in.
--------------------------	-----------------	-----------------------

W10314620




Piston Ring Gap

1. Insert the piston ring into the lower part of the cylinder (the least worn out part) with a piston ring compressor and piston.
2. Measure the ring gap with a feeler gauge.
3. If the measurement exceeds the allowable limit, replace the piston ring.

Piston ring gap	Top ring	Factory specification	0.20 to 0.35 mm 0.0079 to 0.0138 in.
		Allowable limit	1.25 mm 0.0492 in.
	Second ring	Factory specification	0.35 to 0.50 mm 0.0138 to 0.0197 in.
		Allowable limit	1.25 mm 0.0492 in.
	Oil ring	Factory specification	0.20 to 0.35 mm 0.0079 to 0.0138 in.
		Allowable limit	1.25 mm 0.0492 in.

W11466710





Clearance between Piston Ring and Piston Ring Groove

1. Clean the rings and the ring grooves, and install each ring in its groove.
2. Measure the clearance between the ring and the groove with a feeler gauge.
3. If the clearance exceeds the allowable limit, replace the piston ring.
4. If the clearance still exceeds the allowable limit after replacing the ring, replace the piston.

Clearance between piston ring and piston ring groove	Second ring	Factory specification	0.090 to 0.120 mm 0.00354 to 0.00472 in.
		Allowable limit	0.15 mm 0.0059 in.
	Oil ring	Factory specification	0.04 to 0.08 mm 0.0016 to 0.0031 in.
		Allowable limit	0.15 mm 0.0059 in.

W11485500

(4) Crankshaft



Crankshaft Side Clearance

1. Set a dial indicator with its tip on the end of the crankshaft.
2. Measure the side clearance by moving the crankshaft to the front and rear.
3. If the measurement exceeds the allowable limit, replace the thrust bearings.
4. If the same size bearing is useless because of the crankshaft journal wear, replace it with an oversize one referring to the table and figure.

Crankshaft side clearance	Factory specification	0.15 to 0.31 mm 0.0059 to 0.0122 in.
	Allowable limit	0.50 mm 0.0197 in.

(Reference)


- Oversize thrust bearing

Oversize	Bearing	Code Number	Marking
0.2 mm 0.008 in.	Thrust bearing 1 02	15261-23950	020 OS
	Thrust bearing 2 02	15261-23970	020 OS
0.4 mm 0.016 in.	Thrust bearing 1 04	15261-23960	040 OS
	Thrust bearing 2 04	15261-23980	040 OS

- Oversize dimensions of crankshaft journal

Oversize	0.2 mm 0.008 in.	0.4 mm 0.016 in.
Dimension A	23.40 to 23.45 mm 0.9213 to 0.9232 in.	23.80 to 23.85 mm 0.9370 to 0.9390 in.
Dimension B	46.1 to 46.3 mm 1.815 to 1.823 in.	46.3 to 46.5 mm 1.823 to 1.831 in.
Dimension C	1.8 to 2.2 mm radius 0.071 to 0.087 in. radius	1.8 to 2.2 mm radius 0.071 to 0.087 in. radius
(0.8S) The crankshaft journal must be fine-finished to higher than ∇∇∇∇.		

W11586190




Crankshaft Alignment

1. Support the crankshaft with V blocks on the surface plate at both end journals.
2. Set a dial indicator with its tip on the intermediate journal.
3. Measure the crankshaft alignment.
4. If the measurement exceeds the allowable limit, replace the crankshaft.

Crankshaft alignment	Allowable limit	0.02 mm 0.0008 in.
----------------------	-----------------	-----------------------

W11613530



Oil Clearance between Crankpin and Crankpin Bearing

1. Clean the crankpin and crankpin bearing.
2. Put a strip of plastigage on the center of the crankpin.
3. Install the connecting rod cap and tighten the connecting rod screws to the specified torque, and remove the cap again.
4. Measure the amount of the flattening with the scale, and get the oil clearance.
5. If the oil clearance exceeds the allowable limit, replace the crankpin bearing.
6. If the same size bearing is useless because of the crankpin wear, replace it with an undersize one referring to the table and figure.

■ NOTE

- **Never insert the plastigage into the crankpin oil hole.**
- **Be sure not to move the crankshaft while the connecting rod screws are tightened.**

Oil clearance between crankpin and crankpin bearing	Factory specification	0.020 to 0.051mm 0.00079 to 0.00201 in.
	Allowable limit	0.15 mm 0.0059 in.

Crankpin O.D.	Factory specification	33.959 to 33.975 mm 1.33697 to 1.33760 in.
Crankpin bearing I.D.	Factory specification	33.995 to 34.010 mm 1.33839 to 1.33898 in.

(Reference)



- Undersize crankpin bearing

Undersize	Bearing	Code Number	Marking
0.2 mm 0.008 in.	Crankpin bearing 02	15861-22970	020 US
0.4 mm 0.016 in.	Crankpin bearing 04	15861-20980	040 US

- Undersize dimensions of crankpin

Undersize	0.2 mm 0.008 in.	0.4 mm 0.016 in.
Dimension A	2.3 to 2.7 mm radius 0.091 to 0.106 in. radius	2.3 to 2.7 mm radius 0.091 to 0.106 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.0394 to 0.0591 in. relief	1.0 to 1.5 mm relief 0.0394 to 0.0591 in. relief
Dimension C	33.759 to 33.775 mm dia. 1.32910 to 1.32973 in. dia.	33.559 to 33.575 mm dia. 1.32122 to 1.32185 in. dia.
(0.8S) The crankshaft journal must be fine-finished to higher than $\nabla\nabla\nabla\nabla$. *Holes to be de-burred and edges rounded with 1.0 to 1.5 mm (0.0394 to 0.0591 in.) relief.		

W11625390



Oil Clearance between Crankshaft Journal and Crankshaft Bearing 1

1. Measure the O.D. of the crankshaft front journal with an outside micrometer.
2. Measure the I.D. of the crankshaft bearing 1 with an inside micrometer, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the crankshaft bearing 1.
4. If the same size bearing is useless because of the crankshaft journal wear, replace it with an undersize one referring to the table and the figure.

Oil Clearance between crankshaft journal and crankshaft bearing 1	Factory specification	0.034 to 0.106 mm 0.00134 to 0.00417 in.
	Allowable limit	0.20 mm 0.0079 in.

Crankshaft journal O.D.	Factory specification	43.934 to 43.950 mm 1.72968 to 1.73031 in.
Crankshaft bearing 1 I.D.	Factory specification	43.984 to 44.040 mm 1.73165 to 1.73386 in.

(Reference)

- Undersize crankshaft bearing 1


Undersize	Models	Bearing	Code Number	Marking
0.2 mm 0.008 in.	D902-E2-BX-2,	Crankshaft bearing 1 02	1G460-23910	020 US
0.4 mm 0.016 in.	D902-E3-BX-2	Crankshaft bearing 1 04	1G460-23920	040 US

- Undersize dimensions of crankshaft journal

Undersize	Models	0.2 mm 0.008 in.	0.4 mm 0.016 in.
Dimension A	All models	1.8 to 2.2 mm radius 0.071 to 0.087 in. radius	1.8 to 2.2 mm radius 0.071 to 0.087 in. radius
*Dimension B	All models	1.0 to 1.5 mm relief 0.0394 to 0.0591 in. relief	1.0 to 1.5 mm relief 0.0394 to 0.0591 in. relief
Dimension C	D902-E2-BX-2, D902-E3-BX-2	43.734 to 43.750 mm dia. 1.72181 to 1.72244 in. dia.	43.534 to 43.550 mm dia. 1.71394 to 1.71457 in. dia.

(0.8S)
The crankshaft journal must be fine-finished to higher than $\nabla\nabla\nabla\nabla$.
*Holes to be de-burred and edges rounded with 1.0 to 1.5 mm (0.0394 to 0.0591 in.) relief.

W10323470



Replacing Crankshaft Bearing 1

(When removing)

1. Press out the used crankshaft bearing 1 using a crankshaft bearing 1 replacing tool. (Refer to “**SPECIAL TOOLS**”.)

(When installing)

1. Clean a new crankshaft bearing 1 and crankshaft journal bore, and apply engine oil to them.
2. Using a crankshaft bearing 1 replacing tool, press in a new bearing 1 (2) so that its seam (1) directs toward the exhaust manifold side. (See figure.)

Dimension (A)	Factory specification	0.0 to 0.3 mm 0.0 to 0.0118 in.
---------------	-----------------------	------------------------------------

(1) Seam


(A) Dimension

(2) Crankshaft Bearing 1

(B) 0.366 rad (21 °)

(3) Cylinder Block

W10342000



Oil Clearance between Crankshaft Journal and Crankshaft Bearing 2 and Crankshaft Bearing 3

1. Put a strip of plastigage on the center of the journal.
2. Install the bearing case and tighten the bearing case screws 1 to the specified torque, and remove the bearing case again.
3. Measure the amount of the flattening with the scale, and get the oil clearance.
4. If the oil clearance exceeds the allowable limit, replace the crankshaft bearing 2 (crankshaft bearing 3).
5. If the same size bearing is useless because of the crankshaft journal wear, replace it with an undersize one referring to the table and figure.

NOTE


- Be sure not to move the crankshaft while the bearing case screws are tightened.

Oil clearance between crankshaft journal and crankshaft bearing 2 (crankshaft bearing 3)	Factory specification	0.028 to 0.059 mm 0.00110 to 0.00232 in.
	Allowable limit	0.20 mm 0.0079 in.

Crankshaft journal O.D. (Flywheel side)	Factory specification	43.934 to 43.950 mm 1.72968 to 1.73031 in.
Crankshaft bearing 2 I.D.	Factory specification	43.978 to 43.993 mm 1.73142 to 1.73201 in.

Crankshaft journal O.D. (Intermediate)	Factory specification	43.934 to 43.950 mm 1.72968 to 1.73031 in.
Crankshaft bearing 3 I.D.	Factory specification	43.978 to 43.993 mm 1.73142 to 1.73201 in.

W10344030



Oil Clearance between Crankshaft Journal and Crankshaft Bearing 2 and Crankshaft Bearing 3 (Continued)

(Reference)

- Undersize crankshaft bearing 2 and 3 (0.2 mm (0.008 in.))

Undersize	Bearing	Code Number	Marking
D902-E2-BX-2	Crankshaft bearing 2 02	1G460-23930	020 US
	Crankshaft bearing 3 02	1G460-23940	

- Undersize crankshaft bearing 2 and 3 (0.4 mm (0.016 in.))

Undersize	Bearing	Code Number	Marking
D902-E2-BX-2	Crankshaft bearing 2 04	1G460-23950	040 US
	Crankshaft bearing 3 04	1G460-23960	

- Undersize dimensions of crankshaft journal

Undersize	Undersize	0.2 mm 0.008 in.	0.4 mm 0.016 in.
Dimension A	All models	1.8 to 2.2 mm radius 0.071 to 0.087 in. radius	1.8 to 2.2 mm radius 0.071 to 0.087 in. radius
*Dimension B	All models	1.0 to 1.5 mm relief 0.0394 to 0.0591 in. relief	1.0 to 1.5 mm relief 0.0394 to 0.0591 in. relief
Dimension C	D902-E2-BX-2, D902-E3-BX-2	43.734 to 43.750 mm dia. 1.72181 to 1.72244 in. dia.	43.534 to 43.550 mm dia. 1.71394 to 1.71457 in. dia.
Dimension D	All models	43.734 to 43.750 mm dia. 1.72181 to 1.72244 in. dia.	43.534 to 43.550 mm dia. 1.71394 to 1.71457 in. dia.



(0.8S)

The crankshaft journal must be fine-finished to higher than ▽▽▽▽.

*Holes to be de-burred and edges rounded with 1.0 to 1.5 mm (0.0394 to 0.0591 in.) relief.

W1047088

(5) Cylinder



Cylinder Wear


- Measure the cylinder liner I.D. at the six positions (see figure) with a cylinder gauge to find the maximum and minimum I.D.'s.
- Get the difference (Maximum wear) between the maximum and the minimum I.D.'s.
- If the wear exceeds the allowable limit, bore and hone to the oversize dimension. (Refer to **"Correcting Cylinder"**.)
- Visually check the cylinder wall for scratches. If deep scratches are found, the cylinder should be bored. (Refer to **"Correcting Cylinder"**.)

Cylinder liner I.D.	Factory specification	72.000 to 72.019 mm 2.83464 to 2.83539 in.
	Allowable limit	72.150 mm 2.84055 in.

(A) Top
(B) Middle
(C) Bottom (Skirt)

(a) Right-angled to Piston Pin
(b) Piston Pin Direction

W10360060



Correcting Cylinder

- When the cylinder is worn beyond the allowable limit, bore and hone it to the specified dimension.

Cylinder liner I.D.	Factory specification	72.250 to 72.269 mm 2.84449 to 2.84524 in.
	Allowable limit	72.400 mm 2.85040 in.
Finishing	Hone to 2.2 to 3.0 μmRz . (0.000087 to 0.00012 in.Rz) ▽▽▽	

- Replace the piston and piston rings with oversize ones.
Oversize : 0.25 mm (0.0098 in.)
Marking : 025

NOTE

- When the oversize cylinder is worn beyond the allowable limit, replace the cylinder block with a new one.

(1) Cylinder I.D. (Before Correction) (2) Cylinder I.D. [Oversize]

W10367470

(6) Oil Pump




Rotor Lobe Clearance

- Measure the clearance between lobes of the inner rotor and the outer rotor with a thickness gauge.
- If the clearance exceeds the factory specifications, replace the oil pump rotor assembly.

Rotor lobe clearance	Factory specification	0.03 to 0.14 mm 0.0012 to 0.0055 in.
----------------------	-----------------------	---

W10378950




Clearance between Outer Rotor and Pump Body

- Measure the clearance between the outer rotor and the pump body with a thickness gauge.
- If the clearance exceeds the factory specifications, replace the oil pump rotor assembly.

Clearance between outer rotor and pump body	Factory specification	0.07 to 0.15 mm 0.0028 to 0.0059 in.
---	-----------------------	---

W10381420



Clearance between Rotor and Cover

- Put a strip of plastigage onto the rotor face with grease.
- Install the cover and tighten the screws.
- Remove the cover carefully, and measure the amount of the flattening with the scale and get the clearance.
- If the clearance exceeds the factory specifications, replace oil pump rotor assembly.

Clearance between rotor and cover	Factory specification	0.075 to 0.135 mm 0.00295 to 0.00531 in.
-----------------------------------	-----------------------	---

W10382660


2 TRANSAXLE

MECHANISM

CONTENTS

1. STRUCTURE	2-M1
2. TRAVELLING SYSTEM	2-M2
[1] HYDROSTATIC TRANSMISSION	2-M2
(1) Structure	2-M2
(2) Oil Flow	2-M3
(3) HST Control Linkage	2-M8
(4) Speed Set Linkage	2-M9
[2] RANGE GEAR SHIFT SECTION	2-M11
[3] FRONT WHEEL DRIVE SECTION	2-M11
[4] DIFFERENTIAL GEAR SECTION	2-M12
(1) Differential Gears	2-M12
(2) Differential Lock	2-M13
[5] BRAKE SECTION	2-M14
3. PTO SYSTEM	2-M15
[1] PTO CLUTCH AND VALVE	2-M15
[2] MID AND REAR PTO SECTION	2-M18
4. OTHERS	2-M19
[1] HYDRAULIC PUMP DRIVE GEAR SECTION	2-M19

1. STRUCTURE



- (1) Hydrostatic Transmission
- (2) PTO Clutch Section
- (3) Range Gear Shift Section

- (4) Front Wheel Drive Gear Section
- (5) Mid-PTO Section
- (6) PTO Gear Shift Section


- (7) Rear PTO Section
- (8) Differential Gear Section
- (9) Brake Section

A : Front Side
B : Rear Side

2. TRAVELLING SYSTEM

[1] HYDROSTATIC TRANSMISSION


(1) Structure



- | | | | |
|--|-------------------------|-----------------------------|----------------------------|
| (1) Check and High Pressure Relief Valve | (6) Thrust Ball Bearing | (12) Cir-Clip | (17) Needle Bearing |
| (2) Trunnion Arm | (7) Swashplate | (13) Thrust Ball Bearing | (18) Ball Bearing |
| (3) Center Section | (8) Cradle Bearing | (14) Cylinder Block (Motor) | (19) Pump Shaft |
| (4) Piston Spring | (9) Spring | (15) Plug | (20) Cylinder Block (Pump) |
| (5) Piston | (10) Cir-Clip | (16) Motor Shaft | (21) Charge Relief Valve |
| | (11) Spring | | |

The hydrostatic transmission consists of variable displacement piston pump, fixed displacement piston motor and valve system.

(2) Oil Flow




- | | | | |
|--|--|--|-------------------|
| (1) Cylinder Block (Pump) | (7) High Pressure Relief Port Plug (Forward) | (13) Power Steering Controller | A : A Port |
| (2) Swashplate | | (14) Hydraulic Pump | B : B Port |
| (3) Piston | (8) Charge Relief Valve | (15) Flow Priority Valve (Hydraulic Control Valve) | C : C Port |
| (4) Cylinder Block (Motor) | (9) High Pressure Relief Port Plug (Reverse) | (16) Position Control Valve | D : D Port |
| (5) Check and High Pressure Relief Valve (Forward) | (10) PTO Clutch Valve | (17) Oil Strainer | |
| (6) Check and High Pressure Relief Valve (Reverse) | (11) PTO Relief Valve | (18) Transmission Case | |
| | (12) Oil Filter Cartridge | | |

The pump and motor are joined in a closed hydraulic loop and most of oil circulates within the main oil circuit. A little oil lubricates and oozes out from the clearance between the moving parts of the case. Then oil in the main oil circuit of the HST needs to be supplied a want.

The oil from the power steering circuit flows into the HST for charging.

The charge oil aids smooth operation of pistons for pump and motor. The charge oil passes through the oil filter cartridge to charge relief valve port. The rest of oil passes through the charge relief valve into the HST housing. And overflow oil from HST housing return to the transmission case.


Neutral



- | | | | |
|--|--|--|--------------------------|
| (1) Cylinder Block (Pump) | (7) High Pressure Relief Port Plug (Forward) | (13) Power Steering Controller | A : A Port |
| (2) Swashplate | (8) Charge Relief Valve | (14) Hydraulic Pump | B : B Port |
| (3) Piston | (9) High Pressure Relief Port Plug (Reverse) | (15) Flow Priority Valve (Hydraulic Control Valve) | C : C Port |
| (4) Cylinder Block (Motor) | (10) PTO Clutch Valve | (16) Position Control Valve | D : D Port |
| (5) Check and High Pressure Relief Valve (Forward) | (11) PTO Relief Valve | (17) Oil Strainer | X : High Pressure |
| (6) Check and High Pressure Relief Valve (Reverse) | (12) Oil Filter Cartridge | (18) Transmission Case | Y : Low Pressure |
| | | | Z : Free Oil |

When the speed control pedal is in neutral, the variable swashplate is not tilted as shown in figure above. The pump pistons only rotate with cylinder block without reciprocating. Since the oil is not being pumped to the motor, the cylinder block in the motor is stationary and the output shaft does not move.

■ **Forward**



- | | | | |
|--|--|--|--------------------------|
| (1) Cylinder Block (Pump) | (7) High Pressure Relief Port Plug (Forward) | (13) Power Steering Controller | A : A Port |
| (2) Swashplate | | (14) Hydraulic Pump | B : B Port |
| (3) Piston | (8) Charge Relief Valve | (15) Flow Priority Valve (Hydraulic Control Valve) | C : C Port |
| (4) Cylinder Block (Motor) | (9) High Pressure Relief Port Plug (Reverse) | (16) Position Control Valve | D : D Port |
| (5) Check and High Pressure Relief Valve (Forward) | (10) PTO Clutch Valve | (17) Oil Strainer | X : High Pressure |
| (6) Check and High Pressure Relief Valve (Reverse) | (11) PTO Relief Valve | (18) Transmission Case | Y : Low Pressure |
| | (12) Oil Filter Cartridge | | Z : Free Oil |


When the speed control pedal is stepped on and in forward, the variable swashplate is tilted as shown in figure above.

As the pump cylinder block rotates with the input shaft, oil is forced out of pump port **B** at high pressure. As pressure oil enters motor port **D**, the pistons, which align with port **D**, are pushed against the swashplate and slide down the inclined surface.

Then the output shaft rotates with the motor cylinder block. This drives the machine forward and the angle of pump swashplate determines the output shaft speed.

As the motor cylinder block continues to rotate, oil is forced out of motor port **C** at low pressure and returns to the pump.

■ Reverse



- | | | | |
|--|--|--|--------------------------|
| (1) Cylinder Block (Pump) | (7) High Pressure Relief Port Plug (Forward) | (13) Power Steering Controller | A : A Port |
| (2) Swashplate | | (14) Hydraulic Pump | B : B Port |
| (3) Piston | (8) Charge Relief Valve | (15) Flow Priority Valve (Hydraulic Control Valve) | C : C Port |
| (4) Cylinder Block (Motor) | (9) High Pressure Relief Port Plug (Reverse) | (16) Position Control Valve | D : D Port |
| (5) Check and High Pressure Relief Valve (Forward) | (10) PTO Clutch Valve | (17) Oil Strainer | X : High Pressure |
| (6) Check and High Pressure Relief Valve (Reverse) | (11) PTO Relief Valve | (18) Transmission Case | Y : Low Pressure |
| | (12) Oil Filter Cartridge | | Z : Free Oil |


When the speed control pedal is stepped on and in reverse, the variable swashplate is tilted as shown in figure above.

As the pump cylinder block rotates with the input shaft, oil is forced out of pump port **A** at high pressure. As pressure oil enters motor port **C**, the pistons, which align with port **C**, are pushed against the swashplate and slide down the inclined surface.

Then the output shaft rotates with the motor cylinder block. This drives the machine rearward and the angle of pump swashplate determines the output shaft speed.

As the motor cylinder block continues to rotate, oil is forced out of motor port **D** at low pressure and returns to the pump.

■ Relief (Reverse)



(1) Cylinder Block (Pump)

(2) Swashplate

(3) Piston

(4) Cylinder Block (Motor)

(5) Check and High Pressure Relief Valve (Forward)

(6) Check and High Pressure Relief Valve (Reverse)

(7) High Pressure Relief Port Plug (Forward)

(8) Charge Relief Valve

(9) High Pressure Relief Port Plug (Reverse)

(10) PTO Clutch Valve

(11) PTO Relief Valve

(12) Oil Filter Cartridge

(13) Power Steering Controller

(14) Hydraulic Pump

(15) Flow Priority Valve (Hydraulic Control Valve)

(16) Position Control Valve

(17) Oil Strainer

(18) Transmission Case

A : A Port**B : B Port****C : C Port****D : D Port****X : High Pressure****Y : Low Pressure****Z : Free Oil**


When the speed control pedal is in reverse, the variable swashplate is tilted as shown in figure above.

As the pump cylinder block rotates with the input shaft, oil is forced out of pump port **A** at high pressure. As pressure oil enters motor port **C**, the pistons, which align with port **C**, are pushed against the swashplate and slide down the inclined surface. Since the oil pressure in the check and high pressure relief valve (Reverse) increase, the high oil pressure opens the check and high pressure relief valve (Reverse) and the flows through the charge relief valve to the transmission case.

Then the output shaft rotates with the motor cylinder block. This drives the machine reverse and the angle of pump swashplate determines the output shaft speed.

As the motor cylinder block continues to rotate, oil is forced out of motor port **D** at low pressure and returns to the pump.

(3) HST Control Linkage



- (1) Neutral Spring
- (2) Trunnion Arm
- (3) Cruise Rod
- (4) Brake Pedal
- (5) Speed Control Pedal
- (6) Parking Plate
- (7) Cruise Arm
- (8) Cruise Lock
- (9) Cruise Lock
- (10) HST Pedal Link
- (11) Speed Change Rod
- (12) Damper


W1020319

The speed control pedal (5) and the trunnion arm are linked with the HST pedal link (10) and the speed change rod (11). As the front of the pedal is depressed, the swashplate connected to the trunnion arm (2) rotates and forward travelling speed increases. Depressing the rear end increases reverse speed.

The trunnion arm (2) is returned to neutral position by the neutral arm and the tension of neutral spring. At the same time, the swashplate is returned to neutral, when the pedal is released. The damper (12) connected to the HST pedal link (10) restricts the movement of the linkage to prevent abrupt operation or reversing.

(4) Speed Set Linkage

■ Speed Set




When pushing and holding the speed set rod (1) and depressing the speed control pedal (3), the desired speed is set.

When pushing the speed set rod (1), the cruise arm (5) is rotated counter clockwise.

When depressing the speed control pedal (3) forward, the HST pedal link clockwise.

Since both the cruise lock (6) of the cruise arm (5) and the cruise lock (7) of HST pedal link (8) are locked, the speed control pedal (3) is held at a selected position.

■ When the Brake Pedal is Depressed



3TAAAAHKP072B

- (1) Speed Control Pedal
- (2) Brake Pedal
- (3) Release Plate
- (4) Brake Rod
- (5) Brake Wire, RH
- (6) Parking Brake Wire
- (7) Parking Brake Lock Pedal
- (8) Brake Wire, LH
- (9) Brake Rod, LH
- (10) Emergency Brake Lever
- (11) Speed Set Rod
- (12) Cruise Arm
- (13) Cruise Lock
- (14) Cruise Lock
- (15) HST Pedal Link
- (16) Speed Change Rod
- (17) Trunnion Arm

A : Cruise Rod "Pushed Up"
B : HST Pedal Link "Pushed Up"
C : Cruise Arm Rotates "Clockwise"

W1022896


When the brake pedal (2) is depressed, the release plate (3) located under the brake pedal (2) is pushed down. Since the release plate (3) rotates, the HST pedal link (15) is pushed up.

The lock between the cruise lock (14) of the HST pedal link (15) and the cruise lock (13) of the cruise arm (12) is released.

The speed control pedal (1) is not held at a selected position.

Since the spring pulls the speed set rod (11) upward, the speed set rod (11) is pushed up.

[2] RANGE GEAR SHIFT SECTION



Two kinds of power flow are selected by operating the range gear shift lever to shift the 16T-24T shifter gear (4) on the spiral bevel gear shaft (3).

■ Low Range

17T Gear Shaft (2) → Shifter Gear (24T) (4) → Spiral Bevel Pinion Shaft (3).

■ High Range


25T Gear (1) → Shifter Gear (16T) (4) → Spiral Bevel Pinion Shaft (3).

- (1) 25T Gear
- (2) 17T Gear
- (3) Spiral Bevel Pinion Shaft
- (4) 16T-24T Shifter Gear

L : Low Range
H : High Range

W1014705

[3] FRONT WHEEL DRIVE SECTION



2-wheel drive or 4-wheel drive is selected by changing the position of 19T shifter gear (2) with the front wheel drive lever.

■ Front Wheel Drive “Disengaged”

When the front wheel drive lever is set to “Disengaged” position, the 19T shifter gear (2) is neutral and power is not transmitted to the front wheel drive shaft (1).

■ Front Wheel Drive “Engaged”

When the front wheel drive lever is set to “Engaged” position, the 19T shifter gear (2) slides to the right to engage with 13T-25T gear shaft (5). Therefore, the power from spiral bevel pinion shaft (3) is transmitted to the front wheel drive shaft (1) through the gears.


- (1) Front Wheel Drive Shaft
- (2) 19T Shifter Gear
- (3) Spiral Bevel Pinion Shaft
- (4) 12T Gear
- (5) 13T-25T Gear Shaft

A : Front Wheel Drive
“Engaged”

W1014843

[4] DIFFERENTIAL GEAR SECTION

(1) Differential Gears



- (1) Differential Case
- (2) Differential Pinion
- (3) 37T Spiral Bevel Gear
- (4) 10T Final Gear Shaft
- (5) Differential Side Gear
- (6) Differential Pinion Shaft
- (7) 66T Final Gear
- (8) Differential Pinion
- (9) Differential Side Gear

W1018746

3TAAAHKP001A

1. During Straight Running

Rotation of the spiral bevel pinion is transmitted to the 37T spiral bevel gear (3), 10T final gear shaft (4), 66T final gear (7) and differential case (1).

When road resistance to the right and left wheels are equal, differential pinions (2), (8) and differential side gears (5), (9) all rotate as a unit. Both rear axles received equal input, and both wheels turn at the same speed, allowing the tractor to go straight ahead.


At this time, differential pinions (2), (8) do not rotate around the differential pinion shaft (6).

2. During Turning

When the tractor turns, the road resistance to the inside tire increases. In other words, if one of tires slows down, revolution difference is generated in the differential side gears (5), (9). When rotation of one differential side gear becomes lower than the other, differential pinions (2), (8) begin rotating around differential pinion shaft (6). The other differential side gear is increased in speed by the speed increment of differential pinion shaft (6). This means that rotation of one rear axle is slowed down and that of the other rear axle is increased. Thus, the tractor turn smoothly without power loss.

The combined number of revolutions of the right and left differential side gears is always twice that of the spiral bevel gear (3). When spiral bevel gear revolution is $100 \text{ min}^{-1} \text{ (rpm)}$, and if one of the differential side gears stops moving, the revolution of the other differential side gear becomes $200 \text{ min}^{-1} \text{ (rpm)}$ and if one rotates at $50 \text{ min}^{-1} \text{ (rpm)}$, the other rotates at $150 \text{ min}^{-1} \text{ (rpm)}$.

(2) Differential Lock



- (1) Rear Axle
- (2) Differential Lock Shifter
- (3) Differential Case
- (4) Differential Pinion
- (5) Rear Axle
- (6) Differential Lock Arm
- (7) Differential Lock Shaft
- (8) Differential Lock Shift Fork
- (9) Differential Side Gear
- (10) Differential Pinion Shaft
- (11) Differential Pinion


W1015160

When resistance to the right and left tires are greatly different due to ground conditions or type of work, the tire with less resistance slips and prevents the tractor from moving ahead. To compensate for this drawback, the differential lock restricts the differential action and causes both rear axles to rotate as a unit.

When the differential lock pedal is stepped on, it causes the differential lock arm (6) and differential lock shaft (7) to rotate, which will move the differential lock shift fork (8) and the differential lock shifter (2) toward the differential side gear (9). The pins on the differential lock shifter (2) go into the holes in the differential case (3) to cause the differential case (3), differential lock shifter (2) and differential side gear (9) to rotate as a unit.

Therefore, differential pinions (4), (11) are unable to rotate around differential pinion shaft (10) and identical revolutions are transmitted to the right and left rear axle (1), (5).

[5] BRAKE SECTION



- | | | | |
|--------------------|---------------------------|-------------------------------|----------------------|
| (1) Rear Axle (LH) | (7) Internal Cir-clip | (13) Brake Pedal | (19) Brake Wire (RH) |
| (2) Steel Ball | (8) Bearing | (14) Parking Brake Lock Pedal | (20) Brake Rod (RH) |
| (3) Actuator | (9) Brake Cam Lever (LH) | (15) Brake Wire (LH) | (21) Wire Arm |
| (4) Brake Disc | (10) O-ring | (16) Parking Brake Rod (RH) | |
| (5) Friction Plate | (11) Brake Cam Lever (RH) | (17) Parking Brake Wire | |
| (6) bearing Holder | (12) Rear Axle (RH) | (18) Emergency Brake Lever | |

A : Braked
B : Released

The mechanical wet disc brakes are used for the travelling brake. The brake is operated by the brake pedal (13) through the mechanical linkages and provide stable braking and require little adjustment.

The brake body is incorporated in the transmission case and axle cover filled with transmission oil.

For greater braking force, four brake discs (4) are provided at the rear axle, and the friction plates (5) fixed to the transmission case is arranged between the brake discs (4).

■ Travelling Brake

When the brake pedal (13) is depressed, the brake rod pulls the brake cam lever (9), (11).

Therefore, the cam plates also moves and rides on the steel balls set in the grooves of the transmission case to press the brake disc, the final gear shaft is braked by the frictional force generated by the cam plate and brake disc.

■ Parking Brake

When the parking brake is applied, the brake pedal (13) is locked by the parking brake lock pedal (14).

■ Emergency Brake


When the emergency brake is applied, the left brake and the right brake are braked by the brake wires (15), (17) and the wire arm (21).

When the emergency brake lever is pushed down, the left brake and the right are free.

Since the emergency brake is not linked to the parking brake lock pedal (14), the emergency brake is not locked by the parking brake lock pedal (14).

3. PTO SYSTEM

[1] PTO CLUTCH AND VALVE



3TAAAAHKP003A

- (1) PTO Select Gear
- (2) PTO Clutch Pack
- (3) Rear PTO Shaft
- (4) Transmission Case

- (5) PTO Clutch Valve
- (6) PTO Clutch Relief Valve
- (7) Oil Filter Cartridge

A : From HST Pump Shaft
B : To Mid-PTO


C : From Power Steering Controller
D : To Hydrostatic Transmission

The BX 50 series equipped with hydraulic independent PTO clutch (wet multi-plates type). Therefore, the engine power engages or disengages to the PTO shafts without stopping the tractor movement.

The PTO clutch pack (2) has four clutch discs, four drive plates, pressure plate, clutch piston and so on.

The clutch piston is actuated by hydraulic oil flow from the power steering controller.

The PTO clutch valve (5) controls the hydraulic oil flow from power steering controller to the PTO clutch pack (2) by operating the PTO clutch lever through the linkage.



PTO Clutch Relief Valve

The PTO clutch relief valve is provided to control the PTO operating pressure. When the oil pressure exceed the relief valve setting pressure, relief valve opens and the oil flows into PTO clutch and hydrostatic transmission.


(Reference)

- Relief valve setting pressure : 490 kPa
5.0 kgf/cm²
71.2 psi

- (1) Plug
- (2) O-ring
- (3) Spring
- (4) Poppet
- (5) PTO Clutch Valve
- (6) HST Charge Relief Valve
- (7) PTO Clutch Relief Valve

A : From Power Steering Controller
B : To Hydrostatic Transmission
C : To PTO Clutch Valve

W1015382



PTO Clutch "Engaged"


The oil from power steering controller flows into the PTO clutch valve.

When the PTO clutch lever is set at the "Engaged" position, the PTO clutch valve rotates. Oil flows from the oil line through transmission case to the PTO clutch pack.

Oil entering the clutch pack pushes the clutch piston (4) to engage the clutch pack. Power is transmitted from the HST pump shaft (1) through the PTO clutch to the clutch gear (2) and the PTO shafts.

- (1) HST Pump Shaft
 - (2) Clutch Gear
 - (3) Clutch Case
 - (4) Clutch Piston
 - (5) Clutch Plate
 - (6) Clutch Disc
 - (7) Spring
 - (8) Spline Boss
 - (9) O-ring
 - (10) Transaxle Case
 - (11) Brake Disc
- A : From PTO Clutch Valve**
B : Power to PTO Shaft
C : PTO Clutch "Engaged"

W1015610



■ PTO Clutch “Disengaged”

When the PTO clutch lever is set at the “Disengaged” position, the PTO clutch valve closes the oil passage to the PTO clutch pack. The oil in the PTO clutch pack drain into the transaxle case (10). Thus the clutch piston (4) is pushed back by the spring (7).


When the clutch piston (4) is pushed back by the spring (7), the brake plate (11) is also moved to contract the brake disc (12) so as to stop the rotation and drag of the PTO shafts.

- | | |
|--------------------|---------------------|
| (1) HST Pump Shaft | (9) O-ring |
| (2) Clutch Gear | (10) Transaxle Case |
| (3) Clutch Case | (11) Brake Plate |
| (4) Clutch Piston | (12) Brake Disc |
| (5) Clutch Plate | |
| (6) Clutch Disc | |
| (7) Spring | |
| (8) Spline Boss | |

C : PTO Clutch “Disengaged”

W1015793

[2] MID AND REAR PTO SECTION



(1) HST Pump Shaft
(2) 12T Clutch Gear
(3) PTO Clutch Pack

(4) Rear PTO Shaft
(5) 23T Mid PTO Gear

(6) 24T Mid PTO Idle Gear
(7) Mid-PTO Shaft

(8) 28T PTO Select Gear
(9) 11T Gear Shaft

Three kinds of power flow are selected by operating the PTO select lever to shift the PTO select gear (8) on the 11T gear shaft (9).

■ Mid-PTO Position (A)

PTO Clutch Pack (3) → 12T Gear Clutch (2) → PTO Select Gear (8) → 23T Mid PTO Gear (5) → 24T Mid PTO Idle Gear (6) → Mid-PTO Shaft (7).

■ Rear PTO Position (B)


PTO Clutch Pack (3) → 12T Gear Clutch (2) → PTO Select Gear (8) → 11T Gear Shaft (9) → Rear PTO Shaft (4).

■ Mid and Rear PTO Position

A and B at the same time.

4. OTHERS

[1] HYDRAULIC PUMP DRIVE GEAR SECTION



- (1) HST Pump Shaft
- (2) Spline Boss
- (3) Idle Gear
- (4) Hydraulic Pump Drive Gear Shaft
- (5) Hydraulic Pump Drive Gear
- (6) Hydraulic Pump Drive Gear Shaft
- (7) Hydraulic Pump
- (8) Flow Priority Valve
- (9) Relief Valve (3P Hitch)
- (10) Transmission Case

W1016433

3TAAAFKP014A

The hydraulic pump (7) is mounted to the transmission case (10) and driven by the hydraulic pump drive gear (5). The spline boss (2) mounted on the HST pump shaft drives the hydraulic pump drive gear (5) mounted on the hydraulic pump drive gear shaft (4) through the idle gear (3).

SERVICING

CONTENTS

1. TROUBLESHOOTING	2-S1
2. SERVICING SPECIFICATIONS	2-S5
3. TIGHTENING TORQUES	2-S7
4. CHECKING, DISASSEMBLING AND SERVICING.....	2-S8
[1] CHECKING AND ADJUSTING	2-S8
[2] PREPARATION	2-S16
(1) Separating Transaxle	2-S16
[3] DISASSEMBLING AND ASSEMBLING.....	2-S25
(1) Hydrostatic Transmission.....	2-S25
(2) Hydraulic Cylinder	2-S31
(3) HST Front Cover	2-S32
(4) Hydraulic Pump Assembly	2-S33
(5) Rear PTO Cover Assembly.....	2-S34
(6) Rear Axle	2-S35
(7) Transmission Case Shafts	2-S39
[4] SERVICING	2-S43
(1) Hydrostatic Transmission.....	2-S43
(2) Transaxle Case	2-S45

1. TROUBLESHOOTING

HYDROSTATIC TRANSMISSION

Symptom	Probable Cause	Solution	Reference Page
System Will Not Operate in Either Direction	Oil level is low	Check oil level or fill oil to proper level	G-13
	Speed control pedal linkage defective	Repair linkage	2-S18
	Charge pressure is too low	Solution order 1. Replace oil filter cartridge	G-13
		2. Check charge pressure	2-S12
		3. Inspect or flush charge relief valve	2-S43
	Check and high pressure relief valve does not move smoothly	Inspect or replace check and high pressure relief valve	2-S43
	Component parts defective	Replace hydrostatic transmission assembly	2-S27
Vibration and Noise	Oil level is too low	Check oil level or fill oil to proper level	G-13
	Speed control pedal linkage defective	Repair linkage	2-M8
	Charge pressure is too low	Solution order 1. Replace oil filter cartridge	G-13
		2. Check charge pressure	2-S12
		3. Inspect or flush charge relief valve	2-S43
	Check and high pressure relief valve does not move smoothly	Inspect or replace check and high pressure relief valve	2-S43
	Component part is defective	Replace hydrostatic transmission assembly	2-S27

W1022927

HYDROSTATIC TRANSMISSION (Continued)

Symptom	Probable Cause	Solution	Reference Page
Loss of Power	Oil level is low	Check oil level or fill oil to proper level	G-13
	Speed control pedal linkage defective	Repair linkage	2-M8
	Charge pressure is too low	1. Replace oil filter cartridge	G-13
		2. Check charge pressure	2-S12
		3. Inspect or flush charge relief valve	2-S43
	Check and high pressure relief valve does not move smoothly	Inspect or replace check and high pressure relief valve	2-S43
	Component parts defective	Replace hydrostatic transmission assembly	2-S27
Transmission Oil Over Heats	Low transmission oil level	Fill transmission oil level up to proper level	G-13
	Radiator net clogged	Clean radiator net	—
	Excessive machine load	Reduce machine load	—
	Improper charge pressure	1. Check high relief pressure	2-S12
		2. Replace transmission oil filter cartridge	G-13
		3. Replace check and high pressure relief valve	2-S43
		4. Inspect and replace charge relief valve	2-S43
Machine Will Not Stop in Neutral Position	Speed control linkage is out of adjustment or sticking	Repair or replace linkage	2-M8
		Adjust neutral position	2-S10
System Operates in One Direction Only	Speed control linkage defective	Repair or replace linkage	2-M8
	Check and high pressure relief valve defective	Replace check and high pressure relief valve	2-S43

W1026435

TRAVELLING GEAR SHIFT SECTION

Symptom	Probable Cause	Solution	Reference Page
Noise from Transmission	Transmission oil insufficient	Refill	2-S16
	Gear worn or broken	Replace	–
	Bearings worn	Replace	–
Gear Slip Out of Mesh	Shift fork spring tension insufficient	Replace	2-S39
	Shift fork or shifter worn	Replace	2-S39
	Shift fork bent	Replace	2-S39

W1013580

DIFFERENTIAL GEAR SECTION

Symptom	Probable Cause	Solution	Reference Page
Excessive or Unusual Noise at All Time	Improper backlash between spiral bevel pinion and bevel gear	Adjust	2-S48
	Improper backlash between differential pinion and differential side gear	Adjust	2-S48
	Bearing worn	Replace	–
	Insufficient or improper type of transmission fluid used	Replenish or change	G-7, 2-S16
Noise while Turning	Differential pinions or differential side gears worn or damaged	Replace	2-S35, 2-S39
	Differential lock binding (does not disengaged)	Replace	2-S36
	Bearing worn	Replace	–
Differential Lock Can Not Be Set	Differential lock shift fork damaged	Replace	2-S36
	Differential lock shifter mounting pin damaged	Replace	2-S36
	Differential lock pin damaged	Replace	2-S36
Differential Lock Pedal Does Not Return	Differential lock pedal return spring weaken or damaged	Replace	2-S23
	Differential lock fork shaft rusted	Repair	2-S36

W1013718

BRAKE SECTION

Symptom	Probable Cause	Solution	Reference Page
Brake Drags	Brake pedal free travel too small	Adjust	G-23
	Ball holes of actuator for uneven wear	Replace	2-S49
	Brake pedal return spring weaken or broken	Replace	2-S23
	Brake cam rusted	Repair	2-S38
Poor Braking Force	Brake pedal free travel excessive	Adjust	G-23
	Brake disc worn	Replace	2-S38
	Actuator warped	Replace	2-S38
	Brake cam or lever damaged	Replace	2-S38
	Transmission fluid improper	Change	2-S16

W1010878

PTO SECTION

Symptom	Probable Cause	Solution	Reference Page
PTO Clutch Slip	Operating pressure is low	Check	2-S15
	PTO clutch valve malfunctioning	Repair or replace	2-S25
	Clutch disc or drive plate excessively worn	Replace	2-S40
	Deformation of clutch piston	Replace	2-S40
PTO Shaft Does Not Rotate	PTO clutch malfunctioning	Repair or replace	2-S40
PTO Clutch Operating Pressure is Low	Transmission oil improper or insufficient	Replenish or change	2-S16
	Relief valve malfunctioning	Check or replace	2-M16
PTO Clutch Drags	Brake plate excessive worn	Replace	2-S40
	Clutch spring weaken or broken	Replace	2-S40
	Deformation of pressure plate or steel plate	Replace	2-S40

W1011002

2. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Charge Relief Valve [Oil temperature at 50 °C, 122 °F]	Setting Pressure	0.55 to 0.75 kPa 5.6 to 7.7 kgf/cm ² 79.8 to 108.8 psi	—
High Pressure Relief Valve (Forward and Reverse) [Oil temperature at 50 °C, 122 °F]	Setting Pressure	19 to 22 MPa 193.8 to 224.4 kgf/cm ² 2775 to 3190 psi	
PTO Clutch	Operating Pressure	1.0 to 1.3 MPa 10.2 to 13.3 kgf/cm ² 145.0 to 188.5 psi	
PTO Clutch Disc	Thickness	1.50 to 1.70 mm 0.060 to 0.066 in.	1.35 mm 0.053 in.
Separate Plate	Thickness	0.945 to 1.055 mm 0.0373 to 0.0413 in.	0.80 mm 0.0310 in.
Back Plate	Thickness	1.9 to 2.1 mm 0.075 to 0.082 in.	1.85 mm 0.073 in.
Clutch Piston	Flatness	—	0.15 mm 0.0059 in.
Pressure Plate and Steel Plate	Flatness	—	0.20 mm 0.0079 in.
Clutch Spring	Free Length	38.5 mm 1.52 in.	34.5 mm 1.36 in.
PTO Brake Disc	Thickness	2.9 to 3.1 mm 0.115 to 0.122 in.	2.70 mm 0.106 in.
PTO Brake Plate	Thickness	1.9 to 2.1 mm 0.075 to 0.082 in.	1.85 mm 0.073 in.
Differential Case to Differential Side Gear	Clearance	0.050 to 0.151 mm 0.0020 to 0.0059 in.	0.30 mm 0.0118 in.
Differential Case	I.D.	38.000 to 38.062 mm 1.4961 to 1.4985 in.	—
Differential Side Gear	O.D.	37.911 to 37.950 mm 1.4926 to 1.4941 in.	—
Differential Pinion Shaft to Differential Pinion	Clearance	0.080 to 0.122 mm 0.0031 to 0.0048 in.	0.30 mm 0.0118 in.
Differential Pinion	I.D.	20.060 to 20.081 mm 0.7898 to 0.7906 in.	—
Differential Pinion Shaft	O.D.	19.959 to 19.980 mm 0.7858 to 0.7866 in.	—

W1013874

(Continued)

Item		Factory Specification	Allowable Limit
Differential Pinion to Differential Side Gear	Backlash	0.15 to 0.30 mm 0.0059 to 0.0118 in.	0.40 mm 0.0157 in.
Spiral Bevel Pinion Shaft to Spiral Bevel Gear	Backlash	0.10 to 0.30 mm 0.0039 to 0.0118 in.	—
Actuator and Bearing Holder	Flatness	—	0.30 mm 0.0118 in.
Cam Plate and Ball	Height	22.89 to 22.99 mm 0.9012 to 0.9051 in.	22.40 mm 0.8819 in.
Brake Disc	Thickness	3.3 to 3.5 mm 0.130 to 0.138 in.	3.0 mm 0.118 in.
Friction Plate	Thickness	1.92 to 2.08 mm 0.0756 to 0.0819 in.	1.52 mm 0.0598 in.

W1033005

3. TIGHTENING TORQUES



Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-8.)

Item	N·m	kgf·m	lbf·ft
Charge relief valve checking plug (R 1/4)	29 to 44	3.0 to 4.5	21.4 to 32.5
Hexagon socket head plug (R 1/4)	29 to 44	3.0 to 4.5	21.4 to 32.5
Check and high pressure valve screw	2.5 to 3.0	0.26 to 0.31	1.8 to 2.2
PTO clutch operating pressure plug (R 1/8)	13 to 22	1.3 to 2.2	9.6 to 16.2
ROPS mounting nut	124 to 147	12.6 to 15.0	91.2 to 108
Fuel tank stay mounting bolt and nut	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Fender bracket mounting bolt and nut	124 to 147	12.6 to 15.0	91.2 to 108
Rear wheel mounting screw	108.5 to 130.2	11.1 to 13.2	80 to 96
Hitch plate mounting bolt and nut	124 to 147	12.6 to 15.0	91.2 to 108
Transaxle assembly mounting screw (M12)	62.8 to 72.6	6.4 to 7.4	46.3 to 53.5
Transaxle assembly mounting screw (M14)	124 to 147	12.6 to 15.0	91.2 to 108
Rear coupling mounting screw (M8)	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2
Front coupling mounting screw (M8)	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2
HST fan mounting screw (M8)	9.8 to 11.3	1.0 to 1.2	7.2 to 8.3
Hydraulic control lever mounting bolt and nut	17.7 to 20.6	1.8 to 2.1	13.0 to 15.2
HST front cover mounting bolt and nut	18.0 to 21.0	1.8 to 2.1	13.3 to 15.5
Check and high pressure relief valve plug	29 to 44	3.0 to 4.5	21.4 to 32.5
Hydraulic cylinder mounting screw	39.2 to 44.1	4.0 to 4.5	28.9 to 32.5
Transaxle case front cover mounting bolt (M8)	29 to 34	3.0 to 3.5	21.4 to 25.1
Hydraulic pump assembly mounting bolt (M6)	8.0 to 9.0	0.8 to 0.9	5.9 to 6.6
Hydraulic pump assembly mounting bolt (M8)	18.0 to 21.0	1.8 to 2.1	13.3 to 15.5
Rear PTO cover mounting bolt (M8)	18.0 to 21.0	1.8 to 2.1	13.3 to 15.5
Rear axle case (RH) mounting bolt (M8)	18.0 to 21.0	1.8 to 2.1	13.3 to 15.5
66T final gear mounting screw	60.8 to 70.6	6.2 to 7.2	44.8 to 52.1

W1012736

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING



Adjusting Maximum Speed

■ Forward

- 1. Depress the speed control pedal (1) all the way and lengthen the stopper bolt (2) until it touches the speed control pedal (2).
- 2. Adjust the stopper bolt (2) length **A** to 17.0 mm (0.67 in.) and lock it securely.

■ Reverse

- 1. Adjust the stopper bolt (3) length **B** to 17.5 mm (0.69 in.) and lock it securely.




(Reference)

Stopper bolt length	Reference	Forward	17.0 mm 0.67 in.
		Reverse	17.5 mm 0.69 in.
Maximum speed	Reference	Forward	13.0 to 14.0 km/h 8.1 to 8.8 mph
		Reverse	10.0 to 11.0 km/h 6.3 to 6.9 mph

- (1) Speed Control Pedal
- (2) Stopper Bolt (Forward)
- (3) Stopper Bolt (Reverse)

A : Stopper Bolt Length (Forward)
B : Stopper Bolt Length (Reverse)

W1012590



Preparation before HST Adjustment



CAUTION

- **Park the machine on a firm and level ground.**
- 1. Place the wooden blocks at the front and the rear side of the wheels not to move the tractor.
- 2. Lift up the rear wheels (1) safely by the rigid jacks.
- 3. Shift the front wheel drive lever (2) to “OFF” position (A).
- 4. Remove the rear right wheel from the tractor.

- (1) Rear Wheel
- (2) Front Wheel Drive Lever
- (3) Neutral Adjuster
- (4) Lock Screw

(A) “OFF” Position

W1047776



Adjustment of HST Neutral Position

1. Start the engine.
2. Keep the engine at the maximum revolution.
3. Shift the range shift lever (1) to "Hi" position (B).
4. Loosen the locking screw (5).

■ NOTE

- When adjusting the HST neutral position, loosen the locking screw approximately 2 turns counterclockwise not to drop the nut inside.
- Make sure 4WD lever is 2WD before making adjustment.

(Forward to Neutral Position)

5. Depress the speed control pedal (3) to "Forward" speed position, and release the foot from the speed control pedal (3). Check that the rear axle (or the wheel) stops rotating. If the rear axle (or the wheel) does not stop rotating, move the position of the locking screw (5) to the machine front side to stop rotating.



(Reverse to Neutral Position)

6. Depress the speed control pedal (3) to "Reverse" speed position, and release the foot from the speed control pedal (3). Check the rear axle (or the wheel) stops rotating. If the rear axle (or the wheel) does not stop rotating, adjust the locking screw (5) to stop rotating.
7. After adjusting the neutral position, tighten the lock screw (5) securely.

- (1) Range Gear Shift Lever
- (2) Front Wheel Drive
- (3) Speed Control Pedal
- (4) Neutral Adjust Lever
- (5) Locking Screw
- (6) Screw Driver

- (A) 4WD "OFF" Position
- (B) "Hi" Position
- (C) FORWARD
- (D) REVERSE

W1012819



Checking and Adjusting HST Neutral Spring (for Dynamic Braking)

⚠ WARNING

- Do not operate if tractor move on level ground with foot off speed control pedal.
- If tractor moves on level ground with foot off the pedal, or, if the pedal is too slow in returning to “Neutral” position when removing the foot from the pedal, adjust the HST neutral spring.

The HST neutral spring located under the front right side of the fender can adjust returning speed of speed control pedal.

Since the HST neutral spring tension is weakened, the HST tension should be checked and adjusted every 100 hours.

1. Checking the HST neutral spring tension : Dynamic braking
 - Start the engine and hold the maximum engine speeds.
 - Operate the machine on the concrete level ground.
 - Shift the range gear shift lever to “High” position.
 - Depress the speed control pedal to “Forward”.
 - Release the foot from the speed control pedal.
 - Check the distance between the foot releasing point and the machine stopping point.
 - If the distance is more than approximately 3 m (9.8 feet), strengthen the HST neutral spring tension so that the machine will stop in approximately 3 m (9.8 feet) after releasing the foot from the speed control pedal.

(Reference)

Distance (L) between the foot releasing point and the machine stopping point	Reference	Approx. 3 m (9.8 feet)
--	-----------	------------------------

2. Remove the step from the machine.
 - Loosen the lock nut (2).
 - Turn the adjusting nut (3) half turn to pull the HST neutral spring (1).
 - Tighten and lock the lock nut (2).
 - Start the engine and check dynamic brake as mentioned former.
 - If the machine will not stop with dynamic brake in approximately 3 m (9.8 feet), adjust the neutral spring again.


(Reference)

Length (M) of adjusting rod at shipping the machine from the factory	Reference	10 mm 0.39 in.
--	-----------	-------------------

- (1) HST Neutral Spring
(2) Lock Nut
(3) Adjusting Nut
(4) Adjusting Rod

- (A) Foot Releasing Point
(B) Machine Stopping Point
L : Distance between Foot Releasing Point and the Machine Stopping Point
M : Length of Adjusting Rod from Stay

W1079634



Charge Relief Pressure

⚠ CAUTION

- When checking, park the tractor on flat ground, and apply the parking brake.

1. Remove the plug (R 1/4) (1) from the front cover, then install the adaptor (R 1/4) and pressure gauge.
2. Set the range gear shift lever to “Neutral” position.
3. Start the engine and run it at the maximum speed.
4. Read the pressure gauge to measure the charge relief pressure.
5. If the measurement is not within the factory specifications, check the charge relief valve and related hydraulic components.

■ NOTE

- When reinstalling the hexagon socket head plug, apply liquid lock (Three Bond 1324 or its equivalent) to the plug.

Charge relief pressure	Factory specification (Oil temperature at 50 °C, 122 °F)	0.55 to 0.75 MPa 5.6 to 7.7 kgf/cm ² 79.8 to 108.8 psi
------------------------	--	---

Tightening torque	Charge relief pressure port plug (R 1/4)	29 to 44 N·m 3.0 to 4.5 kgf·m 21.4 to 32.5 lbf·ft
-------------------	---	---

(1) Plug

W1013009



High Relief Pressure (Forward)

⚠ CAUTION

- When checking, park the tractor on flat ground, and apply the parking brake.

1. Remove the hexagon socket head plug (R 1/4) from P2 (2), then install the adaptor, cable and pressure gauge.
2. Start the engine and run it at maximum speed.
3. Set the range gear shift lever to “Hi” position.
4. Depress the speed control pedal to “Forward”, and read the pressure gauge to measure the high relief pressure.
5. If the measurement is not same as factory specification, check the high pressure relief valve and related hydraulic components.

High relief pressure (Forward)	Factory specification (Oil temperature at 50 °C, 122 °F)	19 to 22 MPa 193.8 to 224.4 kgf/cm ² 2755 to 3190 psi
-----------------------------------	--	--

Tightening torque	Hexagon socket head plug (P1 and P2 port)	29 to 44 N·m 3.0 to 4.5 kgf·m 21.4 to 32.5 lbf·ft
-------------------	--	---

■ IMPORTANT

- Measure quickly so that the high pressure relief valve may not be in operation more than 10 seconds.


■ NOTE


- When reinstalling the hexagon socket head plug, apply liquid lock (Three Bond 1324 or its equivalent) to the plug.

(1) P1 Port (Reverse)

(2) P2 Port (Forward)

W1013275





High Relief Pressure (Reverse)

⚠ CAUTION

- When checking, park the tractor on flat ground, and apply the parking brake.
1. Remove the hexagon socket head plug (R 1/4) from **P1** (1), then install the adaptor, cable and pressure gauge.
 2. Start the engine and run it at maximum speed.
 3. Set the range gear shift lever to “Hi” position.
 4. Depress the speed control pedal to “Reverse”, and read the pressure gauge to measure the high relief pressure.
 5. If the measurement is not same as factory specification, check the high pressure relief valve and related hydraulic components.

High relief pressure (Reverse)	Factory specification (Oil temperature at 50 °C, 122 °F)	19 to 22 MPa 193.8 to 224.4 kgf/cm ² 2755 to 3190 psi
--------------------------------	--	--

Tightening torque	Hexagon socket head plug (P1 and P2 port)	29 to 44 N·m 3.0 to 4.5 kgf·m 21.4 to 32.5 lbf·ft
-------------------	---	---

■ IMPORTANT

- Measure quickly so that the high pressure relief valve may not be in operation more than 10 seconds.




■ NOTE

- When reinstalling the hexagon socket head plug, apply liquid lock (Three Bond 1324 or its equivalent) to the plug.

(1) P1 Port (Reverse)

(2) P2 Port (Forward)

W1040164



Readjustment of Relief Valve (When the HST does not Work Due to its Loose Hexagon Socket Head Screw)

■ IMPORTANT

- KUBOTA does not recommend the readjustment of relief valve. KUBOTA recommends with genuine parts.
- As the HST may be damaged if the pressure is set to high by mistake, be careful when adjusting it.

■ NOTE

- The relief pressure is set in between 33.3 to 36.3 MPa (340 to 370 kgf/cm², 4836 to 5262 psi) when shipped from the factory. But, for the purpose of after-sales services, as it is impossible to reset the pressure precisely as set in the factory, its setting range is defined as a slightly wider range between 31.4 to 35.3 MPa (320 to 360 kgf/cm², 4551 to 5120 psi)
1. Measure the pre-adjustment distance **A**.
 2. Compress the spring of the relief valve with a relief valve assembling tool (3).
 3. Then, find the distance **A** by turning the poppet (4) with a screwdriver.
- Reference: The distance **A** changes by about 0.5 mm (0.0197 in.) per one turn of the poppet (4).
4. Repeat the same operation a few times to find the distance **A** as it is difficult to acquire at the first time.
 5. After finding the distance **A**, hold the setscrew (6) to a vice and fasten the hexagon socket head screw (2) with specified torque. On this occasion, use a copper plate, etc. for the vice jaws not to damage the setscrew (6).
 6. Install the relief valve in the HST.
 7. Check the relief pressure as indicated in page 2-S6 and 2-S7.
- The distance **A** is for refresh only. Make sure to check the relief pressure after readjustment.
8. If the relief pressure does not fall within the readjustment pressure range, repeat the processes of the above.
- Reference: The pressure changes by 1.47 MPa (15 kgf/cm², 213.3 psi) per 0.1 mm (0.0039 in.) in distance **A**

Tightening torque	Hexagon socket head screw	2.5 to 3.0 N·m 0.26 to 0.31 kgf·m 1.8 to 2.2 lbf·ft
-------------------	---------------------------	---

Relief valve readjusting pressure	Factory specification	19 to 22 MPa 193.8 to 224.8 kgf/cm ² 2755 to 3190 psi
-----------------------------------	-----------------------	--


Distance A of relief valve (Forward)	Reference value	39.1 to 39.2 mm 1.5394 to 1.5433 in.
Distance A of relief valve (Reverse, ϕ 1.5 mm orifice)		38.6 to 38.7 mm 1.5197 to 1.5236 in.

- (1) Relief Valve Assembly
(2) Hexagon Socket Head Screw
(3) Relief Valve Assembling Tool
(4) Poppet

- (5) Valve Seat
(6) Setscrew

A : Distance

W1082809



PTO Clutch Operating Pressure

⚠ CAUTION

- When checking, park the tractor on flat ground, apply the parking brake.
1. Lift the rear of the tractor and remove the left rear wheel.
 2. Remove the plug (R 1/8), then install the adaptor (R 1/8), cable and pressure gauge.
 3. Start the engine and set at maximum speed.
 4. Move the PTO clutch lever to “**Engaged**” position, and measure the pressure.
 5. If the measurement is not same as factory specifications, check the PTO relief valve and related hydraulic components.

■ IMPORTANT

- Do not connect the universal joint of the implement to the mid and rear PTO shaft.

■ NOTE

- When reinstall the hexagon socket head plug, apply liquid lock (Three Bond 1324 or its equivalent) to the plug.

PTO clutch operating pressure	Factory specification	1.0 to 1.3 MPa 10.2 to 13.3 kgf/cm ² 145.0 to 188.5 psi
-------------------------------	-----------------------	--

Tightening torque	PTO clutch valve plug (R 1/8)	13 to 22 N·m 1.3 to 2.2 kgf·m 9.6 to 16.2 lbf·ft
-------------------	-------------------------------	--

Condition

- Engine speed : Maximum
- Oil temperature : 45 to 55 °C (113 to 131 °F)

W1013552



Brake Pedal Free Travel

See page G-23.

W1013715

[2] PREPARATION

(1) Separating Transaxle



Draining Transmission Fluid

CAUTION

- Be sure to stop the engine before checking and changing the transmission fluid.

1. Place oil pan under the tractor.
2. Remove the drain plug (1) at the bottom of the transmission case.
3. Drain the transmission fluid and reinstall the drain plug.

(When refilling)

- Fill new oil from filling port after removing the filling plug (2) up to the upper notch on the dipstick (3).
- After running the engine for few minutes, stop it and check the oil level again, if low, add oil to prescribed level.

IMPORTANT


- Use only multi-grade transmission oil. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7.)
- Never work the tractor immediately after changing the transmission oil. Keeping the engine at medium speed for a few minutes to prevents damage to the transmission.
- Do not mix different brands oil together.

Transmission fluid capacity	11.6 L 3.1 U.S.gals 2.6 Imp.gals
-----------------------------	--

- (1) Drain Plug
(2) Filling Plug
(3) Dipstick

(A) Oil level is acceptable within this range

W1014039



Battery

CAUTION


- When disconnecting the battery cables, disconnect the negative cable from the battery first. When connecting, connect the positive cable to the battery first.

1. Remove the under panel.
2. Disconnect the negative cable (2) from the battery.
3. Disconnect the positive cable (3) from the battery (1) and remove the battery (1).

- (1) Battery
(2) Negative Cable

(3) Positive Cable

W1032888




Lift Rod and Lower Link

1. Remove the top link (2).
2. Remove the stopper pin (6) and remove the check chain plate (3).
3. Move the bushes (8) to inside.
4. Move the shaft (9) to right side and remove the lower link as a unit.

- | | |
|-----------------------|-------------------|
| (1) Lift Rod LH | (6) Stopper Pin |
| (2) Top Link | (7) Lower Link LH |
| (3) Check Chain Plate | (8) Bush |
| (4) Lift Rod RH | (9) Shaft |
| (5) Lower Link RH | |

W1045015



Roll-Over Protective Structures (ROPS)


1. Disconnect the lead wires from the combination lamp (2), (4) and the beacon switch (5).
2. Remove the ROPS mounting nuts, and remove the ROPS (1).

(When reassembling)

Tightening torque	ROPS mounting nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.2 to 108 lbf·ft
-------------------	-------------------	--

- | | |
|--------------------------|--------------------------|
| (1) ROPS | (4) Combination Lamp, LH |
| (2) Beacon Light | (5) Beacon Switch |
| (3) Combination Lamp, RH | |

W1014508






Seat

1. Remove the snap pins(2) to remove the seat (1).
2. Remove the seat (1).

(1) Seat

(2) Snap Pin

W1014409



Speed Control Pedal and Step


1. Remove the valve covers (3).
2. Remove the speed control pedals (1) and step (2).

(1) Speed Control Pedal

(3) Valve Cover

(2) Step

W1014726



Lever Grips and Fender

1. Remove the lever grips (2). Remove the emergency brake lever stay.
2. Remove the lowering speed adjusting knob (5) and the cutting height adjusting dial knob (4).
3. Disconnect the DC outlet (6).
4. Remove the fender (1) with the lever guide (3).

(1) Fender

(2) Lever Grip


(3) Lever Guide

(4) Cutting Height Adjusting Dial Knob

(5) Lowering Speed Adjusting Knob

(6) DC Outlet

W1014865



Fuel Tank

1. Drain the fuel, and remove the seat mat (2).
2. Disconnect the lead wire from fuel level sensor and fuel hoses from the fuel tank (1).
3. Remove the fuel tank stays (3), (4) and cushions, then remove the fuel tank (1).




(When reassembling)

Tightening torque	Fuel tank stay mounting bolt and nut	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 lbf·ft
-------------------	--------------------------------------	---

- (1) Fuel Tank
(2) Seat Mat

- (3) Fuel Tank Stay, LH
(4) Fuel Tank Stay, RH

W1015094



Rear Wheel

1. Remove the rear wheels (1) (2).






(When reassembling)

Tightening torque	Rear wheel mounting bolt	108.5 to 130.2 N·m 11.1 to 13.2 kgf·m 80 to 96 lbf·ft
-------------------	--------------------------	---

- (1) Rear Wheel, LH

- (2) Rear Wheel, RH

W1014976



Fender Bracket, Hitch Plate

- 1. Remove the lower brackets (1) (2).
- 2. Remove the hitch plate (4).
- 3. Remove the fender brackets (3) (5).

(When reassembling)

- Do not firmly tighten all screws, bolts and nuts until most components are attached.

Tightening torque	Hitch plate mounting bolt and nut (M14)	124 to 147 N·m 12.6 to 15.0 kgf·m 91.2 to 108 lbf·ft
	Fender bracket mounting bolt and nut (M14)	124 to 147 N·m 12.6 to 15.0 kgf·m 91.2 to 108 lbf·ft

- (1) Lower Bracket, RH

(2) Lower Bracket, LH

(3) Fender Bracket, LH
- (4) Hitch Plate

(5) Fender Bracket, RH



W1024983

Auxiliary Control Valve

- 1. Remove the auxiliary control valve mounting bolt (1).
- 2. Remove the auxiliary control valve (2) as an assembly.

- (1) Auxiliary Control Valve
- (2) Mounting Bolt

W1030037






Transaxle Assembly (Linkage and Loader Pipes)

1. Disconnect the brake rod and the brake wire, LH (1).
2. Disconnect the differential lock rod (2) and disconnect the mower link (5).
3. Disconnect the loader pipes (6).
4. Disconnect the brake rod and the brake wire, RH (7).

Tightening torque	Transaxle assembly mounting bolt (M12)	62.8 to 72.6 N·m 6.4 to 7.4 kgf·m 46.3 to 53.5 lbf·ft
	Transaxle assembly mounting bolt (M14)	124 to 147 N·m 12.6 to 15.0 kgf·m 91.2 to 108 lbf·ft

- | | |
|--|----------------------------------|
| (1) Brake Rod and Brake Wire, LH | (5) Mower Link |
| (2) Differential Lock Rod | (6) Loader Pipe |
| (3) Transaxle Assembly Mounting Bolt (M12) | (7) Brake Rod and Brake Wire, RH |
| (4) Transaxle Assembly Mounting Bolt (M14) | |

W1016000



Transaxle Assembly (Propeller Shaft, Pipe, Speed Control Rod and 4WD Shaft Coupling)

- 1. Remove the propeller shaft coupling bolt (3) pushing the coupling (1).
- 2. Disconnect the pipe (3).
- 3. Disconnect the speed control rod (4).
- 4. Disconnect the 4WD shaft coupling (5).
- 5. Remove the transaxle assembly mounting bolts.

(When reassembling)

- Tighten the smaller bolt (M12) first.
- Before mounting the transaxle assembly on the tractor main frame, check the flatness of the frame brackets with a straight edge securely.

Tightening torque	Propeller shaft coupling bolt (M8)	9.8 to 11.3 N·m 1.0 to 1.2 kgf·m 7.2 to 8.3 lbf·ft
	Transaxle assembly mounting bolt (M12)	62.8 to 72.6 N·m 6.4 to 7.4 kgf·m 46.3 to 53.5 lbf·ft
	Transaxle assembly mounting bolt (M14)	124 to 147 N·m 12.6 to 15.0 kgf·m 91.2 to 108 lbf·ft

- (1) Coupling

(2) Coupling Bolt




(3) Pipe

(4) Speed Control Rod

(5) Coupling

(6) 4WD Shaft

W1031849



Brake Pedal and Propeller Shaft

1. Unhook the brake spring (2) and the split pin (2).
2. Removing the spring pin (7) from the brake pedal (1). Remove the joint pin (9) and remove the brake pedal (1).
3. Disconnect the front coupling (10) from the engine.
4. Remove the propeller shaft assembly.
5. Remove the HST fan from the propeller shaft.

(When reassembling)

- Apply grease to inside of the front coupling and the rear coupling.

Tightening torque	Front coupling mounting bolt (M8)	23.5 to 27.4 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 lbf·ft
	HST fan mounting bolt (M8)	9.8 to 11.3 N·m 1.0 to 1.2 kgf·m 7.2 to 8.3 lbf·ft

- | | |
|-------------------|---------------------|
| (1) Brake Pedal | (7) Split Pin |
| (2) Split Pin | (8) Brake Arm |
| (3) Brake Spring | (9) Joint Pin |
| (4) Brake Rod, RH | (10) Front Coupling |
| (5) Bush | (11) Rear Coupling |
| (6) Brake Rod, LH | (12) HST Fan |


W1016476

Differential Lock Pedal

1. Remove the differential lock return spring (1).
2. Remove the rue ring cotter (3).
3. Turn and remove the differential lock pedal (2).

- | | |
|-----------------------------|---------------------------|
| (1) Spring | (3) Rue Ring Cotter |
| (2) Differential Lock Pedal | (4) Differential Lock Rod |

W1016728




Speed Control Pedal, HST Dumper and Cruise Control Rod

1. Remove the speed control pedal (1).
2. Remove the rue ring cotter (4).
3. Remove the HST dumper (2).
4. Remove the cruise upper rod (7).
5. Remove the spring (6) and the cruise rod (5).
6. Remove the cruise lock (8).




- | | |
|-------------------------|----------------------|
| (1) Speed Control Pedal | (5) Cruise Rod |
| (2) HST Dumper | (6) Spring |
| (3) HST Pedal Link | (7) Cruise Upper Rod |
| (4) Rue Ring Cotter | (8) Cruise Rock |

W1016858



[3] DISASSEMBLING AND ASSEMBLING

(1) Hydrostatic Transmission



Levers

1. Tap out the spring pin from the range gear shift lever, PTO select lever and front wheel drive lever, then remove levers.

(1) Levers

W1017118

4WD Detent Ball

1. Before disassembling the transaxle assembly, remove the plug (2), the spring (3) and the 4WD detent ball (4).

■ NOTE

- If you forget to remove the 4WD detent ball before disassembling the transaxle assembly, the 4WD detent ball will drop into the case.

(1) 4WD Lever Arm
(2) Plug

(3) Spring
(4) 4WD Detent ball

W1034488

PTO Clutch Valve

1. Remove the stopper (1).
2. Draw out the PTO clutch valve (2) from the transaxle assembly.





(When reassembling)

1. Clean the oil passages (4).
2. Apply the transmission fluid to the O-rings (3).

(1) Stopper
(2) PTO Clutch Valve

(3) O-ring
(4) Oil Passage

W1086372



Oil Cooler Cover

1. Remove the oil cooler cover.

(When reassembling)

- 1. Do not damage the O-ring (5).
- 2. Tighten the HST mounting bolts and the nut to the factory specifications.

Tightening torque	Oil cooler cover mounting bolt (M8)	18.0 to 21.0 N·m 1.8 to 2.1 kgf·m 13.3 to 15.5 lbf·ft
	Oil cooler cover mounting nut (M8)	18.0 to 21.0 N·m 1.8 to 2.1 kgf·m 13.3 to 15.5 lbf·ft






- (1) Oil Cooler Cover

(2) Transaxle Assembly

(3) Nut
- (4) Bolt

(5) O-ring

W1086612



Center Section and Valve Plates

1. Remove the center section (1).
2. Remove the valve plates (2) (3).

(When reassembling)

1. Check the direction of the groove (4).
2. Install the valve plates (2) (3) to the anchor pins (5) securely.
3. Install the groove (6) of the valve plate (pump plate) to the engine side.

- | | |
|-------------------------------|----------------|
| (1) Center Section | (4) Groove |
| (2) Valve Plate (Pump Shaft) | (5) Anchor Pin |
| (3) Valve Plate (Motor Shaft) | (6) Groove |

W1086956

Check and High Pressure Relief Valve Plug


1. Remove the check and high pressure relief plug (G 1/2).

(When reassembling)

Tightening torque	Check and high pressure relief valve plug (G 1/2)	59.0 to 78.0 N·m 6.0 to 8.0 kgf·m 43.5 to 57.5 lbf·ft
-------------------	---	---

- | | |
|--------------------|----------|
| (1) Center Section | (3) Plug |
| (2) Plug | |

W1087469



Check and High Pressure Relief Valve

1. After removing the plug (1), draw out the spring (3) and the check and high pressure relief valve assembly (5) (6).
2. If the service is required, disassemble the check and high pressure relief valve (5), (6).

(When reassembling)

- Take care not to damage the O-ring (2) on the plug (1).
- Since there is an orifice (1.5 mm, 0.059 in.) in the check and relief valve body (reverse) (6), re-install the check and relief valve (5) (6) to their original positions.

Tightening torque	Check and high pressure relief valve screw	2.5 to 3.0 N·m 0.26 to 0.31 kgf·m 1.84 to 2.21 lbf·ft
-------------------	--	---

- (1) Plug





(2) O-ring

(3) Spring

(4) Shim

(5) Check and Relief Valve (Forward)

(6) Check and Relief Valve (Reverse)
- W1087625



Cylinder Block

1. Remove the gasket (1).
2. Remove the O-ring (2).
3. Remove the cylinder block assembly (4) (5) from the transaxle.

(When reassembling)

- Turn the disassembling and the assembling stand vertically.
- Install the cylinder block assembly (4) (5) to the shafts not to drop the pistons from the cylinder block assembly (4) (5) carefully.

- (1) Gasket
(2) O-ring
(3) Pump Shaft

- (5) Cylinder Block Assembly (Pump Side)
(6) Cylinder Block Assembly (Motor Side)

W1087850

Cylinder Block and Piston

1. Remove the piston (3) and the spring (2) from the cylinder block (1).

(When reassembling)

- Apply clean transmission oil to the cylinder block and the piston.


■ NOTE

- Take care not to damage the surface of the cylinder block and the piston.

- (1) Cylinder Block
(2) Spring

- (3) Piston

W1088078



Swashplate and Thrust Roller Bearing





1. Remove the cir-clip (6) from the pump shaft (3) and the motor shaft (1).
2. Remove the thrust bearing (2).
3. Remove the swashplate (5) and the thrust roller bearing (4).



(When reassembling)

- Apply clean transmission oil to the cradle bearing and the trunnion arm.
- Hold the slot guide with a minus screw driver.
- Apply clean transmission oil to the thrust roller bearing.

- | | |
|---------------------------|--------------------|
| (1) Motor Shaft | (5) Swashplate |
| (2) Thrust Roller Bearing | (6) Cir-Clip |
| (3) Pump Shaft | (7) Slot Guide |
| (4) Thrust Roller Bearing | (8) Cradle Bearing |

W1088366





Neutral Arm and Trunnion Arm

1. Disconnect the neutral spring(2) from the HST front cover.
2. Loosen the neutral adjuster (5).
3. Remove the external cir-clip (7).
4. Remove the bolts (1).
5. Remove the neutral adjuster (5) and the neutral arm (3).
6. Remove the trunnion arm (6).




(When reassembling)

- Adjust the HST neutral position. Refer to “**Checking and Adjusting**” section.

- | | |
|--------------------|-----------------------|
| (1) Bolt | (5) Neutral Adjuster |
| (2) Neutral Spring | (6) Trunnion Arm |
| (3) Neutral Arm | (7) External Cir-clip |
| (4) Lock Screw | |

W1088807

(2) Hydraulic Cylinder



Hydraulic Cylinder

1. Disconnect the delivery pipe (1).
2. Remove the hydraulic cylinder mounting bolts (3).
3. Remove the hydraulic cylinder (2).

(When reassembling)






- Apply liquid gasket (Three Bond 1208D or equivalent) to the joint surface of the transaxle case to the hydraulic cylinder.

Tightening torque	Hydraulic cylinder mounting bolt	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 28.9 to 32.5 lbf·ft
-------------------	----------------------------------	---

- | | |
|------------------------|----------|
| (1) Delivery Pipe | (3) Bolt |
| (2) Hydraulic Cylinder | |

W1089147

(3) HST Front Cover



HST Front Cover

- 1. Remove the cir-clip (8) from the HST pump shaft (5).
- 2. Remove the cir-clip (9) from the HST motor shaft (4).
- 3. Remove the HST front cover mounting bolt (7).
- 4. Remove the HST front cover (6).

(When assembling)

- Reinstall the adjusting shims (10) to the HST front cover (6).
- Do not damage the oil seals (11), (12)
- Apply liquid gasket (Three Bond 1208D or equivalent) to the joint surface of the transaxle case to the HST front cover.

Tightening torque	HST front cover mounting bolt (M10)	39.3 to 44.1 N·m 4.0 to 4.5 kgf·m
	HST front cover mounting nut (M10)	29.0 to 32.5 lbf·ft

- (1) Plug

(2) Spring

(3) HST Charge Valve

(4) HST Motor Shaft

(5) HST Pump Shaft

(6) HST Front Case
- (7) Bolt

(8) Cir-clip

(9) Cir-clip





(10) Shim

(11) Oil Seal

(12) Oil Seal

W1089420

(4) Hydraulic Pump Assembly



Hydraulic Pump Assembly

1. Remove the hydraulic pump assembly mounting bolt (2), (3).
2. Remove the hydraulic pump assembly (1) as an unit from the transaxle case.

(When reassembling)

- Apply transmission oil to the O-rings.
- Since the mounting bolt (2) is installed through the hydraulic pump to the transaxle case, bind the sealing tape to the mounting bolt (2) securely.

Tightening torque	Hydraulic pump assembly mounting bolt (M6)	8.0 to 9.0 N·m 0.8 to 0.9 kgf·m 5.9 to 6.6 lbf·ft
	Hydraulic pump assembly mounting bolt (M8)	18.0 to 21.0 N·m 1.8 to 2.1 kgf·m 13.3 to 15.5 lbf·ft

- (1) Hydraulic Pump

(2) Bolt (Through Bolt)

(3) Bolt





(4) O-ring
- (5) O-ring

(6) O-ring

(7) O-ring

W1089827

(5) Rear PTO Cover Assembly



Rear PTO Cover Assembly

1. Remove the rear PTO cover mounting bolts (1).
2. Remove the rear PTO cover (2).
3. Remove the rear PTO shaft (5) from the rear PTO cover (2).

(When reassembling)






- Pull the 11T PTO select shaft with the bearing approximately the bearing thickness.
- Apply liquid gasket (Three Bond 1208D or equivalent) to the joint surface of transaxle case to the rear PTO cover.
- Bind the vinyl tape to the rear PTO shaft not to damage the oil seal.

Tightening torque	Rear PTO cover mounting bolt (M8)	18.0 to 21.0 N·m 1.8 to 2.1 kgf·m 13.3 to 15.5 lbf·ft
-------------------	-----------------------------------	---

- | | |
|--------------------------|--------------------|
| (1) Bolt | (5) Rear PTO Shaft |
| (2) Rear PTO Cover | (6) Oil Seal |
| (3) Bearing | (7) Vinyl Tape |
| (4) 11T PTO Select Shaft | |

W1090219

(6) Rear Axle



Rear Axle Case (RH)

1. Remove the rear axle case (RH) mounting bolts.
2. Remove the rear axle case (RH) as an assembly from the transaxle case.

NOTE

- Since the adjusting shims are installed behind the 37T spiral bevel gear, check the shims.

3. Remove the 37T spiral bevel gear (3) and the shims (2).
4. Remove the 10T final gear shaft (4).






(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to the joint surface of transaxle case to the rear axle (RH) case.

Tightening torque	Rear axle case (RH) mounting bolt (M10)	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 29.0 to 32.5 lbf·ft
-------------------	---	---

- | | |
|---------------------------|--------------------|
| (1) Rear Axle Shaft | (6) Oil Seal |
| (2) Shim | (7) Cir-clip |
| (3) 37T Spiral Bevel Gear | (8) Bearing |
| (4) 10T Final Gear Shaft | (9) Rear Axle Case |
| (5) 66T Final Gear | (10) Brake |

W1091120



Rear Axle (LH)

NOTE

- Prepare a specially bent snap ring pliers.
1. Draw out the oil seal with a screw driver.
 2. Remove the internal cir-clip from the rear axle case.
 3. Draw out the rear axle from the rear axle case.

(When reassembling)

- Do not damage the oil seal.

- | | |
|-----------------------|------------------|
| (1) Rear Axle Case | (4) Ball Bearing |
| (2) Oil Seal | (5) Rear Axle |
| (3) Internal Cir-clip | |

W1090759

Differential Lock Shift Fork




1. Remove the snap pin (2).
2. Remove the joint pin (1).
3. Remove the differential arm (3).
4. Push the differential lock shift fork (4) into the transmission case.
5. Remove the differential lock shift fork (4) with the 66T final gear (5).

(When reassembling)

- Do not damage the O-rings.

- | | |
|---------------------------|---------------------------------|
| (1) Joint Pin | (4) Differential Lock Shift Arm |
| (2) Snap Pin | (5) 66T Final Gear |
| (3) Differential Lock Arm | |

W1091475



66T Final Gear

1. Remove the bearing (1) with a puller.
2. Remove the bearing (4) with a puller.
3. Remove the differential lock shifter (2) and 66T final gear (3).
4. Put parting marks on the differential pinions (10), (14) and the differential side gears (7), (12).
5. Tap out the differential pinion shaft (6).
6. Remove the differential pinions (10), (14), the differential pinion washers (11), (14), differential side gears (7), (12) and the differential side gear washers (8), (13).





(When reassembling)

- Install the differential pinion and differential gear, aligning the parting marks.
- Lock the differential pinion shaft (6) by setting the key (9).

Tightening torque	66T final gear mounting bolt	60.8 to 70.6 N·m 6.2 to 7.2 kgf·m 44.8 to 52.1 lbf·ft
-------------------	------------------------------	---

- | | |
|-----------------------------------|------------------------------------|
| (1) Bearing | (9) Key |
| (2) Differential Lock Shifter | (10) Differential Pinion |
| (3) 66T Final Gear | (11) Differential Pinion Washer |
| (4) Bearing | (12) Differential Side Gear |
| (5) Differential Case | (13) Differential Side Gear Washer |
| (6) Differential Pinion Shaft | (14) Differential Pinion |
| (7) Differential Side Gear | (15) Differential Pinion Washer |
| (8) Differential Side Gear Washer | |

W1050078



Brake, RH




1. Remove the internal cir-clip (15).
2. Remove the bearing holder (14) and the other brake parts from the brake case.

(When reassembling)

- Apply grease to the steel balls.
- Take care not to damage the O-ring on the brake cam lever.
- Check the direction of the cir-clip (15).
- Check that the brake cam lever moves smoothly.

- | | |
|---------------------|---------------------|
| (1) Rear Axle, RH | (9) Ball |
| (2) Oil Seal | (10) Pin |
| (3) Cir-clip | (11) Actuator |
| (4) Bearing | (12) Brake Plate |
| (5) Brake Cam Lever | (13) Brake Disc |
| (6) O-ring | (14) Bearing Holder |
| (7) Rear Axle Case | (15) Cir-clip |
| (8) Cir-clip | |

W1091813



Brake, LH

1. Remove the internal cir-clip (13).
2. Remove the bearing holder (12) and the other brake parts from the brake case.



(When reassembling)

- Apply grease to the steel balls.
- Take care not to damage the O-ring on the brake cam lever.
- Check the direction of the cir-clip (13).
- Check that the brake cam lever moves smoothly.

- | | |
|---------------------|---------------------|
| (1) Rear Axle, LH | (8) Pin |
| (2) Cir-clip | (9) Actuator |
| (3) Bearing | (10) Brake Plate |
| (4) Brake Cam Lever | (11) Brake Disc |
| (5) O-ring | (12) Bearing Holder |
| (6) Cir-clip | (13) Cir-clip |
| (7) Ball | |

W1053089

(7) Transmission Case Shafts






Removing Transmission Shafts

1. Remove the bearing (7) and the collar (8) from the rear PTO shaft (6).
2. Remove **A** group shafts shaking the each shafts slowly.
3. Remove **B** group shafts.
4. Remove **C** group shafts.

- | | |
|-------------------------------|---------------------------|
| (1) 4WD Output Shaft | (8) Collar |
| (2) 4WD Gear Shaft | (9) Mid PTO Idle Shaft |
| (3) Spiral Bevel Pinion Shaft | (10) Mid PTO Output Shaft |
| (4) HST Motor Shaft | |
| (5) HST Pump Shaft | |
| (6) PTO Select Gear Shaft | |
| (7) Bearing | |

A, B, C : Shafts Group

W1054316




PTO Clutch Assembly

1. Remove the bearing (5).
2. Remove the PTO clutch pack (4).
3. Remove the seal rings (6).
4. Remove the external cir-clip (18) using a clutch spring compressor.
5. Disassembling the clutch pack inner parts as show in the figure.





(When reassembling)

- Change the seal rings (6) with a new one.



- | | |
|-----------------------------------|-------------------------------|
| (1) Pump Shaft (PTO Clutch Shaft) | (10) Brake Plate |
| (2) Bearing | (11) Clutch Piston |
| (3) Clutch Gear | (12) Separate Plate |
| (4) Clutch Pack | (13) Disc Plate |
| (5) Bearing | (14) Backing Plate |
| (6) Seal Ring | (15) Internal Cir-clip |
| (7) Clutch Case | (16) Brake Spring |
| (8) O-ring | (17) Washer |
| (9) Brake Disc | (18) External Cir-clip |
| | (19) Clutch Spring Compressor |

W1092125



Assembling Select Arms and HST Pump Shaft (PTO Clutch Shaft)

1. Install the PTO select arm (1).
2. Install the range shift arm (2) and the front wheel drive shaft arm (3).
3. Install the idle gear shaft.

NOTE

- **Install the rear PTO cover and the PTO select gear shaft before installing HST pump shaft assembly.**


4. After installing the rear PTO cover to the transaxle case, install the PTO select gear shaft (6). (Refer to page 2-S34.)
5. Install the HST pump shaft (PTO clutch shaft) (5).

(When reassembling)

- Take care not to damage the O-rings on the arms.

- | | |
|---------------------------------|---------------------------------------|
| (1) PTO Select Arm | (4) Mid-PTO Idle Gear Shaft |
| (2) Range Shift Arm | (5) HST Pump Shaft (PTO Clutch Shaft) |
| (3) Front Wheel Drive Shift Arm | (6) PTO Select Gear Shaft |

W1092555





Front Wheel Drive Shaft, Shifter, Spiral Bevel Pinion Shaft and Mid-PTO Shaft

1. Install the front drive shaft (1).
2. Install the shifter (2) and the spiral bevel pinion shaft (3) together.
3. Install the mid-PTO idle gear shaft (5) and the mid-PTO shaft (6) and the HST motor shaft (4) together.


- | | |
|-------------------------------|-----------------------------|
| (1) Front Wheel Drive Shaft | (4) HST Motor Shaft |
| (2) Shifter | (5) Mid-PTO Idle Gear Shaft |
| (3) Spiral Bevel Pinion Shaft | (6) Mid-PTO Shaft |

W1092968



[4] SERVICING

(1) Hydrostatic Transmission




Center Section

1. Check the center section surface (1) for scratches or wear.
2. If deep scratch or excessive wear is found, replace the hydrostatic transmission assembly.

(1) Center Section Surface

W1093581



Charge Relief Valve


1. Check the charge relief cone (1) and the spring (2).
2. If defects are found, replace it.

(1) Charge Relief Valve

(3) Plug

(2) Spring

W1093691



Check and High Pressure Relief Valve

1. Check the check and high pressure relief valve (5), (6) for scratches and damage.
2. Check the spring (3) for breakage and wear.
3. If anything are unusual, replace the check and high pressure relief valve as complete assembly.

NOTE

- Check and high pressure relief valve (reverse) has a pin hole (1.5 mm, 0.059 in.).

(1) Plug

(4) Shim


(2) O-ring

(5) Check and High Pressure Relief Valve (Forward)

(3) Spring

(6) Check and High Pressure Relief Valve (Reverse)

W1093783



Cylinder Block Assembly

1. Check the cylinder blocks (1) and the pistons (2) for scratches and wear.
2. If there are scratch or worn, replace the cylinder block assembly.
3. Check the pistons for their free movement in the cylinder block bores.
4. If the piston or the cylinder block is scored, replace the cylinder block assembly.
5. Check the polished face (4) of the cylinder block for scoring. If it is scored, replace the cylinder block assembly.

IMPORTANT

- Do not interchange the pistons between the pump cylinder block and the motor cylinder block. Pistons and cylinder blocks are matched.


(1) Cylinder Block

(3) Spring

(2) Piston

(4) Polished Face

W1093936



Cylinder Block Assembly

1. Check the cylinder blocks (1) and the pistons (2) for scratches and wear.
2. If there are scratch or worn, replace the cylinder block assembly.
3. Check the pistons for their free movement in the cylinder block bores.
4. If the piston or the cylinder block is scored, replace the cylinder block assembly.
5. Check the polished face (4) of the cylinder block for scoring. If it is scored, replace the cylinder block assembly.


■ IMPORTANT

- Do not interchange the pistons between the pump cylinder block and the motor cylinder block. Pistons and cylinder blocks are matched.

(1) Cylinder Block
(2) Piston

(3) Spring
(4) Polished Face

W1094117




Thrust Washer, Thrust Roller Bearing, Thrust Plate and Cradle Bearing


1. Check the thrust bearing (3) for scratches and excessive wear.
2. If it is worn, replace it.
3. Check the thrust plate (4) for scratches and excessive wear. If it is worn or scored, replace it.
4. Check the cradle bearing (5) for excessive wear. If it is worn, replace it.

(1) Swashplate
(2) Thrust Washer
(3) Thrust Bearing

(4) Thrust Plate
(5) Cradle Bearing

W1094264







Pump Shaft (PTO Clutch Shaft)

1. Check the seal surface (1) and the bearing surface.
2. If the pump shaft is rough or grooved, replace it.
3. If the ball bearing or the needle bearing is worn, replace it.

(1) Seal Surface

(2) Bearing Surface

W1094465




Needle Bearing

1. Check the needle bearing (1) for wear.
2. If the needle bearing (1) are worn, replace them.

(1) Needle Bearing

W1094709


(2) Transaxle Case



Bearing

1. Hold the inner race, and push and pull the outer race in all directions to check wear and roughness.
2. Apply the transmission oil to the bearing, and hold the inner race. And turn the outer race to check rotation.
3. If there are any defect, replace the bearing.

W1094849




PTO Clutch Disc Wear

1. Measure the thickness of PTO clutch disc with vernier calipers.
2. If the thickness is less than the allowable limit, replace it.

Thickness of PTO clutch disc	Factory specification	1.50 to 1.70 mm 0.060 to 0.066 in.
	Allowable limit	1.35 mm 0.053 in.

W1024320




Separate Plate and Back Plate Wear

1. Measure the thickness of pressure plate and steel back with vernier calipers.
2. If the thickness is less than the allowable limit, replace it.

Thickness of separate plate	Factory specification	0.945 to 1.055 mm 0.0373 to 0.0413 in.
	Allowable limit	0.80 mm 0.0310 in.

Thickness of back plate	Factory specification	1.9 to 2.1 mm 0.075 to 0.082 in.
	Allowable limit	1.85 mm 0.073 in.

W1017226




Flatness of Clutch Piston, Pressure Plate and Steel Plate

1. Place the part on a surface plate.
2. Check the flatness by inserting a feeler gauge (allowable limit size) underneath it at least four points.
3. If the gauge can be inserted, replace it.

Flatness of clutch piston	Allowable limit	0.15 mm 0.0059 in.
---------------------------	-----------------	-----------------------

Flatness of pressure plate and steel plate	Allowable limit	0.20 mm 0.0079 in.
--	-----------------	-----------------------

W1017358




Clutch Spring Free Length

1. Measure the free length of spring with vernier calipers.
2. If the measurement is less than the allowable limit, replace it.

Clutch spring free length	Factory specification	38.5 mm 1.52 in.
	Allowable limit	34.5 mm 1.36 in.

W1017533




PTO Brake Disc Wear

1. Measure the PTO brake disc thickness with a vernier caliper.
2. If the thickness is less than allowable limit, replace it.

PTO brake disc thickness	Factory specification	2.9 to 3.1 mm 0.115 to 0.122 in.
	Allowable limit	2.70 mm 0.106 in.

W1029590




PTO Brake Plate

1. Measure the PTO brake plate thickness with a vernier caliper.
2. If the thickness is less than allowable limit, replace it.

PTO brake plate thickness	Factory specification	1.9 to 2.1 mm 0.075 to 0.082 in.
	Allowable limit	1.85 mm 0.073 in.

W1095464




Clearance between Differential Case and Differential Side Gear

1. Measure the differential side gear boss O.D. with an outside micrometer.
2. Measure the differential case I.D. with a cylinder gauge and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace faulty parts.

Clearance between differential case and differential side gear	Factory specification	0.050 to 0.151 mm 0.0020 to 0.0059 in.
	Allowable limit	0.30 mm 0.0118 in.

Differential case I.D.	Factory specification	38.000 to 38.062 mm 1.4961 to 1.4985 in.
Differential side gear O.D.	Factory specification	37.911 to 37.950 mm 1.4926 to 1.4941 in.

W1029693




Clearance between Differential Pinion Shaft and Differential Pinion

1. Measure the differential pinion shaft O.D. with an outside micrometer.
2. Measure the differential pinion I.D. with a cylinder gauge, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace faulty parts.

Clearance between differential pinion shaft and differential pinion	Factory specification	0.080 to 0.122 mm 0.0031 to 0.0048 in.
	Allowable limit	0.30 mm 0.0118 in.

Differential pinion I.D.	Factory specification	20.060 to 20.081 mm 0.7898 to 0.7906 in.
Differential pinion shaft O.D.	Factory specification	19.959 to 19.980 mm 0.7858 to 0.7866 in.

W1029832



Backlash between Differential Pinion and Differential Side Gear



1. Secure the differential case with a vise.
2. Set the dial indicator (lever type) with its finger on the tooth of the differential side gear.
3. Press differential pinion and side gear against the differential case.
4. Hold the differential pinion and move the differential side gear to measure the backlash.
5. If the backlash exceeds the allowable limit, adjust with differential side gear shims.

Backlash between differential pinion and differential side gear	Factory specification	0.15 to 0.30 mm 0.0059 to 0.0118 in.
	Allowable limit	0.40 mm 0.0157 in.

(Reference)

- Thickness of shims :
1.5 mm (0.0591 in.), 1.6 mm (0.0630 in.), 1.7 mm (0.0669 in.)


W1029971



Backlash between Spiral Bevel Pinion Gear and Bevel Gear

1. Temporarily assemble the spiral bevel pinion gear (2) and the bevel gear (1) in the transaxle case.
2. Prepare the fuse bent already three to four times.
3. Hold the fuse on the bevel gear teeth upper surface (A).
4. Turn the front drive shaft one turn clockwise by hands.
5. Measure the thickness of the fuse as a backlash between the spiral bevel pinion gear and the bevel gear.
6. If the backlash exceeds the factory specifications, adjust the shims (3), (4).


Backlash between spiral bevel pinion and bevel gear	Factory specification	0.10 to 0.30 mm 0.0039 to 0.0118 in.
---	-----------------------	---



- (1) Bevel Gear
- (2) Spiral Bevel Pinion Gear
- (3) Shim
- (4) Shim
- (5) Final Gear Shaft (Brake Shaft)

(A) Bevel Gear Teeth Upper Surface


W1095931



Brake Cam Lever Movement

1. Move the brake cam lever by hand to check its movement.
2. If its movement is heavy, refine the brake cam with a emery paper.

W1096217




Flatness of Actuator and Bearing Holder

1. Place a straightedge of 150 mm (5.91 in.) or more in length on the contacting surface of the actuator and the bearing holder.
2. Inspect the friction surface of the actuator and the bearing holder with the straightedge, and determine if a 0.30 mm (0.0118 in.) feeler gauge will fit on the part of wear.
3. If it will fit, resurface.

Flatness of actuator and bearing holder	Allowable limit	0.30 mm 0.0118 in.
---	-----------------	-----------------------

W1030671




Height of Cam Plate and Ball

1. Measure the height of the cam plate with the ball installed.
2. If the measurement is less than the allowable limit, replace the cam plate and balls.
3. Inspect the ball holes of cam plate for uneven wear.
4. If the uneven wear is found, replace it.

Height of cam plate and ball	Factory specification	22.89 to 22.99 mm 0.9012 to 0.9051 in.
	Allowable limit	22.40 mm 0.8819 in.

W1030769



Brake Disc and Friction Plate Wear

1. Measure the brake disc thickness and the friction plate thickness with an outside micrometer.
2. If the thickness is less than the allowable limit, replace it.

Brake disc thickness	Factory specification	3.3 to 3.5 mm 0.130 to 0.138 in.
	Allowable limit	3.0 mm 0.118 in.

Friction plate thickness	Factory specification	1.92 to 2.08 mm 0.0756 to 0.0819 in.
	Allowable limit	1.52 mm 0.0598 in.

W1030890


3 FRONT AXLE

MECHANISM

CONTENTS

1. STRUCTURE	3-M1
2. FRONT WHEEL ALIGNMENT	3-M2

1. STRUCTURE



- | | | | |
|---------------------|---------------------------------|----------------------------------|-----------------------|
| (1) Axle | (6) Bevel Gear | (11) Differential Pinion Shaft | (16) Bevel Gear Shaft |
| (2) Axle Flange | (7) Differential Yoke Shaft, RH | (12) Differential Yoke Shaft, LH | (17) Front Gear Case |
| (3) Bevel Gear | (8) Front Axle Case | (13) Differential Side Gear | (18) Bevel Gear |
| (4) Bevel Gear | (9) Bevel Pinion Shaft | (14) Differential Pinion Gear | (19) Collar |
| (5) Bevel Gear Case | (10) Differential Gear Assembly | (15) Bevel Gear | |

The front axle of the 4WD is constructed as shown above. Power is transmitted from the transmission through the propeller shaft to the bevel pinion shaft (9), then to the bevel gear (15) and to the differential side gear (13).


The power through the differential side gear is transmitted to the differential yoke shaft (7), (12), and to the bevel gear shaft (16) through the bevel gears (4), (6) in the bevel gear case (5).

The revolution is greatly reduced by the bevel gears (18), (3), then the power is transmitted to the axle (1).

The differential system allows each wheel to rotate at a different speed to make turning easier.

2. FRONT WHEEL ALIGNMENT

To assure smooth mobility or maneuverability and enhance stable and straight running, the front wheels are mounted at an angle to the right, left and forward directions. This arrangement is referred to as the Front Wheel Alignment.




■ Camber

The front wheels are tilted from the vertical as viewed from the front, upper wheels are spreader than lower ones.

This inclination is called camber (a). Camber reduces bending or twisting of the front axle caused by vertical load or running resistance, and also maintains the stability in running.

Camber (a)	0.035 rad 2 °
------------	------------------

W1012811



■ Kingpin Angle


The Kingpin is titled from the vertical as viewed from the front.

This angle is called kingpin angle (a). As with the camber, kingpin angle reduces rolling resistance of the wheels, and prevents any shimmy motion of the steering wheel.

It also reduces steering effort.

Kingpin angle (a)	0.209 rad 12 °
-------------------	-------------------

W1013073



■ Caster

The kingpin is titled forward as viewed from the side. The point (b) of the wheel center line is behind the point (a) of the kingpin shaft center line.

This inclination is called caster (c). Caster helps provide steering stability.


As with the kingpin inclination, caster reduces steering effort.

Camber (c)	0 rad 0 °
------------	--------------

F : Front

R : Rear

W1013142



■ Toe-in

Viewing the front wheels from above reveals that the distance between the toes of the front wheels is smaller than that between the heels.

It is called toe-in. The front wheels tend to roll outward due to the camber, but toe-in offsets it and ensures parallel rolling of the front wheels. Another purpose of toe-in is to prevent excessive and uneven wear of tires.

Toe-in (R - F)	0 to 5 mm 0 to 0.19 in.
----------------	----------------------------

F : Front

R : Rear

W1013242

SERVICING

CONTENTS

1. TROUBLESHOOTING	3-S1
2. SERVICING SPECIFICATIONS	3-S2
3. TIGHTENING TORQUES	3-S3
4. CHECKING, DISASSEMBLING AND SERVICING.....	3-S4
[1] CHECKING AND ADJUSTING	3-S4
[2] PREPARATION	3-S5
(1) Separating Front Axle Assembly.....	3-S5
[3] DISASSEMBLING AND ASSEMBLING.....	3-S8
(1) Front Axle Assembly	3-S8
[4] SERVICING	3-S12

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Front Wheels Wander to Right or Left	Tire pressure uneven	Adjust	G-42
	Improper toe-in adjustment (improper alignment)	Adjust	G-24, 3-S5
	Clearance between center pin and shaft support bushing excessive	Replace	3-S11
	Front axle rocking force too small	Adjust	3-S4
	Tie-rod end loose	Tighten	3-S8
	Air sucked in power steering circuit	Bleed	–
Front Wheels Can Not Be Driven	Front wheel driving gears in front axle gear case broken	Replace	3-S11
	Universal joint broken	Replace	3-S7
	Front wheel drive gears in transmission broken	Replace	–
	Front differential gear broken	Replace	3-S13, S14
Noise	Gear backlash excessive	Adjust or replace	3-S13
	Oil insufficient	Replenish	3-S5
	Bearings damaged or broken	Replace	–
	Gears damaged or broken	Replace	–
	Spiral bevel pinion shaft turning force improper	Adjust	3-S13

W1014322

2. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Front Wheel Alignment	Toe-in	0 to 10 mm 0 to 0.39 in.	—
Front Axle	Rocking Force	49.0 to 117.7 N 5.0 to 12.0 kgf 11.0 to 26.5 lbf	—
Differential Case to Differential Side Gear	Clearance	0.040 to 0.082 mm 0.00157 to 0.00323 in.	0.17 mm 0.0067 in.
Differential Case	I.D.	26.000 to 26.021 mm 1.02362 to 1.02445 in.	—
Differential Side Gear	O.D.	25.939 to 25.960 mm 1.02122 to 1.02205 in.	—
Differential Pinion Shaft to Differential Pinion	Clearance	0.025 to 0.055 mm 0.00098 to 0.00217 in.	0.25 mm 0.0096 in.
Differential Pinion Shaft	O.D.	9.960 to 9.975 mm 0.39212 to 0.39272 in.	—
Differential Pinion	I.D.	10.000 to 10.015 mm 0.39370 to 0.39429 in.	—
Differential Pinion to Differential Side Gear	Backlash	0.1 to 0.3 mm 0.004 to 0.012 in.	—
Bevel Pinion Shaft	Turning Torque	0.8 to 1.0 N·m 0.08 to 0.10 kgf·m 0.59 to 0.73 lbf·ft	—
Bevel Pinion Shaft to Bevel Gear	Backlash	0.1 to 0.3 mm 0.004 to 0.012 in.	—
12T Bevel Gear to 15T Bevel Gear	Backlash	0.1 to 0.3 mm 0.004 to 0.012 in.	—
Center Pin to Pin Support Bushing	Clearance	0 to 0.231 mm 0 to 0.00909 in.	0.70 mm 0.0276 in.
Center Pin	O.D.	19.850 to 20.000 mm 0.78149 to 0.78740 in.	—
Bushing	I.D.	20.000 to 20.081 mm 0.78740 to 0.79059 in.	—

W1016639

3. TIGHTENING TORQUES


Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-8.)

Item	N·m	kgf·m	lbf·ft
Front wheel mounting screw	149.2 to 179.0	15.2 to 18.3	110 to 132
Front wheel mounting screw	149.2 to 179.0	15.2 to 18.3	110 to 132
Tie-rod slotted nut	17.7 to 34.3	1.8 to 3.5	13.0 to 25.3
Power steering cylinder mounting screw	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2
Bevel gear case mounting screw (M10)	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2
Bevel gear case mounting screw (M12)	77.5 to 90.2	7.9 to 9.2	57.2 to 66.5
Front gear case cover mounting screw	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2

W1012736

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING



Toe-in

1. Inflate the tires to the specified pressure.
2. Turn the front wheels straight ahead.
3. Measure the toe-in ((B) - (A)).
4. If the measurement is not within the factory specifications, adjust the tie-rod length.

Toe-in (B) - (A)	Factory specification	0 to 5 mm 0 to 0.19 in.
------------------	-----------------------	----------------------------



■ Adjusting procedure

1. Loosen the lock nuts and turn the tie-rod to adjust the rod length until the proper toe-in measurement is obtained.
2. Retighten the lock nuts.

- (1) Tie-rod
(2) Lock Nut

(A) Wheel to Wheel Distance at Front
(B) Wheel to Wheel Distance at Rear
(C) Front

W1011333



Front Axle Rocking Force

1. Jack up the front side of tractor and remove the front wheel.
2. Set a spring balance to the front gear case cover.
3. Measure the front axle rocking force.
4. If the measurement is not within the factory specifications, adjust as following.

■ Adjusting procedure

1. Remove the cotter pin (1).
2. Tighten or loosen the adjusting nut (2) so that the measurement of rocking force comes to factory specifications.
3. If the slot and pin hole do not meet, align the nut until they do meet within factory specifications.
4. Install the new cotter pin.

(When reassembling)

- Be sure to split the cotter pin like an anchor.

(Reference)


- Tightening torque of adjusting nut:
19.6 N·m (2.0 kgf·m, 14.5 lbf·ft)

Front axle rocking force	Factory specification	49.0 to 177.7 N 5.0 to 12.0 kgf 11.0 to 26.5 lbf
--------------------------	-----------------------	--

(1) Cotter Pin

(2) Adjusting Nut

W1011602



Front Wheel Steering Angle

1. Inflate the tires to the specified pressure.
2. Loosen the lock nut and shorten the length of stopper bolt LH (1).
3. Steer the wheels to the extreme left.
4. Lengthen the length of stopper bolt (1) until the stopper bolt contacts with the bevel gear case (3).
5. Return the steering wheel to straight ahead and lengthen the stopper bolt four turn from above position further.
6. Lock the stopper bolt by lock nut (2).
7. For adjusting the right steering angle, perform the same procedure as mentioned in left steering angle.

(Reference)

Steering angle	Right side	0.84 to 0.87 rad 48 to 50 °
	Left side	0.92 to 0.96 rad 53 to 55 °
Length of adjusting bolt (L)	Right side	26 mm 1.02 in.
	Left side	21 mm 0.83 in.


- (1) Stopper Bolt LH
(2) Lock Nut

- (3) Bevel Gear Case

W1011846

[2] PREPARATION

(1) Separating Front Axle Assembly



Draining Front Axle Case Oil

1. Place the oil pans underneath the front axle case.
2. Remove both right and left hand side drain plugs (3) and filling plug (2) to drain the oil.
3. After draining, reinstall the drain plugs (3).

(When reassembling)

- When re-filling, remove the right and left breather plugs (1).

■ IMPORTANT






- After ten minutes, check the oil level again, add oil to prescribed level.
- Use KUBOTA SUPER UDT fluid or SAE80, 90 gear oil. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7.)

Oil Capacity	4.7 L
	5.0 U.S.qts
	4.1 Imp.qts

- (1) Breather Plug
(2) Filling Plug with Dipstick
(3) Drain Plug

(A) Oil level is acceptable within this range.

W1012192



Battery Cables and Battery

CAUTION

- When disconnecting the battery cables, disconnect the negative cable from the battery first. When connecting, connect the positive cable to the battery first.

- Remove the under panel and the battery cover.
- Disconnect the negative cable (2) from the battery (1).
- Disconnect the positive cable (3) from the battery (1) and remove the battery (1).

(1) Battery

(2) Negative cable

(3) Positive Cable

W1018657

Bonnet and Under Cover

- Open the bonnet (1), disconnect the connectors (3) for the head lights, then remove the bonnet with the bonnet bracket (4).
- Remove the under cover (2).

(1) Bonnet

(2) Under Cover

(3) Connector

(4) Bonnet Bracket

W1018393

Front Wheel and Propeller Shaft Cover


- Lift up the front of tractor and place the disassembling stand under the front axle frame.
- Remove the front wheels.
- Remove the propeller shaft cover mounting bolt and slide the propeller shaft cover (1).

(When reassembling)

Tightening torque	Front wheel mounting screw	149.2 to 179.0 N·m 15.3 to 18.2 kgf·m 110 to 132 lbf·ft
-------------------	----------------------------	---

(1) Propeller Shaft Cover

W1012838



Disconnecting Propeller Shaft

1. Tap out the spring pins (2) and disconnect the universal joint (1) and spiral bevel pinion shaft.


(When reassembling)

- Apply grease to the splines of the propeller shaft and universal joint.

(1) Universal Joint

(2) Spring Pin

W1013075



Front Axle Assembly

1. Remove the power steering hose clamp (1).
2. Place the garage jack under the front axle.
3. Remove the cotter pin (2).
4. Remove the slotted nut (2) of center pin and separate the front axle from the frame.
5. Disconnect the power steering cylinder hoses (4).

(When reassembling)

- After mounting the front axle assembly to the frame, be sure to adjust the front axle rocking force. (See page 3-S4.)
- Installing the cotter pin, be sure to split the cotter pin like an anchor

Tightening torque	Power steering cylinder hose	23.6 to 27.4 N·m 2.4 to 2.8 kgf·m 17.4 to 20.2 lbf·ft
-------------------	------------------------------	---



(1) Hose Clamp

(2) Cotter Pin

(3) Slotted Nut (Adjusting Nut for Front Axle Rocking Force)


(4) Power Steering Cylinder Hose

W1023380



[3] DISASSEMBLING AND ASSEMBLING

(1) Front Axle Assembly



Power Steering Cylinder

1. Remove the cotter pin and remove the slotted nut for tie-rod (1).
2. Remove the power steering cylinder mounting screws and remove the power steering cylinder (2) with tie-rod.

(When reassembling)

■ NOTE


- Tighten the slotted nut to 17.7 N·m (1.8 kgf·m, 13 lbf·ft). If the slot and pin hole do not meet, tighten the nut until they do meet, and install the cotter pin.
- Be sure to split the cotter pin like an anchor.

Tightening torque	Tie-rod slotted nut	17.7 to 34.3 N·m 1.8 to 3.5 kgf·m 13.0 to 25.3 lbf·ft
	Power steering cylinder mounting screw	48.1 to 55.8 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 lbf·ft

(1) Tie-rod

(2) Power Steering Cylinder

W1013368



Bevel Gear Case and Front Gear Case

1. Remove the bevel gear case mounting screws.
2. Remove the bevel gear case (2) and front gear case (1) as a unit from the front axle case (3).

(When reassembling)

- Apply grease to the O-ring and take care not to damage it.
- Do not interchange right and left bevel gear case assemblies and right and left gear case assemblies.


Tightening torque	Bevel gear case mounting screw (M10)	48.1 to 55.8 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 lbf·ft
	Bevel gear case mounting screw (M12)	77.5 to 90.1 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 lbf·ft

(1) Front Gear Case

(3) Front Axle Case

(2) Bevel Gear Case

W1013787



Front Gear Case Cover

1. Remove the front gear case mounting screws and remove the front gear case cover (1) with bevel gear (2).

(When reassembling)

- Apply grease to the O-ring and take care not to damage it.



Tightening torque	Front gear case cover mounting screw	48.1 to 55.8 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 lbf·ft
-------------------	--------------------------------------	---

(1) Front Gear Case Cover

(3) Front Gear Case

(2) Bevel Gear

W1013952



36T Bevel Gear and Front Axle Shaft

1. Remove the bearing (5).
2. Take out the 36T bevel gear (4).
3. Take out the collar (3).
4. Tap out the axle shaft (2).

(When reassembling)

- Install the oil seal (6) of front gear case cover (1), noting its direction as shown in the figure.

(1) Front Gear Case Cover

(4) 36T Bevel Gear


(2) Axle Shaft


(5) Ball Bearing

(3) Collar

(6) Oil Seal

W1014087





Front Gear Case and Bevel Gear Case




1. Remove the internal snap ring (1).
2. Remove the bevel gear with ball bearing (3) and shim (2).
3. Remove the bevel gear (4).
4. Remove the external snap ring (7).
5. Remove the bevel gear case (5) from front gear case (6).
6. Remove the oil seal (12) and the ball bearing (11).
7. Remove the internal snap ring (10) and remove the ball bearing (9).
8. Remove the bevel gear shaft (8) with ball bearing.




(When reassembling)

- Install the oil seal (12) of bevel gear case, noting its direction as shown in the figure.
- Install the adjusting shims (2) to their original position.

- | | |
|------------------------|-------------------------|
| (1) Internal Snap Ring | (8) Bevel Gear Shaft |
| (2) Shim | (9) Ball Bearing |
| (3) Ball Bearing | (10) Internal Snap Ring |
| (4) Bevel Gear | (11) Ball Bearing |
| (5) Bevel Gear Case | (12) Oil Seal |
| (6) Front Gear Case | (13) Ball Bearing |
| (7) External Snap Ring | |

W1014354





Bevel Pinion Shaft and Differential Gear Assembly

1. Take out the differential yoke shaft (4), (7).
2. Remove the oil seal (11).
3. Remove the internal snap ring (1).
4. Pull out the bevel pinion shaft (3).
5. Take out the differential gear assembly (5), from right side of front axle case (6).
6. Remove the stake of lock nut (10), and then remove the lock nut (10).
7. Remove the taper roller bearing (9).

(When reassembling)

- Apply gear oil to the taper roller bearings (9) and install them correctly, noting their direction.
- Replace the lock nut (10) and oil seal (11) with new ones.
- After tighten the lock nut (10) to the specified torque, stake it firmly.
- Install the adjusting collars (2), (8) to their original position.

- | | |
|--------------------------------|--------------------------------|
| (1) Internal Snap Ring | (7) Differential Yoke Shaft RH |
| (2) Adjusting Collar | (8) Adjusting Collar |
| (3) Bevel Pinion Shaft | (9) Taper Roller Bearing |
| (4) Differential Yoke Shaft LH | (10) Lock Nut |
| (5) Differential Gear Assembly | (11) Oil Seal |
| (6) Front Axle Case | (12) Collar |

W1015832

Differential Gear [BX2350D]

1. Remove the bevel gear (5) with bearing (6) and bearing (9) by puller.
2. Remove the external snap ring (10).
3. Remove the differential pinion shaft (8).
4. Remove the differential pinions (2), differential side gears (4) and shims (1), (3).

NOTE

- **Arrange the parts to know their original position.**

(When reassembling)

- Apply molybdenum disulfide (Three Bond 1901 or equivalent) to the inner circumferential surface of the differential side gears, differential pinions and shims.

- | | |
|----------------------------|-------------------------------|
| (1) Shim | (6) Bearing |
| (2) Differential Pinion | (7) Differential Gear Case |
| (3) Shim | (8) Differential Pinion Shaft |
| (4) Differential Side Gear | (9) Ball Bearing |
| (5) Bevel Gear | (10) Spring Pin |

W1028857

[4] SERVICING



Clearance between Differential Case and Differential Side Gear

1. Measure the differential side gear boss O.D..
2. Measure the differential case bore I.D., and calculate the clearance.
3. Measure the differential case cover bore I.D., and calculate the clearance.
4. If the clearance exceeds the allowable limit, replace faulty parts.

Clearance between differential case and differential side gear	Factory specification	0.040 to 0.082 mm 0.00157 to 0.00323 in.
	Allowable limit	0.17 mm 0.0067 in.

Differential case bore I.D.	Factory specification	23.500 to 23.521 mm 0.92520 to 0.92602 in.
		26.000 to 26.021 mm 1.02362 to 1.02445 in.
Differential side gear O.D.		23.439 to 23.460 mm 0.92280 to 0.92362 in.
		25.939 to 25.960 mm 1.02122 to 1.02205 in.

W1015523



Clearance between Differential Pinion Shaft and Differential Pinion

1. Measure the differential pinion shaft O.D..
2. Measure the differential pinion I.D., and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace faulty parts.

Clearance between differential pinion shaft and differential pinion	Factory specification	0.025 to 0.055 mm 0.00098 to 0.00217 in.
	Allowable limit	0.25 mm 0.0096 in.

Differential pinion shaft O.D.	Factory specification	9.960 to 9.975 mm 0.39212 to 0.39272 in.
Differential side gear I.D.	Factory specification	10.000 to 10.015 mm 0.39370 to 0.39429 in.

W1015675



Backlash between Differential Pinion and Differential Side Gear


1. Set a dial gauge (lever type) on a tooth of the differential pinion.
2. Fix the differential side gear, and move the differential pinion to measure the backlash.
3. If the measurement exceeds the factory specifications, adjust with the differential side gears shims.

Backlash between differential pinion and differential side gear	Factory specification	0.1 to 0.3 mm 0.004 to 0.012 in.
---	-----------------------	-------------------------------------

(Reference)

- Thickness of adjusting shims :
For side gear : 0.8 mm (0.031 in.), 1.0 mm (0.039 in.)
1.2 mm (0.047 in.)
For pinion : 3.3 mm (0.130 in.), 3.5 mm (0.138 in.)
3.7 mm (0.146 in.), 3.9 mm (0.154 in.)

W1015817



Turning Torque of Bevel Pinion Shaft


1. Clamp the spiral bevel pinion shaft assembly to the vise and tighten the staking nut.
2. Measure the turning torque of bevel pinion shaft.
3. If the turning torque is not within the factory specifications, adjust with the lock nut.

Turning torque	Factory specification	0.8 to 1.0 N·m 0.08 to 0.10 kgf·m 0.59 to 0.73 lbf·ft
----------------	-----------------------	---

NOTE

- After turning force adjustment, be sure to stake the lock nut.

W10206520



Backlash between Bevel Pinion Shaft and Bevel Gear

1. Put the solder (0.5 mm (0.020 in.) thickness) on the position where the tooth proper contact of bevel pinion shaft.
2. Fix the bevel gear and rotate the bevel pinion shaft carefully.
3. Measure the backlash by thickness of the point where solder is the thinnest.
4. If the backlash is not within the factory specifications, change the adjusting collars (3), shims (4). For example change the adjusting shim (4) to 0.1 mm (0.004 in.) smaller size, and change the adjusting collar (3) to 0.1 mm (0.004 in.) larger size.
5. Adjust the backlash properly by repeating the above procedures.

Backlash between bevel pinion shaft and bevel gear	Factory specification	0.1 to 0.3 mm 0.004 to 0.012 in.
--	-----------------------	-------------------------------------

(Reference)

- Above factory specification should be measured on the tooth of bevel pinion. When measuring the backlash on the spline of its shaft, factory specification will be 0.0571 to 0.1714 mm (0.00225 to 0.00675 in.).
- Thickness of adjusting collars (3), (4) :

3.4 mm (0.134 in.)	4.1 mm (0.161 in.)
3.6 mm (0.142 in.)	4.2 mm (0.165 in.)
3.8 mm (0.150 in.)	4.4 mm (0.173 in.)
3.9 mm (0.154 in.)	4.5 mm (0.177 in.)
4.0 mm (0.157 in.)	4.6 mm (0.181 in.)


(1) Bevel Gear


(2) Bevel Pinion Shaft

(3) Adjusting Collar

(4) Adjusting Collar

W10301800





Backlash between 12T Bevel Gear and 15T Bevel Gear

1. Stick a strip of fuse to three spots on the 15T bevel gear (1) with grease.
2. Fix the front axle case, bevel gear case and front gear case.
3. Turn the axle.
4. Remove the bevel gear case from front axle case and measure the thickness of the fuses with an outside micrometer.
5. If the backlash is not within the factory specifications, adjust with shim (3).

Backlash between 12T bevel gear and 15T bevel gear	Factory specification	0.1 to 0.3 mm 0.004 to 0.012 in.
--	-----------------------	-------------------------------------


(Reference)

- Thickness of adjusting shims (3) :
0.8 mm (0.031 in.) 1.2 mm (0.047 in.)
1.0 mm (0.039 in.) 1.4 mm (0.055 in.)
- Tooth contact : More than 35 %

(1) 15T Bevel Gear
(2) 12T Bevel Gear

(3) Shim

W10211780



Clearance between Center Pin and Pin Support Bushing

1. Measure the center pin O.D. with an outside micrometer.
2. Measure the pin support bush I.D. of the front axle with a cylinder gauge.
3. If the clearance exceeds the allowable limit, replace it.

Clearance between center pin and pin support bush	Factory specification	0 to 0.231 mm 0 to 0.00909 in.
	Allowable limit	0.70 mm 0.0276 in.

Center pin O.D.	Factory specification	19.850 to 20.000 mm 0.78149 to 0.78740 in.
Bush I.D.	Factory specification	20.000 to 20.081 mm 0.78740 to 0.79059 in.

W1016540


4 STEERING

MECHANISM

CONTENTS

1. HYDRAULIC CIRCUIT	4-M1
2. STEERING CONTROLLER	4-M2
3. STEERING CYLINDER.....	4-M3

1. HYDRAULIC CIRCUIT







This model is provided with a full hydrostatic power steering.

In the full hydrostatic power steering, the steering controller is connected to the steering cylinder with only the hydraulic piping. Accordingly, it does not have mechanical transmitting parts such as steering gear, pitman arm, drag link, etc.. Therefore, it is simple in construction. This steering system consists of the oil strainer (6), hydraulic pump (5), flow priority valve (3), steering controller (1), steering cylinder (2), etc..

Flow priority valve (3) divides the oil into two direction. One is the control flow to power steering (constantly 9.5 L/min., 2.5 U.S.gals/min., 2.1 Imp.gals/min.), and the other is excessive flow to control valve of implement lift control.

By operating the power steering body, the required amount of oil is fed to the steering cylinder (2).

2. STEERING CONTROLLER



The steering controller consists of a control valve (4) and a metering device (3).

■ Control Valve

The control valve is a rotating spool type.

When the steering wheel is not turned, the position of the spool (7) and sleeve (9) is kept neutral by the centering spring (8). This causes the forming of a "Neutral" oil circuit.

When the steering wheel is turned either clockwise or counterclockwise, the position of the spool and sleeve changes in relation to the centering spring. This allows the forming of a "Right Turning" or "Left Turning" oil circuit. At the same time, the gear pump (Metering device) rotates with the spool and sends the oil to the cylinder corresponding to the rotation of the steering wheel.

■ Metering Device

Oil sent from the hydraulic pump to the steering cylinder, passes through the metering device (3).

Namely, when the rotor is driven, two chambers suck in oil due to volumetric change in the pump chambers formed between the rotor (12) and the stator (13), while oil is discharged from other two chambers. On the other hand, rotation of the steering wheel is directly transmitted to the rotor through the spool (7), drive shaft (10), etc.

Accordingly, the metering device serves to supply the steering cylinder with oil, amount of which corresponds to the rotation of the steering wheel. The wheels are thus turned by the angle corresponding to the rotation of the steering wheel.

When the engine stops or the hydraulic pump malfunctions, the metering device functions as a manual trochoid pump, which makes manual steering possible.

■ Relief Valve

The relief valve (1) is located in the steering controller. It controls the maximum pressure of the power steering system.

Its setting pressure is as follows.

8.33 to 8.83 MPa

85 to 90 kgf/cm²

1209 to 1280 psi

- (1) Relief Valve
- (2) Steering Controller
- (3) Metering Device
- (4) Control Valve
- (5) Steering Cylinder
- (6) Check Valve
- (7) Spool
- (8) Centering Spring
- (9) Sleeve

- (10) Drive Shaft
- (11) Distributor Plate
- (12) Rotor
- (13) Stator

A : Control Valve


B : Metering Device

P : P Port (From flow priority valve)

T : T Port (To PTO clutch valve and HST circuit)

W1012783

3. STEERING CYLINDER



- | | | | |
|------------------------|---------------|------------------------|--------------------|
| (1) Rod | (4) Guide | (7) Center Piston | (10) Cylinder Tube |
| (2) Wiper Seal | (5) O-ring | (8) Piston O-ring | (11) Rod O-ring |
| (3) Internal Snap Ring | (6) Seal Ring | (9) External Snap Ring | |

The steering cylinder is single piston both rod double-acting type. This steering cylinder is installed parallel to the front axle and connected to tie-rods.

The tie-rods connected to both knuckle arm guarantees equal steering movement to both front wheels.

The steering cylinder provide force in both directions. Depending upon direction the steering wheel is turned pressure oil enters at one end of the cylinder to extend, or the other end to retract it, thereby turning front wheel of the tractor.

SERVICING

CONTENTS

1. TROUBLESHOOTING	4-S1
2. SERVICING SPECIFICATIONS	4-S2
3. TIGHTENING TORQUES	4-S3
4. CHECKING, DISASSEMBLING AND SERVICING.....	4-S4
[1] CHECKING	4-S4
(1) Relief Valve.....	4-S4
[2] PREPARATION	4-S4
(1) Separating Power Steering Controller	4-S4
(2) Separating Power Steering Cylinder.....	4-S6
[3] DISASSEMBLING AND ASSEMBLING.....	4-S8
(1) Power Steering Cylinder	4-S8
[4] SERVICING	4-S9

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Cannot Be Steered	Steering controller malfunctioning	Replace	4-S5
Hard Steering	Power steering oil improper	Change with specified oil	G-7
	Hydraulic pump malfunctioning	Replace	5-S15
	Flow priority valve malfunctioning	Repair or replace	5-M6
	Steering controller malfunctioning	Replace	4-S5
Steering Force Fluctuates	Steering controller malfunctioning	Replace	4-S5
	Flow priority valve malfunctioning	Replace	5-M7
	Air sucked in pump due to lack of oil	Replenish	G-7
	Air sucked in pump from suction circuit	Repair	5-S13
Steering Wheel Turns Spontaneously When Released	Steering controller malfunctioning	Replace	4-S5
Front Wheels Wander to Right and Left	Steering controller malfunctioning	Replace	4-S5
	Air sucked in pump due to lack of oil	Replenish	G-7
	Air sucked in pump from suction circuit	Repair	5-S15
	Insufficient bleeding	Bleed	4-S4
	Cylinder malfunctioning	Repair or replace	4-S8
	Improper toe-in adjustment	Adjust	3-S4
	Tire pressure uneven	Inflate	G-44
Wheels Are Turned to a Direction Opposite to Steering Direction	Cylinder piping connected in reverse	Repair	4-S6, S7
Steering Wheel Turns Idle in Manual Steering	Insufficient bleeding	Bleed	4-S4
	Air sucked in due to lack of oil	Replenish	G-7
Noise	Air sucked in pump due to lack of oil	Replenish	G-7
	Air sucked in pump from suction circuit	Repair	5-S15
	Pipe deformed	Replace	—
Oil Temperature Increases Rapidly	Steering controller (relief valve) malfunctioning	Replace	4-S5

W1014322

2. SERVICING SPECIFICATIONS

POWER STEERING BODY

Item		Factory Specification	Allowable Limit
Relief Valve	Operating Pressure	8.33 to 8.83 MPa 85.0 to 90.0 kgf/cm ² 1209 to 1280 psi	—

W1013874

STEERING CYLINDER

Item		Factory Specification	Allowable Limit
Steering Cylinder	I.D.	40.000 to 40.062 mm 1.57480 to 1.57724 in.	40.100 mm 1.57874 in.
Piston Rod to Guide	Clearance	0.020 to 0.070 mm 0.00079 to 0.00276 in.	0.200 mm 0.00787 in.

W1013973

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-8.)

Item	N·m	kgf·m	lbf·ft
Steering wheel mounting nut	20 to 25	2.0 to 2.6	14.8 to 18.4
Power steering hose	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2
Power steering cylinder mounting screw	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2
Tie-rod slotted nut	17.7 to 34.3	1.8 to 3.5	13.0 to 25.3
Tie-rod screw	74 to 84	7.5 to 8.6	54.6 to 61.9

W1012736

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING

(1) Relief Valve



Relief Valve Operating Pressure

1. Disconnect the power steering hose L (or R) from steering controller, and set a pressure gauge and cable.

(Reference)

- Hose and adaptor size : 9/16-18UNF, 37 ° flare
2. Start the engine and set at maximum speed.
 3. Fully turn the steering wheel to the left (or right) to check the feeling which the steering wheel lightly locks. Read the relief valve operating pressure when the steering wheel to the above-mentioned lock position by operation force at approximately 9.8 N (1 kgf, 2.2 lbf) of outer.

■ NOTE


- After set a pressure gauge, be sure to bleed air.
- Note that the pressure value changes by the pump action of the power steering controller when the steering operation is continued after the steering wheel is lightly locked and accurate relief valve pressure cannot be measured.

Relief valve operating pressure	Factory specification	8.33 to 8.83 MPa 85 to 90 kgf/cm ² 1209 to 1280 psi
---------------------------------	-----------------------	--

W1011481

[2] PREPARATION

(1) Separating Power Steering Controller



Battery Cables and Battery



CAUTION


- When disconnecting the battery cables, disconnect the negative cable from the battery first. When connecting, connect the positive cable to the battery first.
1. Remove the under panel and the battery cover.
 2. Disconnect the negative cable (2) from the battery (1).
 3. Disconnect the positive cable (3) from the battery (1) and remove the battery (1).

(1) Battery

(3) Positive Cable

(2) Negative cable

W1013596





Steering Wheel


1. Remove the steering wheel cap (1).
2. Remove the steering wheel mounting nut and remove the steering wheel.

(When reassembling)

Tightening torque	Steering wheel mounting nut	20 to 25 N·m 2.0 to 2.6 kgf·m 14.8 to 18.4 lbf·ft
-------------------	-----------------------------	---

(1) Steering Wheel Cap

W1011793



Meter Panel

1. Disconnect the main switch connector and combination switch connector (7).
2. Remove the hand accelerator lever grip and cruise control lever knob.
3. Disconnect the hand accelerator wire (3) and then turn the hand accelerator lever (2) to the operator seat side.
4. Open the bonnet, remove the panel mounting screws and dismount the meter panel.

(1) Meter panel

(2) Hand Accelerator Lever

(3) Hand Accelerator Wire


(4) Cruise Control Lever

(5) Main Switch

(6) Combination Switch

(7) Connector for Combination Switch

W1011901



Steering Controller

1. Disconnect the power steering hoses (1), (2), (3), (4).
2. Remove the steering controller mounting screws and remove the steering controller (5).

(When reassembling)

- Be sure to connect the power steering hoses to their original position, and tighten them to the specified torque.

Tightening torque	Power steering hose mounting nut	28.4 to 30.0 N·m 2.9 to 3.1 kgf·m 20.9 to 22.1 lbf·ft
-------------------	----------------------------------	---

(1) Cylinder Hose RH

(2) Cylinder Hose LH

(3) Delivery Hose

(4) Return Hose

(5) Steering Controller

A : Bottom View

P : Pump Port
(Connect to Delivery Hose)

T : Tank Port
(Connect to Return Hose)


L : L Port
(Connect to Cylinder LH Hose)

R : R Port
(Connect to Cylinder RH Hose)





a : Right

b : Front

W1012133



(2) Separating Power Steering Cylinder



Bonnet and Under Cover

1. Open the bonnet (1), and then loosen the bolts and pull forward to remove the under cover (2).
2. Disconnect the connectors (3) for head light and remove the bonnet bracket (4) with bonnet.

- (1) Bonnet (3) Connector
(2) Under Cover (4) Bonnet Bracket

W1014028

Front Axle Assembly

1. Remove the power steering hose clamp (1).
2. Place the garage jack under the front axle.
3. Remove the cotter pin (2).
4. Remove the slotted nut (3) of center pin and separate the front axle from the frame.
5. Disconnect the power steering cylinder hoses (4).


(When reassembling)

- After mounting the front axle assembly to the frame, be sure to adjust the front axle rocking force. (See page 3-S4.)
- Installing the cotter pin and be sure to split the cotter pin like an anchor

Tightening torque	Power steering cylinder hose	23.6 to 27.4 N·m 2.4 to 2.8 kgf·m 17.4 to 20.2 lbf·ft
-------------------	------------------------------	---

- (1) Hose Clamp (3) Slotted Nut (Adjusting Nut for Front Axle Rocking Force)
(2) Cotter Pin (4) Power Steering Hose

W1016448



Power Steering Cylinder

1. Remove the cotter pin and remove the slotted nut for tie-rod (1).
2. Remove the power steering cylinder mounting screws and remove the power steering cylinder (2) with tie-rod.

(When reassembling)

NOTE

- Tighten the slotted nut to 17.7 N·m (1.8 kgf·m, 13 lbf·ft). If the slot and pin hole do not meet, tighten the nut until they do meet, and install the cotter pin.
- Be sure to split the cotter pin like an anchor.

Tightening torque	Tie-rod slotted nut	17.7 to 34.3 N·m 1.8 to 3.5 kgf·m 13.0 to 25.3 lbf·ft
	Power steering cylinder mounting screw	48.1 to 55.8 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 lbf·ft





(1) Tie-rod

(2) Power Steering Cylinder

W1016645

[3] DISASSEMBLING AND ASSEMBLING

(1) Power Steering Cylinder



Adaptor and Tie-rod

1. Remove the cylinder hose adaptors (4), (6).
2. Remove the tie-rods (2), (8) from piston rod (7).
3. Remove the cylinder holder (1) and internal snap ring (3).

(When reassembling)

- Be sure to install the hose adaptors (4), (6) as shown figure left.
- After reassembling the tie-rod, be sure to adjust the toe-in. (Refer to 3-S4.)

Tightening torque	Tie-rod screw	74 to 84 N·m 7.5 to 8.6 kgf·m 54.6 to 61.9 lbf·ft
-------------------	---------------	---

- | | |
|------------------------|---------------------------|
| (1) Cylinder Holder | (7) Piston Rod |
| (2) Tie-rod RH | (8) Tie-rod LH |
| (3) Internal Snap Ring | |
| (4) Hose Adaptor RH | A : 0.26 rad (15°) |
| (5) Cylinder | B : Front |
| (6) Hose Adaptor LH | |

W1012941

Steering Cylinder

1. Carefully clamp the cylinder in a vise.
2. Push one of the guide assembly (3) to inside of cylinder tube (2).
3. Drill a hole (2.5 mm dia., 0.1 in. dia.) on the cylinder tube (2) just over the snap ring (4) as shown figure left.
4. Take a little screwdriver and lift off the snap ring (4) from its groove. Simultaneously support this action by pushing from the outside of the cylinder tube with another little screwdriver or another tool.
5. Push out the piston rod assembly (9) and take off the guide assembly (3).

(When reassembling)


■ NOTE

- **Seals must be exchanged after disassembling.**
- **Apply transmission fluid to the exchanged seals.**
- **Enter the piston rod and block the guide assemblies with the snap rings.**

- | | |
|--------------------|--------------------------------|
| (1) Piston Rod | (8) O-ring |
| (2) Cylinder Tube | (9) Piston Rod Assembly |
| (3) Guide Assembly | (10) Center Piston |
| (4) Snap Ring | |
| (5) Guide | A : Drill a Hole |
| (6) Seal Ring | B : 5.25 mm (0.267 in.) |
| (7) Wiper Ring | |

W1013441

[4] SERVICING




Steering Cylinder I.D.

1. Measure the steering cylinder I.D. with a cylinder gauge.
2. If the cylinder I.D. exceed the allowable limit, replace the cylinder barrel.

Steering cylinder I.D.	Factory specification	40.000 to 40.062 mm 1.57480 to 1.57724 in.
	Allowable limit	40.100 mm 1.57874 in.

W1013872



Clearance between Rod and Guide

1. Measure the rod guide I.D. with a cylinder gauge.
2. Measure the rod O.D. with an outside micrometer, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace as a unit.

Clearance between rod and guide	Factory specification	0.020 to 0.070 mm 0.00079 to 0.00276 in.
	Allowable limit	0.200 mm 0.00787 in.

W1013777


5 HYDRAULIC SYSTEM

MECHANISM

CONTENTS

1. HYDRAULIC CIRCUIT	5-M1
2. HYDRAULIC PUMP	5-M2
3. CONTROL VALVE	5-M3
4. FLOW PRIORITY VALVE	5-M6
5. RELIEF VALVE	5-M7
6. HYDRAULIC CYLINDER	5-M9
7. HYDRAULIC BLOCK AND AUXILIARY CONTROL VALVE.....	5-M10
8. MOWER LINKAGE	5-M11

1. HYDRAULIC CIRCUIT



- (1) Power Steering Controller
- (2) PTO Clutch
- (3) PTO Clutch Valve
- (4) PTO Clutch Relief Valve
- (5) Oil Filter
- (6) Hydrostatic Transmission
- (7) Flow Priority Valve

- (8) Relief Valve
- (9) Hydraulic Pump
- (10) Oil Strainer
- (11) Hydraulic Block Type Outlet
- (12) Hydraulic Cylinder
- (13) Control Valve

- (14) Auxiliary Control Valve
- (15) Front Loader Control Valve
- (16) Bucket Cylinder
- (17) Boom Cylinder
- (18) Grass Collector Cylinder
- (19) High Dump Cylinder



- P : P Port (Pump)**
- PB : PB Port (Power Beyond)**
- T : T Port (Tank)**
- 1A, 1B, 2A, 2B : Port for Front Loader**
- SA, SB, DA, DB : Port for Auxiliary Control Valve**

The hydraulic system of this tractor is composed of a hydraulic pump, hydraulic block type outlet, control valve, hydraulic cylinder and other components.

This system has the following functions.

1. Oil is supplied by hydraulic pump which is driven by pump drive shaft in the transmission case. As the pump drive shaft is connected to the propeller shaft, hydraulic pump starts running when engine is started.
2. The hydraulic pump supplies the high pressured oil to control valve for 3 point hitch system, power steering controller, PTO clutch valve and hydrostatic transmission after dividing oil flow by flow priority valve.
3. Hydraulic power take off from the hydraulic block type outlet to operate the implements such as a front loader and so on.

2. HYDRAULIC PUMP



The hydraulic pump is composed of the casing (1), cover (4), side plate (3), and two spur gears (drive gear (5) and driven gear (2) that are in mesh.

Hydraulic pump is driven by the pump drive shaft in the transmission case.

Maximum displacement is as follows.

Displacement	Engine speed	Condition
23.5 L/min. 6.2 U.S.gals/min. 5.2 Imp.gals/min.	At 3200 min ⁻¹ (rpm)	at no load

- (1) Casing

(2) Driven Gear

(3) Side Plate

(4) Cover
- (5) Drive Gear

(6) Pin

(7) Oil Seal

W1013860

3. CONTROL VALVE



This position control valve is located under the hydraulic cylinder.

This control valve is mechanically connected to the position control lever.

Since the feedback rod is not equipped to the lift arm, the neutral position adjustment is adjusted by controlling the position control lever.

The control valve controls the oil flow forced from the hydraulic pump and the oil returned back from the hydraulic cylinder.

■ Neutral



When stopping the position control lever, the spool is stopped.

The spool closes the oil flow from passage between **P** port and **C** port.



Since the oil in the hydraulic cylinder is not drained to **T2** port, "**Neutral**" position is kept.

- (1) Lift Arm
- (2) Hydraulic Cylinder
- (3) Control Valve
- (4) Spool
- (5) Lowering Adjusting Shaft

P : Pump Port
C : Cylinder Port
T1 : Tank Port
T2 : Tank Port

W1015913

■ Lift



When the control lever is set to the “**Lift**” position, the spool (4) moves to the right.

The oil forced into the control valve flows through **P** port to **C** port and the hydraulic cylinder.

The oil pushes the hydraulic piston in the hydraulic cylinder to lift the implement.

Since the spool shape is step down structure, oil passes slowly through the gap between the control valve body (3) and the spool (4) to **C** port.



In this tractor, when setting the control lever to the “**Slow up**”, implement lifts up with ease in increments of approximately 1/4 inches at lower link end.

- (1) Lift Arm
- (2) Hydraulic Cylinder
- (3) Control Valve
- (4) Spool
- (5) Lowering Adjusting Shaft

P : Pump Port
C : Cylinder Port
T1 : Tank Port
T2 : Tank Port

W1016112

■ Down



When the control lever is set to the “**Down**” position, the spool (4) moves to the left.

The oil forced from the **P** port flows through the gap between the control valve body and the spool to the **T1** port.

The oil in the hydraulic cylinder flows through the gap between the control valve body (3) and the spool (4) to the **T2** port.

Since the oil in the hydraulic cylinder drains to the transmission case, the implement lowers.

Since the spool shape is step down structure, oil pass slowly from **C** port through the gap between the control valve body (3) and the spool (4) to **T2** port.


In this tractor, when setting the control lever to the “**Slow down**” position, implement lowers down with ease in increments of approximately 1/4 inches at lower link end.

- (1) Lift Arm
- (2) Hydraulic Cylinder
- (3) Control Valve
- (4) Spool
- (5) Lowering Adjusting Shaft

P : Pump Port
C : Cylinder Port
T1 : Tank Port
T2 : Tank Port

W1016319

4. FLOW PRIORITY VALVE



- (1) Hydraulic Pump Gear
- (2) Hydraulic Pump Case
- (3) Plug
- (4) Flow Priority Valve
- (5) Relief Valve

EF :EF Port (To 3 Points Hitch Control Circuit)

PF :PF Port (To Power Steering, PTO Clutch and HST Circuit)

P : Pump Port (Suction)


T : Tank Port

W1014933

The flow priority valve is a flow divider that divides single hydraulic source (hydraulic pump) to actuates two circuits simultaneously.

This valve feeds fixedly controlled flow (9.5 L/min., 2.5 U.S.gals./min., 2.1 Imp.gals./min.) to the **PF** port with priority and excessive flow to the **EF** port.

5. RELIEF VALVE




The implement control system circuit has a relief valve to restrict the maximum pressure in the circuit. The relief valve is located in the hydraulic control valve assembly.

The relief valve is a guide piston type with damping effect.

Among direct acting relief valves, this type is suited to higher pressure and has large capacity. Furthermore, this type is free from unstable operation, such as chattering, which occurs often in direct acting relief valves.

As shown in the figure, the guide is attached to the poppet (7) and a valve chamber **D.C.** (called the damping chamber) is formed at the top of the guide piston. The inlet of the valve leads to the chamber via a clearance between the sliding portion of the guide and the seat (6), minimizing valve vibration with the damping effect of the chamber.

■ Relief Valve Operating



- (1) Hydraulic Pump Gear
- (2) Hydraulic Pump Case
- (3) Plug
- (4) Flow Priority Valve
- (5) Relief Valve

EF :EF Port (To 3 Points Hitch Control Circuit)

PF :PF Port (To Power Steering, PTO Clutch and HST Circuit)

D.C.:Damping Chamber

P : Pump Port (Suction)

T : Tank Ports

W1016573


When the oil pressure in the circuit is lower than the setting pressure of the relief valve, the relief valve is not operated and the oil fed to the relief valve from the hydraulic pump flows into the implement control valve.

As the oil pressure in the circuit increases, so does the pressure in the damping chamber **D.C.**. When the pressure rises above the valve setting and overcomes the spring force, the valve opens. Oil then flows out to the transmission case through **T** port, preventing any further rise in pressure. The valve closes again when enough oil is released to drop pressure below the valve setting.

(Reference)

- Relief valve setting pressure : 12.3 to 12.7 MPa (125 to 130 kgf/cm², 1778 to 1849 psi)
- Engine speed : Maximum
- Oil temperature : 40 to 50 °C (104 to 122 °F)

6. HYDRAULIC CYLINDER



- (1) Lift Arm
- (2) Hydraulic Arm
- (3) Hydraulic Arm Shaft
- (4) Hydraulic Rod

- (5) Piston
- (6) Spring
- (7) Ball
- (8) Lowering Speed Adjusting Shaft

- (9) Back-up Ring
- (10) O-ring
- (11) Hydraulic Cylinder
- (12) Control Valve


P : Pump Port
C : Cylinder Port

The main components of the hydraulic cylinder are shown in the figure above.

While the lift arm (1) is rising, oil from the hydraulic pump flows into the hydraulic cylinder through the hydraulic control valve (12) and cylinder port (C). Then oil pushes out the piston (5).

While the lift arm (1) is lowering, oil in the hydraulic cylinder is discharged to the transmission case through the hydraulic control valve by the weight of the implement. At this time, the lowering speed of the implement can be controlled by the ball (7) attached to the hydraulic cylinder (11). Turning the lowering speed adjusting knob clockwise decreases the lowering speed, and counterclockwise increases lowering speed. When the lowering speed adjusting valve is completely closed, the lift arm (1) is held at its position since oil in the hydraulic cylinder is sealed between the piston (5) and ball (7).

7. HYDRAULIC BLOCK AND AUXILIARY CONTROL VALVE



The hydraulic block type outlet is located on the hydraulic cylinder assembly.

This hydraulic block type outlet is provided to take power out from the tractor to operate the hydraulic cylinders on the implement, such as front end loader, front snow blade and so on.

- (1) Block Cover
- (2) Hydraulic Cylinder
- (3) Hydraulic Block
- (4) Auxiliary Control Valve

A : When Loader Valve is not Attached

B : When Loader Valve is Attached

C : To Transmission Case

D : To Implement

E : From Implement


P : P Port (Pump)

PB : PB Port (Power Beyond)


SA, SB : Port for Grass Collector

DA, DB : Port for High Dump

W1014064



8. MOWER LINKAGE



- | | | | |
|------------------------|-----------------------------------|---------------------|----------------------|
| (1) Mower Rear Link RH | (4) Rear Lift Link LH | (7) Lift Arm | (10) Lift Lower Boss |
| (2) Lift Pin | (5) Cutting Height Adjusting Dial | (8) Adjusting Bolt | (11) Cam |
| (3) Mower Rear Link LH | (6) Rear Lift Link LH | (9) Lift Upper Boss | |

The mower rear link (1), (3) and the lift arm (7) are linked with the rear lift link LH (4), the lift upper boss (9) and the lift lower boss (10).

As the hydraulic control lever moves to lift position, lift arm (7) is raised and the rear lift link LH (6) is pulled to pull the lift links to the rearward. As a result, mower rear link (1), (3) are lifted.

The cutting height adjusting dial (5) adjusts cutting height of mower by rotating the adjusting cam (11). The position of mower rear link (1), (3) are adjusted by changing the length of the adjusting bolt (8).

SERVICING

CONTENTS

1. TROUBLESHOOTING	5-S1
2. SERVICING SPECIFICATIONS	5-S2
3. TIGHTENING TORQUES	5-S3
4. CHECKING, DISASSEMBLING AND SERVICING.....	5-S4
[1] CHECKING AND ADJUSTING	5-S4
(1) Relief Valve	5-S4
(2) Pump and Priority Valve	5-S5
(3) Mower Lift Linkage	5-S6
[2] PREPARATION	5-S7
(1) Separating Hydraulic Cylinder	5-S7
(2) Separating Hydraulic Pump	5-S11
[3] DISASSEMBLING AND ASSEMBLING.....	5-S16
(1) Hydraulic Cylinder and Control Valve	5-S16
(2) Mower Lift Linkage	5-S18
[4] SERVICING	5-S19
(1) Hydraulic Pump.....	5-S19
(2) Hydraulic Cylinder	5-S20

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Implement Does Not Rise (No Noise)	Control valve broken	Replace	5-S16
	Control valve improperly assembled	Repair	5-S16
	Relief valve spring damaged	Replace	5-S4
	Spool sticks	Repair	5-S16
	Piston O-ring or cylinder damaged	Replace	5-S17
Implement Does Not Rise (Noise)	Oil filter cartridge clogged	Replace	G-13
	Suction pipe loosen or broken	Repair or replace	–
	Suction pipe connecting hose loosen or broken	Repair or replace	–
	Suction pipe O-ring broken	Replace	–
	Insufficient transmission oil	Refill	G-13
	Relief valve setting pressure too low	Adjust or replace	5-S4
	Hydraulic pump broken	Replace	5-S15
Implement Does Not Lower	Control valve malfunctioning	Repair or replace	5-S16
Implement Drops by Its Weight	Hydraulic cylinder worn or damaged	Replace	5-S16
	Piston O-ring worn or damaged	Replace	5-S17
	Control valve malfunctioning	Replace	5-S16

W1014322

2. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Relief Valve	Setting Pressure	12.3 to 12.7 MPa 125 to 130 kgf/cm ² 1778 to 1849 psi	—
Hydraulic Pump	Power steering oil flow	9.5 L/min. 2.5 U.S.gals/min. 2.1 Imp.gals/min.	—
Mower Linkage	Clearance L2	0 to 0.5 mm 0 to 0.019 in.	—
[Hydraulic Pump] Gear to Casing	Clearance	—	0.15 mm 0.0059 in.
Gear	O.D.	33.520 to 33.530 mm 1.3197 to 1.3200 in.	—
Case	I.D.	33.570 to 33.577 mm 1.3217 to 1.3219	—
Gear Shaft to Bushing	Clearance	0.020 to 0.091 mm 0.0008 to 0.0036 in.	0.12 mm 0.0047 in.
Gear Shaft	O.D.	14.970 to 14.980 mm 0.5894 to 0.5898 in.	—
Bushing	I.D.	15.000 to 15.061 mm 0.5906 to 0.5930 in.	—
Side Plate	Thickness	2.48 to 2.50 mm 0.0976 to 0.0984 in.	2.40 mm 0.0945 in.
Hydraulic Cylinder	I.D.	80.05 to 80.15 mm 3.1516 to 3.1555 in.	80.2 mm 3.1575 in.

W1013874

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-8.)



Item	N·m	kgf·m	lbf·ft
ROPS mounting nut	124 to 147	12.6 to 15.0	91.2 to 108
Fuel tank stay mounting bolt and nut	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Fender bracket mounting bolt	124 to 147	12.6 to 15.0	91.2 to 108
Hydraulic cylinder block mounting bolt	39.2 to 44.1	4.0 to 4.5	28.9 to 32.5
Hydraulic pump mounting bolt (M6)	8.0 to 9.0	0.82 to 0.91	6.0 to 6.6
Hydraulic pump mounting bolt (M8)	18.0 to 21.0	1.84 to 2.14	13.3 to 15.4

W1012736

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING

(1) Relief Valve



Relief Valve Setting Pressure

- 1. Install a pressure gauge to **SA** port (1).
- 2. Start the engine and set at maximum speed.
- 3. Move the auxiliary control lever (2) all way up to operate the relief valve and read the gauge.
- 4. If the pressure is not within the factory specifications, adjust with the adjusting shim (4).

Relief valve setting pressure	Factory specification	12.3 to 12.7 MPa 125 to 130 kgf/cm ² 1778 to 1849 psi
-------------------------------	-----------------------	--

Condition

- Engine speed : Maximum
- Oil temperature : 45 to 55 °C (113 to 131 °F)

(Reference)

- Thickness of shim (4) :
0.1 mm (0.0039 in.), 0.2 mm (0.0079 in.), 0.4 mm (0.0157 in.)
- 0.27 MPa (2.74 kgf/cm², 39.0 psi) pressure is increased whenever the thickness of adjusting shim is increased by 0.1 mm (0.0039 in.).


- (1) SA Port

(2) Auxiliary Control Lever
- (3) Relief Valve

(4) Shim

W1011231

(2) Pump and Priority Valve



Checking Hydraulic Oil Flow

■ IMPORTANT

- Use the instruction with the flowmeter when you use the flowmeter.
- While testing, do not close the flowmeter loading valve completely.

■ NOTE

- To measure the flow volume of pump, oil flow on the power steering system side should be stopped.

1. Remove the pump hose and plug in.
2. Remove the pipe and fix the hose and the flow meter as shown in the photo.

■ Measure the flow volume of power steering.

1. Make sure that the flow volume of pump is 10 L (2.6 U.S.gals, 2.2 Imp.gals) or higher and verify the content below.
If the flow volume is insufficient, measure it after replacing the pump as its priority-valve is unreadable of its condition.
2. After measuring the flow volume, remove the flow meter then reassembling the steering hose.
3. Remove the plug, then fix the hose and the flowmeter.
4. Check that a flow volume meets the specifications when the engine revolution is 2000 min⁻¹ (rpm).
5. If the flow volume varies from the specification, replace the priority valve then take measurement again.

Condition

- Engine speed : 2000 min⁻¹ (rpm)
- Oil temperature : 45 to 55 °C (113 to 131 °F)

Power steering oil flow	Factory specification	9.5 L/min. 2.5 U.S.gals/min. 2.1 Imp.gals/min.
-------------------------	-----------------------	--

(Reference)

- Pump Oil Flow

Hydraulic pump delivery at no pressure	Factory specification	24.9 L/min. 6.6 U.S.gals/min. 5.5 Imp.gals/min.
--	-----------------------	---

Condition

- Engine speed : Maximum
- Oil temperature : 45 to 55 °C (113 to 131 °F)




(1) Pump Hose

(A) Pump Oil Flow

(B) Power Steering Oil Flow

W1019335

(3) Mower Lift Linkage



Mower Lift Linkage

After reassembling the mower lift linkage, be sure to adjust it as follows.

- 1. Check the lift arm free play.
- 2. Loosen the adjusting nut (1) and start the engine.
- 3. Move the hydraulic control lever to **Lift** position until the relief valve operating. (**Uppermost** position)
- 4. Adjusting bolt (2) until the clearance between stopper and mower rear link **LH** gets 0 to 0.5 mm (0 to 0.019 in.)
- 5. Secure the lock nut (1).

Clearance L2	Factory specification	0 to 0.5 mm 0 to 0.019 in.
--------------	-----------------------	-------------------------------

(Reference)

Length L1	Factory specification	17 mm 0.669 in.
-----------	-----------------------	--------------------





- (1) Nut
- (2) Bolt

(A) Upper View
L1 :Length
L2 :Clearance

W1020018

[2] PREPARATION

(1) Separating Hydraulic Cylinder



Battery Cables and Battery



CAUTION

- When disconnecting the battery cables, disconnect the negative cable from the battery first. When connecting, connect the positive cable to the battery first.

1. Remove the under panel and the battery cover.
2. Disconnect the negative cable (2) from the battery (1).
3. Disconnect the positive cable (3) from the battery (1) and remove the battery (1).

(1) Battery

(2) Negative cable

(3) Positive Cable

W1016078

Lift Rod and Lower Link

1. Remove the top link (2).
2. Remove the stopper pin (6) and remove the check chain plate (3).
3. Move the bushes (8) to inside.
4. Move the shaft (9) to right side and remove the lower link as a unit.

(1) Lift Rod LH

(2) Top Link

(3) Check Chain Plate

(4) Lift Rod RH

(5) Lower Link RH


(6) Stopper Pin

(7) Lower Link LH

(8) Bush

(9) Shaft

W1016481



- Roll-Over Protective Structures (ROPS)**
1. Disconnect the lead wires from the combination lamp (2), (4) and the beacon switch (5).
 2. Remove the ROPS mounting nuts, and remove the ROPS (1).
- (When reassembling)**

Tightening torque	ROPS mounting nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.2 to 108 lbf·ft
-------------------	-------------------	--

- (1) ROPS

(2) Beacon Light

(3) Combination Lamp, RH
- (4) Combination Lamp, LH

(5) Beacon Switch

W1016892




Seat

1. Remove the snap pins (2) to remove the seat (1).
2. Remove the seat (1).

(1) Seat

(2) Snap Pin

W1014409



Speed Control Pedal and Step


1. Remove the valve covers (3).
2. Remove the speed control pedals (1) and step (2).

(1) Speed Control Pedal

(3) Valve Cover

(2) Step

W1014726



Lever Grips and Fender

1. Remove the lever grips (2). Remove the emergency brake lever stay.
2. Remove the lowering speed adjusting knob (5) and the cutting height adjusting dial knob (4).
3. Disconnect the DC outlet (6).
4. Remove the fender (1) with the lever guide (3).

(1) Fender

(4) Cutting Height Adjusting Dial Knob





(2) Lever Grip

(5) Lowering Speed Adjusting Knob

(3) Lever Guide

(6) DC Outlet

W1014865



Fuel Tank

- 1. Drain the fuel, and remove the seat mat (2).
- 2. Disconnect the lead wire from fuel level sensor and fuel hoses from the fuel tank (1).
- 3. Remove the fuel tank stays (3), (4) and cushions, then remove the fuel tank (1).

(When reassembling)

Tightening torque	Fuel tank stay mounting bolt and nut	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 lbf·ft
-------------------	--------------------------------------	---

- (1) Fuel Tank
- (2) Seat Mat
- (3) Fuel Tank Stay LH
- (4) Fuel Tank Stay RH


W1017535

Mower Linkage and Wire harness

- 1. Disconnect the mower linkage (2).
- 2. Remove the wire harness clamp and wire harness (1), and move to the front side.

- (1) Wire harness
- (2) Mower Linkage

W1027951



Hydraulic Cylinder Block

1. Remove the hydraulic pipe (1).
2. Remove the hydraulic cylinder block mounting bolt.
3. Remove the hydraulic cylinder block (2).


(When reassembling)

Tightening torque	Hydraulic cylinder block mounting bolt	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 28.9 to 32.5 lbf·ft
-------------------	--	---


(1) Hydraulic Pipe

(2) Hydraulic Cylinder Block

W1028149



(2) Separating Hydraulic Pump



Battery Cables and Battery



CAUTION

- When disconnecting the battery cables, disconnect the negative cable from the battery first. When connecting, connect the positive cable to the battery first.


1. Remove the under panel and the battery cover.
2. Disconnect the negative cable (2) from the battery (1).
3. Disconnect the positive cable (3) from the battery (1) and remove the battery (1).


(1) Battery

(2) Negative cable

(3) Positive Cable

W1020555






Lift Rod and Lower Link

1. Remove the top link (2).
2. Remove the stopper pin (6) and remove the check chain plate (3).
3. Move the bushes (8) to inside.
4. Move the shaft (9) to right side and remove the lower link as a unit.

- | | |
|-----------------------|-------------------|
| (1) Lift Rod LH | (6) Stopper Pin |
| (2) Top Link | (7) Lower Link LH |
| (3) Check Chain Plate | (8) Bush |
| (4) Lift Rod RH | (9) Shaft |
| (5) Lower Link RH | |

W1020865



Roll-Over Protective Structures (ROPS)


1. Disconnect the lead wires from the combination lamp (2), (4) and the beacon switch (5).
2. Remove the ROPS mounting nuts, and remove the ROPS (1).

(When reassembling)

Tightening torque	ROPS mounting nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.2 to 108 lbf·ft
-------------------	-------------------	--

- | | |
|--------------------------|--------------------------|
| (1) ROPS | (4) Combination Lamp, LH |
| (2) Beacon Light | (5) Beacon Switch |
| (3) Combination Lamp, RH | |

W1021200






Seat

1. Remove the snap pins (2) to remove the seat (1).
2. Remove the seat (1).

(1) Seat

(2) Snap Pin

W1021516



Speed Control Pedal and Step


1. Remove the valve covers (3).
2. Remove the speed control pedals (1) and step (2).

(1) Speed Control Pedal

(3) Valve Cover

(2) Step

W1021639



Lever Grips and Fender

1. Remove the lever grips (2). Remove the emergency brake lever stay.
2. Remove the lowering speed adjusting knob (5) and cutting height adjusting dial knob (4).
3. Disconnect the DC outlet (6).
4. Remove the fender (1) with the lever guide (3).

(1) Fender

(4) Cutting Height Adjusting Dial Knob


(2) Lever Grip

(5) Lowering Speed Adjusting Knob

(3) Lever Guide

(6) DC Outlet

W1021763



Fuel Tank

1. Drain the fuel, remove the seat mat (2).
2. Disconnect the lead wire from fuel level sensor and fuel hoses from the fuel tank (1).
3. Remove the fuel tank stays (3), (4) and cushions, then remove the fuel tank (1).



(When reassembling)




Tightening torque	Fuel tank stay mounting bolt and nut	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 lbf·ft
-------------------	--------------------------------------	---

- (1) Fuel Tank
(2) Seat Mat

- (3) Fuel Tank Stay LH
(4) Fuel Tank Stay RH

W1019029





Hydraulic Pump

- 1. Disconnect the mower linkage (4).
- 2. Remove the lift arm LH (3).
- 3. Remove the hydraulic pipes (1).
- 4. Remove the hydraulic pump (2).

Tightening torque	Hydraulic pump mounting bolt (M6)	8.0 to 9.0 N·m 0.82 to 0.91 kgf·m 6.0 to 6.6 lbf·ft
	Hydraulic pump mounting bolt (M8)	18.0 to 21.0 N·m 1.84 to 2.14 kgf·m 13.3 to 15.4 lbf·ft

(When reassembling)

- Since the mounting bolt (5) is installed through the transaxle case to the transmission oil tank, seal the sealing tape to the mounting bolt (5) securely.

- (1) Hydraulic Pipe

(2) Hydraulic Pump

(3) Lift Arm LH

(4) Mower Linkage
- (5) Bolt (M8) (Through Bolt)


(6) Bolt (M6)

(7) Bolt (M8)

W1029558

[3] DISASSEMBLING AND ASSEMBLING

(1) Hydraulic Cylinder and Control Valve





Control Valve

1. Remove the control valve (1).
2. Remove the internal snap ring (4) and draw out the spool (2).

- | | |
|-------------------|------------------------|
| (1) Control Valve | (3) Plain Washer |
| (2) Spool | (4) Internal Snap Ring |

W1030131




Control Valve Lever

1. Pull out the pin (1).
2. Remove the control valve lever (3) and arm (2).

- | | |
|---------|-------------------------|
| (1) Pin | (3) Control Valve Lever |
| (2) Arm | |

W1030453



Lift Arm, Hydraulic Arm Shaft and Hydraulic Arm


1. Remove the external snap rings (8), (10), and remove the lift arms (2), (7).
2. Draw out the hydraulic arm shaft (4).

(When reassembling)

- Align the alignment marks of the hydraulic arm (2) and hydraulic arm shaft (4).
- Align the alignment marks of the lift arms (2), (7) and hydraulic arm shaft (4).
- Apply grease to the right and left bushings and O-rings.
- Take care not to damage the O-ring.

- | | |
|------------------------------|-------------------------|
| (1) Hydraulic Cylinder Block | (6) O-ring |
| (2) Lift Arm LH | (7) Lift Arm RH |
| (3) O-ring | (8) External Snap Ring |
| (4) Hydraulic Arm Shaft | (9) Cover |
| (5) Hydraulic Arm | (10) External Snap Ring |

W1031001



Hydraulic Piston

1. Inject the compressed air into the hydraulic cylinder, and take out the hydraulic piston (1).



(When reassembling)

- Take care not to damage the O-ring (3) and backup ring (2).
- Apply transmission fluid to the O-ring.
- Replace the O-ring if it is defective, worn or scratched, which may cause oil leakage.

- (1) Hydraulic Piston
(2) Back-up Ring

- (3) O-ring

W1031555



Lowering Speed Adjusting Valve

1. Remove the internal snap ring (5) and remove the lowering speed adjusting shaft (6).
2. Remove the ball (2) and spring (1).

(When reassembling)

- Take care not to damage the O-rings.


- (1) Spring
(2) Ball
(3) O-ring

- (4) Stopper
(5) Internal Snap Ring
(6) Lowering Speed Adjusting Shaft

W1032074

(2) Mower Lift Linkage

Disassembling Mower Linkage



- (1) Mower Rear Link, RH
- (2) Lift Link Rear, RH
- (3) Cutting Height Adjusting Dial Knob
- (4) Cutting Height Adjusting Rod
- (5) Lift Arm, LH
- (6) Link Adjusting Bolt
- (7) Lift Link Rear, LH
- (8) Mower Rear Link, LH
- (9) Adjusting Cam

W1032616

3TAAAAG8P017A

1. Remove the clevis pin and remove the mower rear link (7).
2. Remove the pin and remove the mower rear links (1), (8).
3. Remove both side of boss and remove the lift link rear RH (2).
4. Remove the cutting height adjusting dial knob (8).
5. Remove the nut and remove the adjusting cam (12) and cutting height adjusting rod (10).



(When reassembling)

- Adjust the length of the link adjusting bolt. (Refer to page 5-S6.)

W1032750

[4] SERVICING

(1) Hydraulic Pump



Clearance between Tip of Gear Tooth and Casing

1. Measure the gear O.D. with an outside micrometer.
2. Measure the casing I.D. with a cylinder gauge and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace the assembly.

Clearance between tip of gear tooth and casing	Allowable limit	0.15 mm 0.0059 in.
--	-----------------	-----------------------

Gear O.D.	Factory specification	33.520 to 33.530 mm 1.3197 to 1.3200 in.
-----------	-----------------------	---

Case I.D.	Factory specification	33.570 to 33.577 mm 1.3217 to 1.3219 in.
-----------	-----------------------	---

W1015764

Clearance between Bushing and Shaft

1. Measure the gear shaft O.D. with an outside micrometer.
2. Measure the bushing I.D. with a cylinder gauge and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace it.

Clearance between bushing and shaft	Factory specification	0.020 to 0.091 mm 0.0008 to 0.0036 in.
	Allowable limit	0.12 mm 0.0047 in.

Shaft O.D.	Factory specification	14.970 to 14.980 mm 0.5894 to 0.5898 in.
------------	-----------------------	---

Bushing I.D.	Factory specification	15.000 to 15.061 mm 0.5906 to 0.5930 in.
--------------	-----------------------	---

W1015972

Side Plate Thickness

1. Measure the side plate thickness with an outside micrometer.
2. If the thickness is less than the allowable limit, replace it.

Side plate thickness	Factory specification	2.48 to 2.50 mm 0.0976 to 0.0984 in.
	Allowable limit	2.40 mm 0.0945 in.

W1016194

(2) Hydraulic Cylinder



Hydraulic Cylinder Bore

1. Check the cylinder internal surface for scoring or damage.
2. Measure the cylinder I.D. with a cylinder gauge.
3. If the measurement exceeds the allowable limit, replace the hydraulic cylinder block.

Cylinder I.D.	Factory specification	80.05 to 80.15 mm 3.1516 to 3.1555 in.
	Allowable limit	80.2 mm 3.1575 in.

W10171300



Hydraulic Arm Shaft Bushing

1. Visually inspect the DX bushings for signs of wear or damage.
(The DX bushing tends to show concentrated wear.)
2. If the DX bushing is worn beyond the alloy thickness (**A**), replace it.


(Reference)

Hydraulic arm shaft bushing	Alloy thickness (A)	0.57 mm 0.0224 in.
-----------------------------	------------------------------	-----------------------

Hydraulic arm shaft	LH	O.D.	31.925 to 31.950 mm 1.2569 to 1.2579 in.
	RH	O.D.	29.925 to 29.950 mm 1.1781 to 1.1791 in.

A : Alloy Thickness
L : Outside Diameter

W1016329



6 ELECTRICAL SYSTEM


MECHANISM

CONTENTS


1. WIRING DIAGRAM	6-M1
[1] BX2350D WITHOUT OPC (SERIAL NUMBER : Below 64999).....	6-M1
[2] BX2350D WITH OPC (SERIAL NUMBER : Above 65000).....	6-M2
2. STARTING SYSTEM	6-M3
[1] ELECTRICAL CIRCUIT	6-M3
(1) BX2350D without OPC System	6-M3
(2) BX2350D with OPC System	6-M4
[2] SAFETY SWITCH	6-M5
(1) BX2350D without OPC System	6-M5
(2) BX2350D with OPC System	6-M5
3. OPERATOR PRESENCE CONTROL (OPC) SYSTEM.....	6-M8
[1] ELECTRICAL CIRCUIT	6-M8
[2] OPC TIMER RELAY	6-M9
[3] SEAT SWITCH.....	6-M9
4. STATIONARY PTO CONTROL SYSTEM.....	6-M10
[1] ELECTRICAL CIRCUIT	6-M10
[2] SAFETY SWITCH FOR STATIONARY PTO CONTROL SYSTEM.....	6-M11
5. CHARGING SYSTEM	6-M13
[1] ELECTRICAL CIRCUIT	6-M13
[2] IC REGULATOR (3P CONNECTOR TYPE).....	6-M14
6. LIGHTING SYSTEM	6-M15
7. GAUGES	6-M16
[1] ELECTRICAL CIRCUIT	6-M16
[2] HOUR AND TACHOMETER.....	6-M17
[3] FUEL LEVEL GAUGE.....	6-M17
[4] WATER TEMPERATURE GAUGE	6-M18
8. OTHERS	6-M19
[1] DC OUTLET	6-M19

1. WIRING DIAGRAM

[1] BX2350D WITHOUT OPC (SERIAL NUMBER : Below 64999)




[2] BX2350D WITH OPC (SERIAL NUMBER : Above 65000)



2. STARTING SYSTEM

[1] ELECTRICAL CIRCUIT

(1) BX2350D without OPC System




- | | | | |
|--------------------|-----------------|------------------------|------------------------------|
| (1) Glow Lamp | (5) Fuse | (9) HST Neutral Switch | (13) Engine Stop Timer Relay |
| (2) Alternator | (6) Fuse | (10) Starter Motor | (14) Solenoid |
| (3) Fuel Pump | (7) Main Switch | (11) Battery | (15) Frame Earth |
| (4) Slow Blow Fuse | (8) PTO Switch | (12) Glow Plug | |

When the main switch (7) is turned to the **GLOW** position, the terminal **BAT** is connected to the terminal **ON** and **AC**. The glow plugs (12) become red-hot, and the preheat indicator lamp also lights on while preheating.

When the main switch is then turned to the **START** position with the safety switches (8) (9) on, the terminal **BAT** is connected to the terminals **GLOW** and **ST**. Consequently, battery current flows to the starter motor (10) and start the engine.

The main switch automatically returns to the **ON** position, the terminal **BAT** is connected only to the terminal **GLOW**, thereby causing the starting circuit to be opened, stopping the starter motor.

When the main switch turned from the **ON** position to the **OFF** position, the fuel cut-off solenoid (14) moves the fuel injection pump control rack to the "No Fuel Injection" position and stops the engine.

(2) BX2350D with OPC System

- | | | | |
|--------------------|-----------------------------|------------------------|------------------------------|
| (1) Glow Lamp | (5) Fuse | (9) HST Neutral Switch | (13) Engine Stop Timer Relay |
| (2) Alternator | (6) Fuse | (10) Starter Motor | (14) Solenoid |
| (3) Fuel Pump | (7) Main Switch | (11) Battery | (15) Frame Earth |
| (4) Slow Blow Fuse | (8) PTO Clutch Lever Switch | (12) Glow Plug | |

When the main switch (7) is turned to the **GLOW** position, the terminal **BAT** is connected to the terminal **ON** and **AC**. The glow plugs (12) become red-hot, and the preheat indicator lamp also lights on while preheating.

When the main switch is then turned to the **START** position with the safety switches (8) (9) on, the terminal **BAT** is connected to the terminals **GLOW** and **ST**. Consequently, battery current flows to the starter motor (10) and start the engine.

The main switch automatically returns to the **ON** position, the terminal **BAT** is connected only to the terminal **GLOW**, thereby causing the starting circuit to be opened, stopping the starter motor.

When the main switch turned from the **ON** position to the **OFF** position, the fuel cut-off solenoid (14) moves the fuel injection pump control rack to the **"No Fuel Injection"** position and stops the engine.

[2] SAFETY SWITCH

(1) BX2350D without OPC System


There is one type of safety switch, normally opened type.

Normally opened type switch is electrically opened in normal condition.

Safety switches adopted in BX2350D tractor operates as sensor detecting and transmitting the position of HST pedal and PTO clutch lever to start the engine.

Type of Switch	Safety Switch Name	Number of Switch Contact
Normally opened type	PTO clutch lever switch	1
	HST pedal neutral switch	1

W1014916




(1) Safety Switch

(2) BX2350D with OPC System

This switch is electrically opened in normal condition (normally opened type). The switch operates as sensor detecting the position of HST pedal and PTO clutch lever.

Type of Switch	Safety Switch Name	Number of Switch Contact
Normally opened type	PTO clutch lever switch	2
	HST pedal neutral switch	2

W1016738



(1) HST Neutral Switch

(2) 2P Connector (LH)

(3) 2P Connector (RH)

(4) Plunger

Lever / Pedal Position, Engine Condition and Switch Condition

No.	Pedal / Lever Position		Engine Condition
	HST Pedal Neutral Switch; Neutral: ON Forward or reverse: OFF	PTO Lever Switch; Engaged: ON I-PTO disengaged: OFF	Engine Starting
1	Neutral Position: ON	Disengaged: OFF	Can Start
2			
3			
4			
5			
6			
7		Engaged: ON	Can not Start
8			
9			
10			
11			
12			
13	Forward (OFF) or Reverse (OFF)	Disengaged: OFF	
14			
15			
16			
17			
18			
19		Engaged: ON	
20			
21			
22			
23			
24			

W1016821


Lever / Pedal Position, Engine Condition and Switch Condition

No.	Lever / Pedal Position		Engine Condition
	HST Pedal Neutral switch; Neutral: ON Forward or reverse: OFF	PTO Clutch Lever Switch; R-PTO Selected: ON M-PTO or M and R-PTO Selected: OFF	Engine Starting
1	Neutral Position: ON	R-PTO Selected: ON	Can Start
2			
3			
4			
5		M-PTO or M and R-PTO Selected: OFF	
6			
7		R-PTO Selected: ON	Can not Start
8			
9			
10			
11		M-PTO or M and R-PTO Selected: OFF	
12			
13	R-PTO Selected: ON		
14			
15			
16			
17	M-PTO or M and R-PTO Selected: OFF		
18			
19			
20			
21	R-PTO Selected: ON		
22			
23			
24			

W1015145

3. OPERATOR PRESENCE CONTROL (OPC) SYSTEM

[1] ELECTRICAL CIRCUIT



- | | | | |
|---------------------|----------------------------|------------------------|------------------------------|
| (1) OPC Timer Relay | (4) Parking Pedal Switch | (7) HST Neutral Switch | (10) Battery |
| (2) Slow Blow Fuse | (5) Rear PTO Select Switch | (8) Main Switch | (11) Engine Stop Timer Relay |
| (3) Seat Switch | (6) PTO Switch | (9) Starter Motor | (12) Engine Stop Solenoid |

Operator presence control (OPC) system is a electrical system to stop the engine when a operator stands up from the operator's seat in selecting the rear PTO work.

Main parts regarding OPC system are shown in the electrical circuit. In OPC system, when the engine stops automatically, battery current flows as follows.

Battery (10) → Starter motor (9) → Slow blow fuse (2) → Main switch (8) → Fuse, 10A → Seat switch (3) and OPC timer relay (1) → Engine stop timer relay (11) → Engine stop solenoid (12)


[2] OPC TIMER RELAY

The function of the OPC timer relay is as follows.

When a operator does not sit on the seat, the seat switch contact is turned to “**OFF**” electrically. The OPC timer relay is also turned to “**ON?**” electrically.

At this moment, battery current flows from the battery through the OPC timer relay (1) to the engine stop solenoid relay and the engine stop solenoid.

[3] SEAT SWITCH



This seat switch detects the position of the operators seat. The seat switch is a normal opened type switch.


When a operator sits on the operator's seat, the seat switch is turned to “**ON**” electrically.

When a operator stands up from the operator's seat, the seat switch is turned to “**OFF**” electrically.

- (1) Seat
- (2) Seat Switch
- (3) OPC Switch Connector

- (A) Vacant
- (B) Seated (Occupied)

W1019128




OPC seat switch and its electrical contacts

Switch name	Switch movement	Electrical contact	OPC system
Seat (occupying) switch	Pushed in when sitting on the seat	ON	Engine does not stop
	Free when seat is vacant	OFF	Engine stops

4. STATIONARY PTO CONTROL SYSTEM

[1] ELECTRICAL CIRCUIT



- | | | | |
|---------------------|----------------------------|------------------------|------------------------------|
| (1) OPC Timer Relay | (4) Parking Pedal Switch | (7) HST Neutral Switch | (10) Battery |
| (2) Slow Blow Fuse | (5) Rear PTO Select Switch | (8) Main Switch | (11) Engine Stop Timer Relay |
| (3) Seat Switch | (6) PTO Switch | (9) Starter Motor | (12) Engine Stop Solenoid |

Stationary PTO control system is a control system not to stop the engine when a operator engage the parking brake and stands up from the operator's seat in using the rear PTO (for chipper or pump).

Main parts regarding stationary PTO control system are shown in the electrical circuit.

In stationary PTO control system, battery current from the battery flows through the parking pedal switch (4) and the rear PTO select switch (5) to the engine stop solenoid relay and the engine stop solenoid as follows.

Battery (10) → Starter motor (9) → Slow blow fuse (2) → Main switch (8) → Fuse, 10A → Parking pedal switch (4) → Rear PTO select switch (5) → Engine stop solenoid relay (11) → Engine stop solenoid (12)

[2] SAFETY SWITCH FOR STATIONARY PTO CONTROL SYSTEM

Switch name	Switch movement	Function
Parking pedal switch	Normally opened type	1. Detects of the condition of parking pedal. 2. When engaging the parking pedal, this safety switch turns to "ON".
HST neutral switch	Normally opened type	1. Detects the positions (Forward, Neutral or Reverse) of HST pedal. 2. When depressing the HST pedal, this safety switch turns to "OFF". 3. When releasing foot from the HST pedal, this safety switch turns to "ON".
Rear PTO select switch	Normally opened type	1. Detects the rear PTO "Engaged" position. 2. When shifting the PTO shift lever to "Rear PTO" position, this safety switch turns to "ON". 3. When shifting the PTO shift lever to "Rear/Mid-PTO" or "Mid-PTO" position, this safety switch turns to "OFF".
PTO switch	Normally opened type	1. Detects the PTO clutch lever "ON" or "OFF" position. 2. When shifting the PTO clutch lever to "ON" position, this safety switch turns to "OFF". 3. When shifting the PTO clutch lever to "OFF" position, this safety switch turns to "ON".

Lever / Pedal Position, Engine Condition and Switch Condition

No.	Lever / Pedal Position					Engine Condition	
	HST Pedal Neutral switch; Neutral: ON Forward or reverse: OFF	PTO Lever Switch; PTO engaged: ON PTO disengaged: OFF	Rear PTO Select Switch; R-PTO Selected: ON M-PTO or M and R-PTO Selected: OFF	Seat Switch; Occupied: ON Off Seat or Vacant: OFF	Parking Pedal Switch; Not Depressed: OFF Depressed or Parking “ Lock ” position: ON	Running: Engine is running and rear PTO is rotating. Stop: Engine stops and rear PTO cannot be used.	
1	Neutral Position: ON	Disengaged: OFF	R-PTO Selected: ON	On Seat: ON	*1	Running	
2				Off Seat: OFF	*1		
3			M-PTO or M and R-PTO Selected: OFF	On Seat: ON	*1		
4				Off Seat: OFF	*1		
5		Engaged: ON	R-PTO Selected: ON	On Seat: ON	*1	Running	
6				Off Seat: OFF	*2	Stop	
7			M-PTO or M and R-PTO Selected: OFF	On Seat: ON	*3	Running	
8				Off Seat: OFF	*1	Running	
9			R-PTO Selected: ON	On Seat: ON	*1	Stop	
10				Off Seat: OFF	*1	Stop	
11			Disengaged: OFF	R-PTO Selected: ON	On Seat: ON	*1	Running
12					Off Seat: OFF	*1	Stop
13	M-PTO or M and R-PTO Selected: OFF	On Seat: ON		*1	Running		
14		Off Seat: OFF		*1	Stop		
15	Forward (OFF) or Reverse (OFF)	R-PTO Selected: ON	On Seat: ON	*1	Running		
16			Off Seat: OFF	*1	Stop		
17		M-PTO or M and R-PTO Selected: OFF	On Seat: ON	*1	Running		
18			Off Seat: OFF	*1	Stop		
19		R-PTO Selected: ON	On Seat: ON	*1	Running		
20			Off Seat: OFF	*1	Stop		
21		M-PTO or M and R-PTO Selected: OFF	On Seat: ON	*1	Running		
22			Off Seat: OFF	*1	Stop		
23	Disengaged: OFF	R-PTO Selected: ON	On Seat: ON	*1	Running		
24			Off Seat: OFF	*1	Stop		

*1 : Not Depressed (OFF) or “LOCK” (ON)


*2 : Not Depressed (OFF)

*3 : “LOCK” (ON)

W1021133

5. CHARGING SYSTEM



[1] ELECTRICAL CIRCUIT



- | | | | |
|--------------------------|--------------------|-----------------|------------------------------|
| (1) Hour and Tach. Meter | (4) Alternator | (7) Main Switch | (10) Beacon Light (Optional) |
| (2) Battery Charge Lamp | (5) Slow Blow Fuse | (8) Battery | (11) Beacon Light Switch |
| (3) Frame Earth | (6) Fuse | (9) Frame Earth | (12) DC Outlet |

The charging system supplies electric power for various electrical devices and also charges the battery while the engine runs.

[2] IC REGULATOR (3P CONNECTOR TYPE)



3P connector is connected to the IC regulator. **3P** connector consists of three leads, Sb (Sky Blue) lead (1), RY (Red / Yellow) lead (2), and WR (White / Red) lead (3).

Sb (Sky Blue) lead (1) is a lead to transmit the puls from the alternator to hour meter and tachometer. When turning on the main switch to “**ON**” position, the hour meter indicates operated hours.

While the engine runs, the tachometer indicates the present engine revolutions.

RY (Red / Yellow) lead (2) is a lead to the main switch.


WR (White / Red) lead (3) is a lead to the charge lamp.

- (1) Sb (Sky Blue) Lead
- (2) RY (Red / Yellow) Lead
- (3) WR (White / Red) Lead
- (4) Alternator Assembly
- (5) IC Regulator
- (6) Load
- (7) Load

- A : To Hour Meter and Tachometer**
- B : To Main Switch “ON” Position**
- C : To Charge Lamp**
- D : To Battery**

W1013535

6. LIGHTING SYSTEM




- | | | | |
|-----------------------------|---------------------------------|---------------------------|------------------------------|
| (1) Illumination Light | (10) Fuel Gauge | (19) Frame Earth | (28) Blinker Switch |
| (2) Trailer Light | (11) Combination Lamp Rear (L) | (20) Trailer Socket | (29) Combination Switch |
| (3) High Beam | (12) Combination Lamp Rear (R) | (21) Brake Lamp Switch | (30) Hazard Switch |
| (4) Oil Pressure Lamp | (13) Combination Lamp Front (L) | (22) Head Light (40/45W) | (31) Position Switch |
| (5) Glow Lamp | (14) Combination Lamp Front (L) | (23) Alternator | (32) Main Switch |
| (6) Blinker (L) | (15) Thermo Unit | (24) Fuse | (33) Battery |
| (7) Blinker (R) | (16) Fuel Sensor | (25) Slow Blow Fuse (50A) | (34) Frame Earth |
| (8) Battery Charge Lamp | (17) License Plate Lamp | (26) Fuse | (35) Working Light |
| (9) Water Temperature Gauge | (18) Oil Pressure Switch | (27) Flasher Unit | (36) Beacon Light Switch |
| | | | (37) Beacon Light (Optional) |


The lighting system consists of main switch, head light switch, turn signal light switch, hazard switch, head lights, turn signal lights, tail lights, trailer socket and beacon light etc..

7. GAUGES

[1] ELECTRICAL CIRCUIT



[2] HOUR AND TACHOMETER



The electrical hour meter and tachometer is equipped on the meter panel.

This meter indicates the operated hours when the main switch is turned to "ON" position.

After starting the engine, this meter indicates the present engine revolution.

The meter picks up the voltage from the IC regulator located in the alternator.


The IC regulator sends a signal of the engine revolution to the meter.

The meter calculates the signal. It changes and indicates the signal to the engine revolution in cooperation with the voltage.

- (1) Electrical Hour Meter and
Tachometer

W1013678

[3] FUEL LEVEL GAUGE



Fuel level gauge and fuel level sensor are connected by the wiring.

Fuel level gauge detects the resistance from the fuel level sensor.

Fuel level gauge indicates the fuel level in the fuel tank.

The relationship between the resistance of the fuel level sensor and the fuel level gauges is as follows.

Resistance of Fuel Level Sensor	Reading on Fuel Level Gauge
Approx. 110 Ω	Empty
Approx. 3 Ω	Full

- (1) Fuel Level Gauge
(2) Fuel Level Sensor
- A : Empty**
B : Full

W1018177

8. OTHERS

[1] DC OUTLET



DC outlet is equipped to this machine.

The capacity of the DC outlet is 12 V / 120 W.


The electrical device as a CD player, a mobile phone battery charger can be used to the DC outlet.

The DC outlet (1) consists of the DC outlet body (3) and the cover (4).

- (1) DC Outlet
- (2) Electrical Device
- (3) DC Outlet Body
- (4) Cover

RL : Red / Blue Lead
B : Black Lead

W1021891



SERVICING

CONTENTS

1. TROUBLESHOOTING	6-S1
2. SERVICING SPECIFICATIONS	6-S6
3. TIGHTENING TORQUES	6-S7
4. CHECKING, DISASSEMBLING AND SERVICING.....	6-S8
[1] CHECKING AND ADJUSTING	6-S8
(1) Battery.....	6-S8
(2) Main Switch.....	6-S10
(3) Starter	6-S11
(4) Glow Plug.....	6-S12
(5) Safety Switch (BX2350D without OPC System)	6-S12
(6) Safety Switch (BX2350D with OPC System)	6-S13
(7) Operator Presence Control (OPC) (BX2350D with OPC System)	6-S15
(8) Fuel Pump.....	6-S19
(9) Engine Stop Solenoid	6-S19
(10)Timer Relay	6-S20
(11)Charging System	6-S20
(12)Alternator	6-S21
(13)Combination Switch	6-S23
(14)Hazard Unit.....	6-S27
(15)Position Switch	6-S28
(16)Flasher Unit	6-S29
(17)Gauge	6-S32
(18)DC Outlet.....	6-S34
[2] DISASSEMBLING AND ASSEMBLING.....	6-S35
(1) Starter	6-S35
(2) Alternator	6-S35
[3] SERVICING	6-S36
(1) Starter	6-S36
(2) Alternator	6-S38

1. TROUBLESHOOTING

FUSE AND WIRING

Symptom	Probable Cause	Solution	Reference Page
All Electrical Equipment Do Not Operate	Battery discharged or defective	Recharge or replace	G-18
	Battery positive cable disconnected or improperly connected	Repair or replace	–
	Battery negative cable disconnected or improperly connected	Repair or replace	–
	Slow blow fuse blown	Replace	G-32, 33
Fuse Blown Frequently	Short-circuited	Repair or replace	–

W10143220

BATTERY

Symptom	Probable Cause	Solution	Reference Page
Battery Discharges Too Quickly	Battery defective	Replace	6-S8
	Alternator defective	Repair or replace	6-S30
	IC Regulator defective	Replace	–
	Wiring harness disconnected or improperly connected (between battery positive terminal and regulator B terminal)	Repair or replace	–
	Cooling fan belt slipping	Adjust tension	G-21

W10137180

STARTING SYSTEM

Symptom	Probable Cause	Solution	Reference Page
Starter Motor Does Not Operate	Battery discharged or defective	Recharge or replace	G-18
	Slow blow fuse blown	Replace	G-32, 33
	Safety switch improperly adjusted or defective	Repair or replace	6-S12
	Wiring harness disconnected or improperly connected (between main switch 50 terminal and safety switches, between safety switches and starter motor, between battery positive terminal and starter motor)	Repair or replace	6-S13, S14
	Starter motor defective	Repair or replace	6-S35
	Main switch defective	Replace	6-S10
Engine Does Not Stop When Main Switch is Turned OFF	Fuse blown (15 A)	Replace	G-32, 33
	Wiring harness disconnected or improperly connected (between main switch AC terminal and engine stop solenoid)	Repair or replace	–
	Engine stop solenoid defective	Replace	6-S19
	Timer relay defective	Replace	6-S20
Engine Does Not Start	Engine stop solenoid defective	Replace	6-S19
	Timer relay defective	Replace	6-S20

W10137180

OPERATOR PRESENCE CONTROL (OPC)

Symptom	Probable Cause	Solution	Reference Page
Engine Does Not Stop	Solenoid fuse blown (15A)	Replace	G-32, 33
	Engine stop timer replay defective	Replace	6-S20
	Engine stop solenoid defective	Replace	6-S19
	PTO select lever switch defective	Adjust or replace	6-S16
	PTO lever switch defective	Adjust or replace	6-S13
	HST neutral switch defective	Adjust or replace	6-S14
	Wiring harness disconnected or improperly connected (between key stop solenoid relay and engine stop solenoid, between engine stop solenoid relay and battery positive terminal)	Repair or replace	—
Starter Motor Does Not Operate	Solenoid fuse blown (15A)	Replace	G-32, 33
	Engine stop solenoid defective	Replace	6-S19
	Engine stop timer relay defective	Replace	6-S19
	Seat switch or parking pedal switch defective	Adjust or replace	6-S15, S18
	PTO select lever switch defective	Adjust or replace	6-S16
	PTO lever switch defective	Adjust or replace	6-S13
	HST neutral switch defective	Adjust or replace	6-S14
Engine Stops When HST Pedal is Pushed in Forward or in Reverse	Wrong wiring of seat switch	Proper Wiring	6-S15
	Parking pedal switch	Adjust the switch position	6-S18

W10236630

CHARGING SYSTEM

Symptom	Probable Cause	Solution	Reference Page
Charging Lamp Does Not Light when Main Switch is Turned ON	Fuse blown (15 A)	Replace	G-32, 33
	Wiring harness disconnected or improperly connected (between main switch AC terminal and panel board, between panel board and dynamo)	Repair or Replace	—
	Alternator defective	Repair or Replace	6-S30
	IC regulator defective	Replace	—
Charging Lamp Does Not Go Off When Engine is Running	Wiring harness disconnected or improperly connected (between main switch 30 terminal and dynamo, between panel board and dynamo)	Repair or Replace	—
	Alternator defective	Repair or Replace	6-S30
	IC regulator defective	Replace	—

W10135800

LIGHTING SYSTEM

Symptom	Probable Cause	Solution	Reference Page
Head Light Does Not Light	Fuse blown (15 A)	Replace	G-31, 32
	Bulb blown	Replace	G-34
	Wiring harness disconnected or improperly connected (between main switch AC terminal and head light switch, between head light switch and head light)	Repair or Replace	–
Tail Light Does Not Light	Fuse blown (15 A)	Replace	G-31, 32
	Bulb blown	Replace	G-34
	Wiring harness disconnected or improperly connected (between main switch AC terminal and head light switch, between head light switch and tail light)	Repair or Replace	–
Illumination Light Does Not Light	Fuse blown (15 A)	Replace	G-31, 32
	Bulb blown	Replace	–
	Wiring harness disconnected or improperly connected (between main switch AC terminal and head light switch, between head light switch and illumination light)	Repair or Replace	–
Hazard Light Does Not Light	Fuse blown (15 A)	Replace	G-31, 32
	Bulb blown	Replace	G-34
	Wiring harness disconnected or improperly connected	Repair or Replace	–
	Flasher unit defective	Replace	6-S29
	Hazard switch defective	Replace	6-S27

W10137180

LIGHTING SYSTEM (Continued)

Symptom	Probable Cause	Solution	Reference Page
Hazard Indicator Lamp Does Not Light	Bulb blown	Replace	–
	Wiring harness disconnected or improperly connected	Repair or Replace	–
Hazard Light Does Not Flicker	Flasher unit defective	Replace	6-S29
Turn Signal Light Does Not Light	Fuse blown (15 A)	Replace	G-31, 32
	Bulb blown	Replace	G-34
	Wiring harness disconnected or improperly connected	Repair or Replace	–
	Flasher unit defective	Replace	6-S29
	Blinker switch defective	Replace	6-S17, S18
Turn Signal Light Indicator Lamp Does Not Light	Bulb blown	Replace	G-34
	Wiring harness disconnected or improperly connected (blinker switch and indicator lamp)	Repair or Replace	–
Turn Signal Light Does Not Flicker	Flasher unit defective	Replace	6-S29
	Blinker switch defective	Replace	6-S25
Glow Lamp Does Not Light When Main Switch Is in Pre-heat Position	Battery discharged or defective	Recharge or Replace	G-18
	Slow blow fuse blown	Replace	G-32, 33
	Wiring harness disconnected or improperly connected (between main switch 19 terminal and pre-heat indicator, between pre-heat indicator and glow plugs)	Repair or Replace	–
	Main switch defective	Replace	6-S10
	Glow lamp defective	Replace	–
Oil Pressure Lamp Lights Up When Engine Is Running	Engine oil pressure too low	Repair engine	–
	Engine oil insufficient	Replenish	G-7
	Oil pressure switch defective	Replace	6-S31
	Short circuit between oil pressure switch lead and chassis	Repair	–
Oil Pressure Lamp Does Not Light When Main Switch Is Turned ON and Engine Is Not Running	Bulb blown	Replace	–
	Oil pressure switch defective	Replace	6-S31
	Wiring harness disconnected or improperly connected (between panel board and oil pressure switch)	Repair or Replace	–
Beacon Light Does Not Light when Main Switch Is Turned ON and Engine Is Running	Beacon light defective	Replace	–
	Beacon light switch defective	Replace	–
	Wiring harness disconnected or improperly connected (between main harness and beacon light) or wiring harness defective (between fuse and beacon light switch)	Repair or Replace	–

W10135800

GAUGES AND TACH. AND HOUR METER

Symptom	Probable Cause	Solution	Reference Page
Fuel Warning Lamp Does Not Light	Fuel gauge defective	Replace	–
	Fuel level sensor defective	Replace	6-S32
	Wiring harness disconnected or improperly connected (between fuel gauge and fuel level sensor)	Repair or Replace	–
Coolant Temperature Gauge Does Not Function	Coolant temperature gauge defective	Replace	–
	Coolant temperature sensor defective	Replace	6-S32
	Wiring harness disconnected or improperly connected (between coolant temperature gauge and coolant temperature sensor)	Repair or Replace	–
Hour And Tach. Meter Does Not Function	Alternator defective	Replace	6-S30
	Hour and tach. meter defective	Replace	–
	Wiring harness defective (between alternator and meter panel)	Replace	–

W10137180

2. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Battery	Voltage	More than 12 V	—
	Potential Difference	Less than 0.1 V	—
Glow Plug	Resistance	Approx. 0.9 Ω	—
Alternator	Charging Current / Alternator Speed	14 to 15 A / 5200 min ⁻¹ (rpm)	—
	Charging Voltage / Alternator Speed	14 to 15 A / 5200 min ⁻¹ (rpm)	—
Head Light Switch	Switch OFF	Infinity	—
	LOW BEAM	0 Ω	—
	HIGH BEAM	0 Ω	—
Blinker Switch	Switch OFF	Infinity	—
	R	0 Ω	—
	L	0 Ω	—
Hazard Light Switch and Position Switch	Switch OFF	Infinity	—
	ON	0 Ω	—
Horn Button	Button OFF	Infinity	—
	ON	0 Ω	—
Starter Commutator	O.D.	30.0 mm 1.181 in.	29.0 mm 1.142 in.
	Difference of O.D.'s	Less than 0.02 mm 0.0008 in.	0.05 mm 0.0020 in.
	Mica Undercut	0.50 to 0.80 mm 0.0197 to 0.0315 in.	0.20 mm 0.0079 in.
	Brush Length	14.0 mm 0.551 in.	9.0 mm 0.354 in.
Alternator			
	Starter Resistance	Less than 1.0 Ω	—
	Rotor Resistance	2.9 Ω	—
	Slip Ring O.D.	1.44 mm 0.5669 in.	14.0 mm 0.5512
	Brush Length	10.0 mm 0.3937 in.	1.5 mm 0.0591

W10138740

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-8.)

Item	N·m	kgf·m	lbf·ft
Starter B terminal nut	5.9 to 11.8	0.6 to 1.2	4.3 to 8.7

W10127360

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING



CAUTION

- To avoid accidental short circuit, be sure to attach the positive cable to the positive terminal before the negative cable is attached to the negative terminal.
- Never remove the battery cap while the engine is running.
- Keep electrolyte away from eyes, hands and clothes. If you are splattered with it, wash it away completely with water immediately.
- Keep open sparks and flames away from the battery at all times. Hydrogen gas mixed with oxygen becomes very explosive.

IMPORTANT

- If the machine is to be operated for a short time without battery (using a slave battery for starting), use additional current (lights) while engine is running and insulate terminal of battery. If this advice is disregarded, damage to alternator and regulator may result.

(1) Battery




Battery Voltage

1. Stop the engine and turn the main switch off.
2. Connect the COM (–) lead of the voltmeter to the battery's negative terminal post and the (+) lead to the positive terminal post, and measure the battery voltage.
3. If the battery voltage is less than the factory specification, check the battery specific gravity and recharge the battery.

Battery voltage	Factory specification	More than 12 V
-----------------	-----------------------	----------------

(1) Battery

W10125620





Battery Terminal Connection

1. Turn the main switch on, and turn on the head light.
2. Measure the voltage with a voltmeter across the battery's positive terminal post and the cable terminal, and the voltage across the battery's negative terminal post and the chassis.
3. If the measurement exceeds the factory specification, clean the battery terminal posts and cable clamps, and tighten them firmly.

Potential difference	Factory specification	Less than 0.1 V
----------------------	-----------------------	-----------------

W10126630



Battery Specific Gravity

1. Check the specific gravity of the electrolyte in each cell with a hydrometer.
2. When the electrolyte temperature differs from that at which the hydrometer was calibrated, correct the specific gravity reading following the formula mentioned in **(Reference)**.
3. If the specific gravity is less than 1.215 (after it is corrected for temperature), charge or replace the battery.
4. If the specific gravity differs between any two cells by more than 0.05, replace the battery.

NOTE

- Hold the hydrometer tube vertical without removing it from the electrolyte.
- Do not suck too much electrolyte into the tube.
- Allow the float to move freely and hold the hydrometer at eye level.
- The hydrometer reading must be taken at the highest electrolyte level.

(Reference)

- Specific gravity slightly varies with temperature. To be exact, the specific gravity decreases by 0.0007 with an increase of 1 °C (0.0004 with an increase of 1 °F) in temperature, and increases by 0.0007 with a decreases of 1 °C (0.0004 with a decrease of 1 °F).

Therefore, using 20 °C (68 °F) as a reference, the specific gravity reading must be corrected by the following formula :

- Specific gravity at 20 °C = Measured value + 0.0007 × (electrolyte temperature – 20 °C)
- Specific gravity at 68 °F = Measured value + 0.0004 × (electrolyte temperature – 68 °F)

Specific Gravity	State of Charge
1.260 Sp. Gr.	100 % Charged
1.230 Sp. Gr.	75 % Charged
1.200 Sp. Gr.	50 % Charged
1.170 Sp. Gr.	25 % Charged
1.140 Sp. Gr.	Very Little Useful Capacity
1.110 Sp. Gr.	Discharged

At an electrolyte temperature of 20 °C (68 °F)

(a) Good

(b) Bad

(c) Bad

W10127630

(2) Main Switch



Main Switch Connector Voltage

1. Remove the under cover panel.
2. Disconnect the **4P** connector (2) and remove the main switch (1).
3. Measure the voltage with a voltmeter across the connector **30** (red) terminal and chassis.
4. If the voltage differs from the battery voltage (11 to 14 V), the wiring harness is faulty.

Voltage	Connector 30 terminal – chassis	Approx. battery voltage
---------	--	-------------------------

(1) Main Switch

(2) **4P** Connector

W10135530



Main Switch Continuity

1) Main Switch Key at OFF Position

1. Set the main switch **OFF** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **ACC** terminal, **B** terminal and **ST** terminal, **B** terminal and **G** terminal.
3. If infinity is not indicated, the contacts of the main switch are faulty.

Resistance	B terminal – ACC terminal	Infinity
	B terminal – ST terminal	
	B terminal – G terminal	

2) Main Switch Key at ON Position

1. Set the main switch **ON** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **ACC** terminal.
3. If 0 ohm is not indicated, the **B** – **ACC** contact of the main switch are faulty.

Resistance	B terminal – ACC terminal	0 Ω
------------	---	------------

3) Main Switch Key at PREHEAT Position

1. Set and hold the main switch key at the **PREHEAT** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **G** terminal, and measure the resistance across the **B** terminal and the **ACC** terminal.
3. If 0 ohm is not indicated, these contacts of the main switch are faulty.

Resistance	B terminal – G terminal	0 Ω
	B terminal – ACC terminal	

4) Main Switch Key at START Position

1. Set and hold the main switch key at the **START** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **G** terminal, across the **B** terminal and the **ST** terminal, and across the **B** terminal and the **ACC** terminal.
3. If 0 ohm is not indicated, these contacts of the main switch are faulty.


Resistance	B terminal – G terminal	0 Ω
	B terminal – ST terminal	
	B terminal – ACC terminal	

(1) **B** Terminal
(2) **ST** Terminal

(3) **ACC** Terminal
(4) **G** Terminal

W10136580

(3) Starter



Motor Test




CAUTION

- **Secure the starter to prevent it from jumping up and down while testing the motor.**
1. Disconnect the battery negative cable from the battery.
 2. Disconnect the battery positive cable and the leads from the starter.
 3. Remove the starter from the engine.
 4. Disconnect the connecting lead (2) from the starter **C** terminal (1).
 5. Connect a jumper lead from the connecting lead (2) to the battery positive terminal post.
 6. Connect a jumper lead momentarily between the starter motor housing and the battery negative terminal post.
 7. If the motor does not run, check the motor.

(1) **C** Terminal

(2) Connecting Lead

W10142670



Magnet Switch Test (Pull-in, Holding Coils)

1. Remove the motor from the starter housing.
2. Prepare a 6 V battery for the test.
3. Connect jumper leads from the battery negative terminal to the housing and the starter **C** terminal.
4. The plunger should be attracted and the pinion gear should pop out when a jumper lead is connected from the battery positive terminal to the **S** terminal. It's a correct.
5. Disconnect the jumper lead to the starter **C** terminal. Then the pinion gear should remain popped out. It's a correct.

■ IMPORTANT

- **Testing time must be 3 to 5 sec..**

C : **C** Terminal


(a) **To Negative Terminal**

S : **S** Terminal

(b) **To Positive Terminal**

W1015210

(4) Glow Plug



Lead Terminal Voltage


1. Disconnect the wiring lead (2) from the glow plug (1) after turning the main switch off.
2. Turn the main switch key to the **"PREHEAT"** position, and measure the voltage between the lead terminal and the chassis.
3. Turn the main switch key to the **"START"** position, and measure the voltage with a voltmeter between the lead terminal and the chassis.
4. If the voltage at either position differs from the battery voltage, the wiring harness or main switch is faulty.

Voltage (Lead terminal – Chassis)	Main switch key at "PREHEAT"	Approx. battery voltage
	Main switch key at "START"	Approx. battery voltage

(1) Glow Plug

(2) Wiring Lead (Positive)

W10149130



3TMABAB9P012A

Glow Plug Continuity

1. Disconnect the lead from the glow plugs.
2. Measure the resistance with an ohmmeter between the glow plug terminal and the chassis.
3. If 0 ohm is indicated, the screw at the tip of the glow plug and the housing are short-circuited.
4. If the factory specification is not indicated, the glow plug is faulty.

Glow plug resistance	Factory specification	Approx. 0.9 Ω
----------------------	-----------------------	---------------

W10151150

(5) Safety Switch (BX2350D without OPC System)



3TAAAAH9P011A


PTO Switch Continuity

1. Remove the left rear wheels.
2. Disconnect the safety switch leads.
3. Measure the resistance with an ohmmeter across the safety switch terminals.
4. If the safety switch is defective, replace it.


Resistance (Across switch terminal)	When switch is pushed	0 Ω
	When switch is released	Infinity

(1) PTO Switch

W10158610



3TAAAAF9P018A




HST Neutral Switch Continuity

1. Remove the right rear wheel.
2. Disconnect the safety switch leads.
3. Measure the resistance with an ohmmeter across the safety switch terminals.
4. If the safety switch is defective, replace it.

Resistance (Across switch terminal)	When switch is pushed	0 Ω
	When switch is released	Infinity

(1) HST Neutral Switch

W10230640



(6) Safety Switch (BX2350D with OPC System)



PTO Lever Switch Continuity



1. Remove the left rear wheel.
2. Remove the PTO shift lever switch (1).
3. Measure the resistance with an ohmmeter across the switch terminals.
4. If the resistance values specified below are not indicated, the safety switch is faulty.

■ Plunger is pushed into the switch body

Resistance 1 terminal (5) – 2 terminal (6)	Factory specification	0 Ω
Resistance 3 terminal (7) – 4 terminal (8)	Factory specification	0 Ω

■ Plunger is released




Resistance 1 terminal (5) – 2 terminal (6)	Factory specification	Infinity
Resistance 3 terminal (7) – 4 terminal (8)	Factory specification	Infinity



- (1) PTO Shift Lever Switch
(2) 2P Connector (LH)
(3) 2P Connector (RH)
(4) Plunger

- (5) 1 Terminal
(6) 2 Terminal
(7) 3 Terminal
(8) 4 Terminal

W10286430



HST Neutral Switch Continuity

- 1. Remove the right rear wheel.
- 2. Remove the HST neutral switch (1).
- 3. Measure the resistance with an ohmmeter across the HST neutral switch terminals.
- 4. If the resistance values specified below are not indicated, the safety switch is faulty.

Plunger is pushed into the switch body

Resistance 1 terminal (5) – 2 terminal (6)	Factory specification	0 Ω
Resistance 3 terminal (7) – 4 terminal (8)	Factory specification	0 Ω

Plunger is released

Resistance 1 terminal (5) – 2 terminal (6)	Factory specification	Infinity
Resistance 3 terminal (7) – 4 terminal (8)	Factory specification	Infinity

- (1) HST Neutral Switch

(2) 2P Connector (LH)

(3) 2P Connector (RH)

(4) Plunger
- (5) 1 Terminal


(6) 2 Terminal

(7) 3 Terminal

(8) 4 Terminal

W10384760

(7) Operator Presence Control (OPC) (BX2350D with OPC System)



- Seat Switch Continuity Check**
1. Disconnect the **2P** connectors from the switch.
2. Connect the circuit tester to the terminals.
- (When switch is not pushed / When operator leaves from the seat)**
1. Measure the resistance between terminals.
2. If continuity is not infinity, the switch is faulty. Replace it.
- (When switch is pushed / When operator sits on the seat)**
1. Measure the resistance between terminals.
2. If continuity is not 0 Ω, the switch is faulty. Replace it.

Resistance	When switch is not pushed / When operator leaves from the seat	Infinity
	When switch is pushed / When operator sits on the seat	0 Ω


- (1) Seat

(2) Seat Switch

(3) Seat Switch Lead

(4) Coupler
- (A) Seat Switch is not Pushed

(B) Seat Switch is Pushed
- W10440960



Rear PTO Select Switch Continuity

1. Remove the left rear wheel.
2. Disconnect the **2P** connectors from the rear PTO select switch (1).
3. Disconnect the rear PTO select switch (1) from the machine.
4. Connect the circuit tester to the terminals (2).

(When switch is not pushed / When operator does not set the PTO select lever to rear PTO position)

1. Measure the resistance between terminals (2).
2. If continuity is not infinity, the switch is faulty. Replace it.

(When switch is pushed / When operator sets the PTO select lever to rear PTO position)




1. Measure the resistance between terminals (2).
2. If continuity is not 0 Ω , the switch is faulty. Replace it.




- (1) Rear PTO Select Switch
(2) Terminal

[A] Rear PTO Switch is not Pushed

[B] Rear PTO Switch is Pushed

W10243030





Checking OPC Timer

1. Remove the OPC timer. (The OPC timer is located under the fender center stay.)
2. Connect the jumper leads across the battery terminal and the Red / White terminal (2), and across the battery positive terminal and the Yellow terminal (3).
3. Connect the jumper lead across the battery negative terminal and the Black terminal (5), and across the battery negative terminal and the Blue terminal.
4. Connect the jumper lead across the Red terminal (4) and the bulb terminal.
5. The bulb lights up when disconnecting the jumper lead from the Red / White terminal (2) 0.7 to 1.3 seconds, the OPC timer (1) is proper.

- | | |
|---|-------------------------------------|
| (1) OPC Timer | (5) Black Terminal (To Frame Earth) |
| (2) Red / White Terminal (From Battery) | (6) Bulb (Load) |
| (3) Yellow Terminal (From OPC Switch) | (7) Battery |
| (4) Red Terminal (To Key Stop Solenoid) | |

W10647550



Parking Pedal Switch Continuity

1. Remove the bonnet under cover.
2. Disconnect the **2P** connectors from the parking pedal switch (1).
3. Disconnect the parking pedal switch (1) from the machine.
4. Connect the circuit tester to the terminals (2).

(When switch is not pushed / When operator does not depress the parking pedal)

1. Measure the resistance between terminals (2).
2. If continuity is not infinity, the switch is faulty. Replace it.

(When switch is pushed / When operator depresses the parking pedal)




1. Measure the resistance between terminals (2).
2. If continuity is not 0 Ω , the switch is faulty. Replace it.

- (1) Parking Pedal Switch
(2) Terminal


[A] Parking Pedal Switch is not Pushed

[B] Parking Pedal Switch is Pushed

W10267240



(8) Fuel Pump




Connector Voltage

1. Disconnect the **2P** connector from the fuel pump.
2. Turn the main switch key to the “**ON**” position, and measure the voltage with a voltmeter between the connector terminals.
3. If the voltage differs from the battery voltage, the wiring harness or main switch is faulty.

Voltage	Between connector terminals	Approx. battery voltage
---------	-----------------------------	-------------------------

W1016341




Fuel Pump Continuity

1. Disconnect the **2P** connector from the fuel pump.
2. Check the continuity between the connector terminals with an ohmmeter.
3. If it does not conduct, the fuel pump is faulty.

W1016134

(9) Engine Stop Solenoid




Engine Stop Solenoid Test

1. Disconnect the **1P** connector from the engine stop solenoid.
2. Remove the engine stop solenoid from the engine.
3. Connect the jumper leads from the battery positive terminal to the **1P** connector, and from the battery negative terminal to the engine stop solenoid body.
4. If the solenoid plunger is not attracted, the engine stop solenoid is faulty.

(1) Battery (12 V)

W1019658

(10) Timer Relay




Timer Relay Connector Voltage

1. Disconnect the connector from the timer relay after turning the main switch off.
2. Measure the voltage with a voltmeter across the connector terminal 4 and chassis.
3. Turn the main switch on, and measure the voltage across the connector terminal 3 and chassis.
4. If these voltages differ from the battery voltage, the wiring harness or main switch is faulty.

Voltage	Connector terminal 4 – chassis	Approx. battery voltage
	Connector terminal 3 – chassis	Approx. battery voltage

(1) Timer Relay

W1016544



Test of Timer Relay


1. Remove the timer relay from the tractor.
2. Connect jumper leads across the battery positive terminal and the timer relay terminal 3, and across the battery positive terminal and the timer relay terminal 4.
3. Connect jumper leads across the battery negative terminal and the timer relay terminal 2, and across the battery negative terminal and the bulb terminal.
4. Connect jumper lead across the timer relay terminal 1 and the bulb terminal.
5. The bulb lights up when disconnecting a jumper lead from the terminal 3 and goes off 6 to 13 seconds later, the timer relay is proper.

(1) Timer Relay
(2) Load (Lamp)

(3) Battery (12V)

W1016721

(11) Charging System



Battery Charging Current

1. After starting the engine, disconnect the battery positive cord (+), and connect an ammeter and voltmeter. Then switch on all electrical loads (such as head lights) and measure the charging current.

NOTE


- Connect an ammeter only after starting the engine.
- When the electrical loads is considerably low or the battery is fully charged, the specified reading may not be obtained.

Factory specification	Current	14 to 15 A
	Voltage	14 to 15 V
	Alternator speed	5200 min ⁻¹ (rpm)

(1) Battery Positive Cord

W1048417

(12) Alternator




Stator

1. Measure the resistance across each lead of the stator coil with resistance range of circuit tester.
2. If the measurement is not within factory specification, replace it.
3. Check the continuity across each stator coil lead and core with resistance range of circuit tester.
4. If infinity is not indicated, replace it.

Resistance	Factory specification	Less than 1.0 Ω
------------	-----------------------	------------------------

W1019964




Rotor

1. Measure the resistance across the slip rings.
2. If the resistance is not the factory specification, replace it.
3. Check the continuity across the slip ring and core with resistance range of circuit tester.
4. If infinity is not indicated, replace it.

Resistance	Factory specification	2.9 Ω
------------	-----------------------	--------------

W1020094




Slip Ring

1. Check the slip ring for score.
2. If scored, correct with an emery paper or on a lathe.
3. Measure the O.D. of slip ring with vernier calipers.
4. If the measurement is less than the allowable limit, replace it.

Slip ring O.D.	Factory specification	14.4 mm 0.567 in.
	Allowable limit	14.0 mm 0.551 in.

W1048713




Brush Wear

1. Measure the brush length with vernier calipers.
2. If the measurement is less than allowable limit, replace it.
3. Make sure that the brush moves smoothly.
4. If the brush is defective, replace it.

Brush length	Factory specification	10.5 mm 0.413 in.
	Allowable limit	8.4 mm 0.331 in.


W1020329







Rectifier

1. Check the continuity across each diode of rectifier with resistance range of circuit tester.
2. The rectifier is normal if the diode in the rectifier conducts in one direction and does not conduct in the reverse direction.

W1020452



(13) Combination Switch



Combination Switch

1. Remove the meter panel, and disconnect the combination switch connector.
2. Remove the combination switch (1) and perform the following checks **1**) to **8**).

- | | |
|------------------------|-------------------------|
| (1) Combination Switch | (6) Yellow / White Lead |
| (2) Green / White Lead | (7) Black Lead |
| (3) Red / White Lead | (8) Green Lead |
| (4) Orange Lead | (9) Red / Yellow Lead |
| (5) Yellow Lead | (10) Brown Lead |

W1049462

1) Connector Voltage

1. Connect the combination switch connector to the main wire harness.
2. Measure the voltage with a voltmeter across the connector **B1** terminal and chassis when the main switch is **ON** position.
3. If the voltage differs from the battery voltage, the wiring harness and main switch is faulty.

Voltage	Main switch at "ON" position	B1 terminal – Chassis	Battery voltage
---------	------------------------------	-----------------------	-----------------

W1050272

2) Head Light Switch Continuity when Setting Switch at "OFF" Position





1. Set the light switch to the **OFF** position.
2. Measure the resistance with an ohmmeter across the red / yellow lead (9) to the orange lead (4), the red / yellow lead (9) to the Brown lead (10).
3. If infinity is not indicated, the head light switch is faulty.

Resistance (Switch at OFF position)	Red / Yellow lead (9) – Orange lead (4)	Infinity
	Red / Yellow lead (9) – Brown lead (10)	

- | | |
|-------------------------|-----------------------|
| (1) Combination Switch | (8) Green Lead |
| (2) Green / White Lead | (9) Red / Yellow Lead |
| (3) Red / White Lead | (10) Brown Lead |
| (4) Orange Lead | |
| (5) Yellow Lead | |
| (6) Yellow / White Lead | |
| (7) Black Lead | |

A : Head Light "OFF" Position

W1050981



3) Head Light Switch Continuity when Setting Switch at “Low Beam” Position and at “High Beam” Position

1. Set the light switch to the **Low Beam** position.
2. Measure the resistance with an ohmmeter across the red / yellow lead (9) to the red / white lead (3) and the red / yellow lead (9) to the brown lead (10).
3. If 0 ohm is not indicated, the head light switch is faulty.

Resistance (Switch at Low beam position)	Red / Yellow lead (9) – Red / White lead (3)	0 Ω
Resistance (Switch at High beam position)	Red / Yellow lead (9) – Brown lead (10)	

- (1) Combination Switch
(2) Green / White Lead
(3) Red / White Lead
(4) Orange Lead
(5) Yellow Lead
(6) Yellow / White Lead
(7) Black Lead

- (8) Green Lead
(9) Red / Yellow Lead
(10) Brown Lead

A : Head Light “OFF” Position
L : Head Light “Low Beam” Position
H : Head Light “High Beam” Position

W1051881

4) Turn Signal Light Switch Continuity when Setting Switch Knob “OFF” Position

1. Set the turn signal switch knob to the **OFF** position.
2. Measure the resistance with an ohmmeter across the green lead (8) and green / white lead (2), and across to the green lead (8) and red / white lead (3).
3. If infinity is not indicated, the combination switch is faulty.





Resistance (Switch knob at OFF position)	Green lead (8) – Green / White lead (2)	Infinity
	Green lead (8) – Red / White lead (3)	

- (1) Combination Switch
(2) Green / White Lead
(3) Red / White Lead
(4) Orange Lead
(5) Yellow Lead
(6) Yellow / White Lead
(7) Black Lead

- (8) Green Lead
(9) Red / Yellow Lead
(10) Brown Lead

**A : Turn Signal Light Switch “OFF”
Position**

W1052305



5) Turn Signal Light Switch Continuity when Setting Switch Knob "RIGHT" Position

1. Set the turn signal switch knob to the **RIGHT** position.
2. Measure the resistance with an ohmmeter across the green lead (8) and red / white lead (3).
3. If 0Ω is not indicated, the combination switch is faulty.

Resistance (Switch knob at RIGHT position)	Green lead (8) – Red / White lead (3)	0Ω
---	--	------------

- | | |
|-------------------------|-----------------------|
| (1) Combination Switch | (8) Green Lead |
| (2) Green / White Lead | (9) Red / Yellow Lead |
| (3) Red / White Lead | (10) Brown Lead |
| (4) Orange Lead | |
| (5) Yellow Lead | |
| (6) Yellow / White Lead | |
| (7) Black Lead | |

A : Turn Signal Light Switch "RIGHT" Position

W1052995

6) Turn Signal Light Switch Continuity when Setting Switch Knob "LEFT" Position





1. Set the turn signal switch knob to the **LEFT** position.
2. Measure the resistance with an ohmmeter across the green lead (8) and green / white lead (2).
3. If 0Ω is not indicated, the combination switch is faulty.

Resistance (Switch knob at LEFT position)	Green lead (8) – Green / White lead (2)	0Ω
--	--	------------

- | | |
|-------------------------|-----------------------|
| (1) Combination Switch | (8) Green Lead |
| (2) Green / White Lead | (9) Red / Yellow Lead |
| (3) Red / White Lead | (10) Brown Lead |
| (4) Orange Lead | |
| (5) Yellow Lead | |
| (6) Yellow / White Lead | |
| (7) Black Lead | |

A : Turn Signal Light Switch "LEFT" Position

W1053450



7) Horn Button Continuity when Not Pushing Button

- 1. Set the horn button to the **OFF** position.
- 2. Measure the resistance with an ohmmeter across the black lead (7) and yellow / white lead (6).
- 3. If infinity is not indicated, the combination switch is faulty.

Resistance (Horn button at OFF position)	Black lead (7) – Yellow / White lead (6)	Infinity
---	---	----------

- (1) Combination Switch

(2) Green / White Lead

(3) Red / White Lad

(4) Orange Lead

(5) Yellow Lead

(6) Yellow / White Lead

(7) Black Lead
- (8) Green Lead

(9) Red / Yellow Lead

(10) Brown Lead

A : Horn Button “OFF” Position

W1053841

8) Horn Button at “ON” Position

- 1. Set the horn button to the **ON** position.
- 2. Measure the resistance with an ohmmeter across the black lead (7) and yellow / white lead (6).
- 3. If 0 Ω is not indicated, the combination switch is faulty.

Resistance (Horn button at ON position)	Black lead (7) – Yellow / White lead (6)	0 Ω
--	---	-----

- (1) Combination Switch

(2) Green / White Lead

(3) Red / White Lad

(4) Orange Lead

(5) Yellow Lead

(6) Yellow / White Lead

(7) Black Lead
- (8) Green Lead



(9) Red / Yellow Lead

(10) Brown Lead

A : Horn Button “ON” Position

W1054637

(14) Hazard Unit



Hazard Switch Connector Voltage

1. Remove the steering handle and the meter panel.
2. Disconnect the **6P** coupler from the hazard switch (1).
3. Measure the connector voltage across the terminal **a** and the chassis.
4. If the voltage differs from the battery voltage, the wiring harness is faulty.

Voltage	Terminal a – Chassis	Approx. battery voltage
---------	-----------------------------	-------------------------

(1) Hazard Switch

a : Terminal **a**
b : Terminal **b**
c : Terminal **c**
d : Terminal **d**

W1041903

Hazard Switch Continuity

1. Measure the resistance with an ohmmeter across the terminal **a** (4) and the terminal **b** (2).
2. Measure the resistance with an ohmmeter across the terminal **c** (5) and the terminal **d** (3).
3. If the measurement is not following below, the hazard switch (1) or the bulb are faulty.



Resistance (Switch at OFF)	Terminal a – Terminal b	Infinity
Resistance (Switch at ON)	Terminal a – Terminal b	0 Ω
Resistance (Bulb)	Terminal c – Terminal d	Approx. 13 Ω

(1) Hazard Switch
(2) Terminal **b**
(3) Terminal **d**

(4) Terminal **a**
(5) Terminal **c**

W1043174

(15) Position Switch



Position Switch Connector Voltage

1. Remove the steering handle and the meter panel.

2. Disconnect the **6P** coupler from the position switch (1).

3. Measure the connector voltage across the terminal **a** and the chassis.

4. If the voltage differs from the battery voltage, the wiring harness is faulty.

Voltage	Terminal a – Chassis	Approx. battery voltage
---------	-----------------------------	-------------------------

- (1) Position Switch

a : Terminal **a**

b : Terminal **b**

c : Terminal **c**

d : Terminal **d**

e : Terminal **e**

W1045236

Position Switch Continuity

1. Measure the resistance with an ohmmeter across the terminal **a** (2) and the terminal **c** (5).

2. Measure the resistance with an ohmmeter across the terminal **b** (3) and the terminal **c** (5).

3. Measure the resistance with an ohmmeter across the terminal **d** (4) and the terminal **e** (6).

4. If the measurement is not following below, the position switch (1) or the bulb are faulty.

Resistance (Switch at OFF)	Terminal a – Terminal c	Infinity
Resistance (Switch at OFF)	Terminal b – Terminal c	0 Ω
Resistance (Switch at ON)	Terminal a – Terminal c	0 Ω
Resistance (Bulb)	Terminal d – Terminal e	Approx. 13 Ω

- (1) Position Switch

(2) Terminal **a**

(3) Terminal **b**



(4) Terminal **d**

(5) Terminal **c**

(6) Terminal **e**

W1045547

(16) Flasher Unit



Flasher Unit

1. Remove the under panel.
2. Disconnect the coupler (2) from flasher unit.
3. Measure the voltage with a voltmeter across the terminal **h** and terminal **c** or chassis.
4. If the voltage differs from the battery voltage, the wiring harness is faulty.

Voltage	Terminal h – Terminal c or Chassis	Approx. battery voltage
---------	---	-------------------------

(1) Flasher Unit

(2) Coupler

W1055033

Flasher Unit Actuation Test



1. Set the hazard switch to the **ON** position, and make sure the hazard light gives 60 to 85 flashes for a minute.
2. With the main switch and the hazard switch at the **ACC** and **ON** positions, respectively, move the turn signal light switch to the left. Make sure that the right-hand light stays on and the left-hand light gives flashes earlier (by about 20 flashes) than when the hazard lamp is activated. Then move the turn signal light switch to the right and make sure the corresponding actions take place.
3. Now set the main switch to the **ACC** position and move the blinker switch alone. Make sure the same actions as above result.
4. If both the hazard switch and the turn signal light switch function but the above actions do not take place, replace the flasher unit with new one.

(1) Hazard Light Switch

(2) Turn Signal Light Switch

(3) Flasher Unit

W1049062



Charge Lamp (Charging Circuit)

1. Disconnect the **3P** connector from the alternator after turning the main switch **OFF**.
2. Turn the main switch **ON** and connect a jumper lead from the wiring harness connector terminal (White / Red) to the chassis.

NOTE

- If you connect the jumper lead from the wiring harness connector terminal (White / Red) to the chassis, 15A fuse will be blown. Do not connect the lead to Red / Yellow terminal.
3. If the charge lamp does not light, the wiring harness or fuse is faulty.

- (1) Alternator
(2) 3P Connector
(3) Sb (Sky Blue) Terminal
(4) RY (Red / Yellow) Terminal
(5) WR (White / Red) Terminal

- A : To Main Switch
B : To Hour Meter and Tachometer
C : To Ground
D : To Change Lamp

W1049297




Engine Oil Pressure Lamp


1. Disconnect the lead (2) from the engine oil pressure switch (1) after turning the main switch **OFF**.
2. Turn the main switch **ON** and connect a jumper lead from the lead to the chassis.
3. If the engine oil pressure indicator lamp does not light, the wiring harness is faulty.

- (1) Engine Oil Pressure Switch
(2) Lead

- (a) From Oil Pressure Lamp

W1049543






- Engine Oil Pressure Switch Continuity**
1. Disconnect the lead (2) from the engine oil pressure switch (1).
 2. Measure the resistance with an ohmmeter across the switch terminal and the chassis.
 3. If 0 ohm is not indicated in the normal state, the switch is faulty.
 4. If infinity is not indicated at pressure over 4.9 kPa (0.5 kgf/cm², 7 psi), the switch is faulty.

Resistance (Switch terminal – Chassis)	In normal state	0 Ω
	At pressure over approx. 4.9 kPa (0.5 kgf/cm ² , 7 psi)	Infinity

(1) Engine Oil Pressure Switch (2) Lead

W1055934

(17) Gauge



Fuel Level Sensor

1) Sensor Continuity


1. Remove the fuel level sensor from the fuel tank.
2. Measure the resistance with an ohmmeter across the sensor terminal and its body.
3. If the reference values are not indicated, the sensor is faulty.

Resistance (Sensor terminal – its body)	Reference value	Float at upper – most position	1 to 5 Ω
		Float at lower – most position	103 to 117 Ω

E : Empty

F : Full

W1049919



Coolant Temperature Sensor (Thermo Unit)

1) Lead Terminal Voltage

1. Disconnect the lead from the coolant temperature sensor after turning the main switch **OFF**.
2. Turn the main switch **ON** and measure the voltage with a voltmeter across the lead terminal and the chassis.
If the voltage differs from the battery voltage, the wiring harness, fuse or coolant temperature gauge is faulty.

Voltage	Lead terminal – Chassis	Approx. battery voltage
---------	-------------------------	-------------------------

2) Sensor Continuity


1. Measure the resistances with an ohmmeter across the sensor terminal and the chassis.
2. If the reference value is not indicated, the sensor is faulty.




Resistance (Sensor terminal – Chassis)	Reference value	Approx. 16.1 Ω at 120 °C (248 °F)
		Approx. 27.4 Ω at 100 °C (212 °F)
		Approx. 51.9 Ω at 80 °C (176 °F)
		Approx. 153.9 Ω at 50 °C (122 °F)

(1) Coolant Temperature Sensor

(a) From Temperature Gauge

W1050131





Hour Meter and Tachometer

1. Disconnect the **3P** connector (4) from the IC regulator (9) located in the alternator (5) after starting the engine.
2. Measure the voltage with a voltmeter across the hour meter terminal (6) and the alternator body when the hour meter or tachometer does not indicated the proper value.
3. If the measured voltages differ from the specified voltage, the hour meter and tachometer is faulty.



Voltage while engine runs at idling speeds	Hour meter terminal – Alternator body	Approx. battery voltage
--	---------------------------------------	-------------------------

- (1) Sb (Sky Blue) Lead
- (2) RY (Red / Yellow) Lead
- (3) WR (White / Red) Lead
- (4) **3P** Connector
- (5) Alternator
- (6) Hour Meter and Tachometer Terminal
- (7) Ground Terminal
- (8) Charge Lamp Terminal
- (9) IC Regulator

- A : To Main Switch**
- B : To Hour Meter and Tachometer**
- C : To Ground**
- D : To Charge Lamp**

W1057349

(18) DC Outlet



DC Outlet Connector Voltage and DC Outlet Continuity

- 1. Disconnect the connector from the DC outlet. And turn the main switch “ON”.
- 2. Measure the voltage with a voltmeter across the connector red / blue lead and the chassis.
If the voltage differs from the battery voltage the wiring harness is faulty.
- 3. Disconnect the connector from the DC outlet. Since the DC outlet can not be removed easily, measure the continuity with a ohm meter across the plus terminal (3) and the nut (5), and across the earth terminal (3) and the DC outlet case (6).
- 4. If the resistance differs from 0 ohm, the DC outlet body (1) is faulty.

DC outlet connector voltage	Red / Blue lead – Chassis	Battery voltage
DC outlet continuity	Plus terminal – Nut	0 Ω
	Earth terminal – DC outlet case	

- (1) DC Outlet Body

(2) Fuse

(3) Earth Terminal (for Chassis)
- (4) Plus Terminal (for Battery)


(5) Nut

(6) DC Outlet Case

W1063447

[2] DISASSEMBLING AND ASSEMBLING

(1) Starter



Motor

1. Disconnect the connecting lead (9) from the magnet switch (8).
2. Remove the screws (6), and then separate the end frame (4), yoke (2) and armature (1).
3. Remove the two screws (5), and then take out the brush holder (3) from the end frame (4).


(When reassembling)

- Apply grease to the spline teeth (A) of the armature (1).

Tightening torque	Nut (7)	5.9 to 11.8 N·m 0.6 to 1.2 kgf·m 4.3 to 8.7 lbf·ft
-------------------	---------	--

- | | |
|------------------|-------------------------|
| (1) Armature | (7) Nut |
| (2) Yoke | (8) Magnet Switch |
| (3) Brush Holder | (9) Connecting Lead |
| (4) End Frame | |
| (5) Screw | A : Spline Teeth |
| (6) Screw | |

W1016288



Magnet Switch


1. Remove the drive end frame (1) mounting screws.
2. Take out the overrunning clutch (2), ball (3), spring (4), gears (5), rollers (6) and retainer (7).

(When reassembling)

- Apply grease to the gear teeth of the gears (5) and overrunning clutch (2), and ball (3).

- | | |
|------------------------|--------------|
| (1) Drive End Frame | (5) Gear |
| (2) Overrunning Clutch | (6) Roller |
| (3) Ball | (7) Retainer |
| (4) Spring | |

W1016728



Plunger

1. Remove the end cover (1).
2. Take out the plunger (2).

- | | |
|---------------|-------------|
| (1) End Cover | (2) Plunger |
|---------------|-------------|

W1016883

(2) Alternator



Alternator


1. Check the battery charging voltage while engine runs.
2. Check the increasing voltage when increasing the engine revolution.
3. If the battery charging voltage does not increase, the alternator is faulty.
4. Replace the alternator as an assembly.

- | |
|-------------|
| (1) Battery |
|-------------|

W1058597

[3] SERVICING

(1) Starter




3EEABAB1P188A

Overrunning Clutch

1. Inspect the pinion for wear or damage.
2. If there is any defect, replace the overrunning clutch assembly.
3. Check that the pinion turns freely and smoothly in the overrunning direction and does not slip in the cranking direction.
4. If the pinion slips or does not rotate in the both directions, replace the overrunning clutch assembly.

W1016990



3EEABAB1P182A

Commutator and Mica

1. Check the contact face of the commutator for wear, and grind the commutator with emery paper if it is slightly worn.
2. Measure the commutator O.D. with an outside micrometer at several points.
3. If the minimum O.D. is less than the allowable limit, replace the armature.
4. If the difference of the O.D.'s exceeds the allowable limit, correct the commutator on a lathe to the factory specification.
5. Measure the mica undercut.
6. If the undercut is less than the allowable limit, correct it with a saw blade and chamfer the segment edges.

Commutator O.D.	Factory specification	30.0 mm 1.181 in.
	Allowable limit	29.0 mm 1.142 in.


Difference of O.D.'s	Factory specification	Less than 0.02 mm 0.0008 in.
	Allowable limit	0.05 mm 0.0020 in.

Mica undercut	Factory specification	0.50 to 0.80 mm 0.0197 to 0.0315 in.
	Allowable limit	0.20 mm 0.0079 in.

- (1) Segment
(2) Undercut
(3) Mica

(a) Correct
(b) Incorrect

W1017092




3EEABAB1P184A

Brush Wear


1. If the contact face of the brush is dirty or dusty, clean it with emery paper.
2. Measure the brush length (A) with vernier calipers.
3. If the length is less than the allowable limit, replace the yoke assembly and brush holder.

Brush length (A)	Factory specification	14.0 mm 0.551 in.
	Allowable limit	9.0 mm 0.354 in.

W1017544




3TAAAB9P037A



Brush Holder

1. Check the continuity across the brush holder and the holder support with an ohmmeter.
2. If it conducts, replace the brush holder.


W1017672



Armature Coil

1. Check the continuity across the commutator and armature coil core with an ohmmeter.
2. If it conducts, replace the armature.
3. Check the continuity across the segments of the commutator with an ohmmeter.
4. If it does not conduct, replace the armature.

W1017767





Field Coil

1. Check the continuity across the lead (1) and brush (2) with an ohmmeter.
2. If it does not conduct, replace the yoke assembly.
3. Check the continuity across the brush (2) and yoke (3) with an ohmmeter.
4. If it conducts, replace the yoke assembly.


(1) Lead
(2) Brush

(3) Yoke

W1018015



(2) Alternator



Bearing

1. Check the bearing for smooth rotation.
2. If it does not rotate smoothly, replace it.

W1019790

Alternator Components

1. When the alternator does not generate or does not charge the battery, replace the alternator as an assembly.

W1060576


7 ROTARY MOWER

SAFETY DECALS

The following safety decals are installed on the mower.


If a decal becomes damaged, illegible or is not on the mower, replace it. The decal part number is listed in the parts list.

[RCK60B-23BX-EU, RCK54-23BX-EU,
RCK48-23BX-EU]




(A) Forward

(1) Part No. K5652-4179-3




1BDACAEAP0440

[RCK60-23BX-EU-F, RCK54-23BX-EU-F,
RCK48-23BX-EU-F]




(A) Forward

(3) Part No. K5652-4178-2



1BDACAGAP001A

(2) Part No. K5652-4180-2




1BDACAGAP003A

CARE OF DANGER, WARNING AND CAUTION LABELS

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels.
4. If a component with danger, warning or caution label(s) affixed is replaced with new part, make sure new label(s) is(are) attached in the same location(s) as the replaced component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

TERMINOLOGY


[RCK60B-23BX-EU, RCK54-23BX-EU]



3TAAAFPP001A

- | | | | |
|-----------------------------|-------------------------|------------------------------|--|
| (1) Front Anti-scalp Roller | (5) Discharge Deflector | (8) Outer Blade (Right) | (11) Outer Blade (Left) |
| (2) Belt Cover (Left) | (6) Universal Joint | (9) Center Anti-scalp Roller | (12) Rear Anti-scalp Roller |
| (3) Gear Box | (7) Deck | (10) Center Blade | (13) Self-balancer (RCK60B-23BX-EU only) |

[RCK48-23BX-EU]




(1) Front Anti-scalp Roller
(2) Belt Cover (Left)
(3) Gear Box

(4) Belt Cover (Right)
(5) Discharge Deflector
(6) Universal Joint

(7) Deck
(8) Outer Blade (Right)
(9) Center Anti-scalp Roller


(10) Center Blade
(11) Outer Blade (Left)
(12) Rear Anti-scalp Roller

[RCK60-23BX-EU-F, RCK54-23BX-EU-F]

9Y0211381IHI001A

- | | | | |
|-----------------------------|--------------------------------|-------------------------|-------------------------------|
| (1) Gear Box | (5) Center Cover | (8) Universal Joint | (11) Center Anti-scalp Roller |
| (2) Front Anti-scalp Roller | (6) Universal Joint Cover Stay | (9) Discharge Deflector | (12) Rear Anti-scalp Roller |
| (3) Left Shield | (7) Deck | (10) Blade | (13) Self-balancer |
| (4) Right Shield | | | (RCK60-23BX-EU-F only) |

[RCK48-23BX-EU-F]



(1) Gear Box
(2) Front Anti-scalp Roller
(3) Left Shield

(4) Right Shield
(5) Universal Joint Cover Stay
(6) Deck

(7) Universal Joint
(8) Discharge Deflector
(9) Blade

(10) Center Anti-scalp Roller
(11) Rear Anti-scalp Roller

SPECIFICATIONS

[RCK60B-23BX-EU, RCK54-23BX-EU, RCK48-23BX-EU]

Model		RCK60B-23BX-EU	RCK54-23BX-EU	RCK48-23BX-EU
Suitable tractor		BX2350		
Mounting method		Quick-Joint, Parallel linkage		
		Self-balance suspended linkage	Suspended linkage	
Adjustment of cutting height		Dial gauge		
Cutting width		1524 mm (60 in.)	1372 mm (54 in.)	1219 mm (48 in.)
Cutting height		25 to 102 mm (1.0 to 4.0 in.)		
Weight (Approx.)		115 kg (250 lbs)	95 kg (210 lbs)	75 kg (165 lbs)
Blade spindle speed		44.1 r/s (2647 rpm)	49.5 r/s (2969 rpm)	54.7 r/s (3281 rpm)
Blade tip velocity		72.5 m/s (14271 fpm)	73.8 m/s (14527 fpm)	72.8 m/s (14331 fpm)
Blade length		523 mm (20.6 in.)	475 mm (18.7 in.)	424 mm (16.7 in.)
Number of blades		3		
Dimensions	Overall length	1000 mm (39.4 in.)	928 mm (36.5 in.)	895 mm (35.2 in.)
	Overall width	1930 mm (76.0 in.)	1780 mm (66.5 in.)	1544 mm (60.8 in.)
	Overall height [Min.]	281 mm (11.0 in.)	281 mm (11.0 in.)	268 mm (10.5 in.)

W1028770

[RCK60-23BX-EU-F, RCK54-23BX-EU-F, RCK48-23BX-EU-F]

Model		RCK60-23BX-EU-F	RCK54-23BX-EU-F	RCK48-23BX-EU-F
Suitable tractor		BX2350D		
Mounting method		Quick-Joint, Parallel linkage		
		Self-balance suspended linkage	Suspended linkage	
Adjustment of cutting height		Dial gauge		
Cutting width		1524 mm (60 in.)	1372 mm (54 in.)	1224 mm (48 in.)
Cutting height		25 to 102 mm (1.0 to 4.0 in.)		
Weight (Approx.)		113 kg (249 lbs)	97 kg (214 lbs)	81 kg (179 lbs)
Blade spindle speed		44.1 r/s (2647 rpm)	49.5 r/s (2969 rpm)	54.7 r/s (3281 rpm)
Blade tip velocity		72.5 m/s (14271 fpm)	73.8 m/s (14527 fpm)	72.8 m/s (14331 fpm)
Blade length		523 mm (20.6 in.)	475 mm (18.7 in.)	424 mm (16.7 in.)
Number of blades		3		
Dimensions	Overall length	1000 mm (39.4 in.)	928 mm (36.5 in.)	895 mm (35.2 in.)
	Overall width	1930 mm (76.0 in.)	1780 mm (66.5 in.)	1544 mm (60.8 in.)
	Overall height [Min.]	281 mm (11.0 in.)	281 mm (11.0 in.)	268 mm (10.5 in.)

W1029973


MECHANISM

CONTENTS

1. POWER TRANSMISSION	7-M1
[1] RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU	7-M1
[2] RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F	7-M2
2. LIFTING MECHANISM	7-M3
[1] RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU	7-M3
[2] RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F	7-M4
3. SELF-BALANCER SYSTEM	7-M5
[1] RCK60B-23BX-EU	7-M5
[2] RCK60-23BX-EU-F	7-M6

1. POWER TRANSMISSION

[1] RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU



3TAAAFMP001A

- | | | | |
|---------------------------------------|---------------------------------------|----------------------|-------------------|
| (1) 21T Bevel Gear
(RCK48-23BX-EU) | (2) 16T Bevel Gear
(RCK48-23BX-EU) | (4) Universal Joint | (9) Mower Belt |
| 19T Bevel Gear
(RCK54-23BX-EU) | RCK54-23BX-EU) | (5) Mid-PTO Shaft | (10) Blade Shaft |
| 18T Bevel Gear
(RCK60B-23BX-EU) | 17T Bevel Gear
(RCK60B-23BX-EU) | (6) Center Blade | (11) Outer Pulley |
| | (3) Pinion Shaft | (7) Center Pulley | (12) Outer Blade |
| | | (8) Bevel Gear Shaft | |


The power is transmitted from mid-PTO to blades as follows:

■ Center Blade

Mid-PTO Shaft (5) → Universal Joint (4) → Pinion Shaft (3) → Bevel Gear (1) → Bevel Gear (2) → Bevel Gear Shaft (8) → Center Blade (6)

■ Outer Blade

Mid-PTO Shaft (5) → Universal Joint (4) → Pinion Shaft (3) → Bevel Gear (1) → Bevel Gear (2) → Bevel Gear Shaft (8) → Center Pulley (7) → Mower Belt (9) → Outer Pulley (11) → Blade Shaft (10) → Outer Blade (12)

[2] RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F

9Y0211381MOM001A

- | | | | |
|---|--|---|---|
| (1) 21T Bevel Gear
(RCK48-23BX-EU-F)
19T Bevel Gear
(RCK54-23BX-EU-F)
18T Bevel Gear
(RCK60-23BX-EU-F) | (2) 16T Bevel Gear
(RCK48-23BX-EU-F,
RCK54-23BX-EU-F)
17T Bevel Gear
(RCK60-23BX-EU-F)
(3) Pinion Shaft | (4) Universal Joint
(5) Mid-PTO Shaft
(6) Center Blade
(7) Center Pulley
(8) Bevel Gear Shaft | (9) Mower Belt
(10) Blade Shaft
(11) Outer Pulley
(12) Outer Blade
(13) PTO Joint Cover |
|---|--|---|---|

The power is transmitted from mid-PTO to blades as follows:

■ **Center Blade**


Mid-PTO Shaft (5) → Universal Joint (4) → Pinion Shaft (3) → Bevel Gear (1) → Bevel Gear (2) → Bevel Gear Shaft (8) → Center Blade (6)

■ **Outer Blade**

Mid-PTO Shaft (5) → Universal Joint (4) → Pinion Shaft (3) → Bevel Gear (1) → Bevel Gear (2) → Bevel Gear Shaft (8) → Center Pulley (7) → Mower Belt (9) → Outer Pulley (11) → Blade Shaft (10) → Outer Blade (12)

2. LIFTING MECHANISM

[1] RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU



(1) Front Link
(2) Rear Link

(3) Lift Link
(4) Rear Lift Link (RH)

(5) Rear Lift Link (LH)

(6) Lift Arm

The lifting of mower is performed by the hydraulic system installed on the tractor.

The mower should be kept lift when traveling. When the position control lever is moved to “**LIFT**” position, the lift arm (6) is lifted up by the oil pressure of hydraulic system, and the rear lift link (LH) (5) is pulled rearward.

Therefore, rear lift links (4), (5) rotate and the mower is lifted by the lift links (3) and rear links (2).


As this link system is a parallel linkage, the mower can be kept parallel at every position.



CAUTION

- Never operate mower in transport position.

[2] RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F



(1) Front Link
(2) Rear Link

(3) Lift Link
(4) Rear Lift Link (RH)

(5) Rear Lift Link (LH)
(6) Lift Arm

(7) PTO Joint Cover

The lifting of mower is performed by the hydraulic system installed on the tractor.

The mower should be kept lift when traveling. When the position control lever is moved to “**LIFT**” position, the lift arm (6) is lifted up by the oil pressure of hydraulic system, and the rear lift link (LH) (5) is pulled rearward.

Therefore, rear lift links (4), (5) rotate and the mower is lifted by the lift links (3) and rear links (2).

As this link system is a parallel linkage, the mower can be kept parallel at every position.





CAUTION

- Never operate mower in transport position.

3. SELF-BALANCER SYSTEM

[1] RCK60B-23BX-EU

This system reduces the stepped differences in cutting height when mowing rolling terrain.



■ Self-Balancer

1. The mower deck is held in place via the balancer plate (4) and the support by the rear link (1), (2).
2. The mower deck is suspended by, and is tilted to the right and left by, the balancer support (5). The balancer springs (3) at both sides adjust themselves for suitable tension to keep the mower deck out of excessive tilt.

■ Without Self-Balancer Type (A)

- When working on a wavy ground, the tractor itself, with the mower deck, goes along the curves of the terrain. If not equipped with the self-balancer, the tractor tends to tilt itself greater than the ground's waves by its own weight. This may cause an uneven mowing. The wider the mower is, the more unevenness is caused.

■ With Self-Balancer Type (B)

- When working on a wavy ground, the tractor itself goes along the curves of the terrain like with the tractor that is not equipped with the self-balancer. The balancer springs (3), however, serve to keep the mower deck in parallel with the ground's curves until the anti-scalp roller (6) comes in contact with the ground.
- If the tractor temporarily tilts itself more than the ground's slope or the like, the anti-scalp roller (6) touches the ground. Now the mower deck is brought back in parallel with the ground by the counterforce of the roller (6) just hitting the ground as well as the tension of the balancer springs (3). This helps reduce an uneven mowing.

■ NOTE

- Always keep the anti-scalp roller with specified position (Refer to Operator's Manual).





- (1) Rear Link (RH)
- (2) Rear Link (LH)
- (3) Balancer Spring
- (4) Balancer Plate
- (5) Balancer Support
- (6) Anti-scalp Roller
- (7) Mower Deck

- (A) Without Self-Balancer
- (B) With Self-Balancer
- (a) Tilt : Tractor
- (b) Tilt : Mower Deck
- (c) Ground
- (d) Grass

W1013200

[2] RCK60-23BX-EU-F

This system reduces the stepped differences in cutting height when mowing rolling terrain.



■ Self-Balancer

1. The mower deck is held in place via the balancer plate (4) and the support by the rear link (1), (2).
2. The mower deck is suspended by, and is tilted to the right and left by, the balancer support (5). The balancer springs (3) at both sides adjust themselves for suitable tension to keep the mower deck out of excessive tilt.

■ Without Self-Balancer Type (A)

- When working on a wavy ground, the tractor itself, with the mower deck, goes along the curves of the terrain. If not equipped with the self-balancer, the tractor tends to tilt itself greater than the ground's waves by its own weight. This may cause an uneven mowing. The wider the mower is, the more unevenness is caused.

■ With Self-Balancer Type (B)

- When working on a wavy ground, the tractor itself goes along the curves of the terrain like with the tractor that is not equipped with the self-balancer. The balancer springs (3), however, serve to keep the mower deck in parallel with the ground's curves until the anti-scalp roller (6) comes in contact with the ground.
- If the tractor temporarily tilts itself more than the ground's slope or the like, the anti-scalp roller (6) touches the ground. Now the mower deck is brought back in parallel with the ground by the counterforce of the roller (6) just hitting the ground as well as the tension of the balancer springs (3). This helps reduce an uneven mowing.

■ NOTE

- Always keep the anti-scalp roller with specified position (Refer to Operator's Manual).

- (1) Rear Link (RH)
- (2) Rear Link (LH)
- (3) Balancer Spring
- (4) Balancer Plate
- (5) Balancer Support
- (6) Anti-scalp Roller
- (7) Mower Deck

(A) Without Self-Balancer

(B) With Self-Balancer

(a) Tilt : Tractor

(b) Tilt : Mower Deck

(c) Ground

(d) Grass

W1014692

SERVICING

CONTENTS

1. GENERAL	7-S1
[1] MOWER IDENTIFICATION	7-S1
[2] LUBRICANTS	7-S2
[3] TIGHTENING (GENERAL USE SCREWS, BOLTS AND NUTS).....	7-S3
[4] MAINTENANCE CHECK LIST	7-S4
[5] CHECK AND MAINTENANCE	7-S5
(1) RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU	7-S5
(2) RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F	7-S8
[6] SETTING UP MOWER	7-S11
(1) RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU	7-S11
(2) RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F ..	7-S14
[7] MOWER ADJUSTMENT	7-S19
2. TROUBLESHOOTING	7-S24
3. SERVICING SPECIFICATIONS	7-S25
4. TIGHTENING TORQUES	7-S26
5. CHECKING, DISASSEMBLING AND SERVICING.....	7-S27
[1] CHECKING AND ADJUSTING	7-S27
[2] DISASSEMBLING AND ASSEMBLING.....	7-S28
[3] SERVICING	7-S34

1. GENERAL

[1] MOWER IDENTIFICATION



When contacting your local KUBOTA distributor, always specify mower serial number.

(1) Mower Serial Number

[A] RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU

[B] RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F

W1020623






[2] LUBRICANTS

No.	Place	Capacity	Lubricants
1	Gear Box	0.36 L 0.38 U.S.qts 0.32 Imp.qts	SAE 90 gear oil (API Service GL-5 gear oil)
Greasing			
2	Universal joint	Until grease overflows.	SAE multi-purpose type grease NLGI-2 or NLGI-1(GC-LB)
3	Three spindle shafts		
4	Belt tension pulley		
5	Belt tension pivot		
6	Balance shaft (RCK60B-23BX-EU and RCK60-23BX-EU-F)		
7	Front and rear anti-scalp roller		

[3] TIGHTENING (GENERAL USE SCREWS, BOLTS AND NUTS)

Screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual should be tightened according to the table below.

Indication on top of bolt	 No-grade or 4T						 7T						 9T		
Indication on top of nut	  No-grade or 4T												   6T		
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness		
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M6	7.9	0.80	5.8	7.9	0.80	5.8	9.81	1.00	7.24	7.9	0.80	5.8	12.3	1.25	9.05
	to 9.3	to 0.95	to 6.8	to 8.8	to 0.90	to 6.5	to 11.2	to 1.15	to 8.31	to 8.8	to 0.90	to 6.5	to 14.2	to 1.45	to 10.4
M8	18	1.8	13	17	1.7	13	24	2.4	18	18	1.8	13	30	3.0	22
	to 20	to 2.1	to 15	to 19	to 2.0	to 14	to 27	to 2.8	to 20	to 20	to 2.1	to 15	to 34	to 3.5	to 25
M10	40	4.0	29	32	3.2	24	48	4.9	36	40	4.0	29	61	6.2	45
	to 45	to 4.6	to 33	to 34	to 3.5	to 25	to 55	to 5.7	to 41	to 44	to 4.5	to 32	to 70	to 7.2	to 52
M12	63	6.4	47	—	—	—	78	7.9	58	63	6.4	47	103	10.5	76.0
	to 72	to 7.4	to 53				to 90	to 9.2	to 66	to 72	to 7.4	to 53	to 117	to 12.0	to 86.7
M14	108	11.0	79.6	—	—	—	124	12.6	91.2	—	—	—	167	17.0	123
	to 125	to 12.8	to 92.5				to 147	to 15.0	to 108				to 196	to 20.0	to 144
M16	167	17.0	123	—	—	—	197	20.0	145	—	—	—	260	26.5	192
	to 191	to 19.5	to 141				to 225	to 23.0	to 166				to 304	to 31.0	to 224
M18	246	25.0	181	—	—	—	275	28.0	203	—	—	—	344	35.0	254
	to 284	to 29.0	to 209				to 318	to 32.5	to 235				to 402	to 41.0	to 296
M20	334	34.0	246	—	—	—	368	37.5	272	—	—	—	491	50.0	362
	to 392	to 40.0	to 289				to 431	to 44.0	to 318				to 568	to 58.0	to 419

W1034542

AMERICAN STANDARD CAP SCREW UNC OR UNF THREADS

Grade	 SAE GR.5			 SAE GR.8		
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
1/4	11.7 to 15.7	1.20 to 1.60	8.63 to 11.5	16.3 to 19.7	1.67 to 2.00	12.0 to 14.6
5/16	23.1 to 27.7	2.36 to 2.82	17.0 to 20.5	33 to 39	3.4 to 3.9	25 to 28
3/8	48 to 56	4.9 to 5.7	36 to 41	61 to 73	6.3 to 7.4	45 to 53
1/2	110 to 130	11.3 to 13.2	81.2 to 95.8	150 to 178	15.3 to 18.1	111 to 131
9/16	150 to 178	15.3 to 18.1	111 to 131	217 to 260	22.2 to 26.5	160 to 191
5/8	204 to 244	20.8 to 24.8	151 to 179	299 to 357	30.5 to 36.4	221 to 263

W1014870

[4] MAINTENANCE CHECK LIST

To keep the mower working in good condition as well as to avoid any accident and trouble, carry out periodic inspection and maintenance. Check the following points before use.


Service interval	Check points	Reference Page
Daily (Each use)	Anything unusual in previous day's operation	–
	Make sure mower blade screws are tighten	7-S5, S8
	Check mower blades for wear or damage	7-S27
	Check gear box oil level	7-S5, S8
	Check oil leaks	–
	Check all hardware	–
	Make sure all pins are in place	–
	Clean mower deck	–
	Apply grease to universal joint	7-S5, S8
	Apply grease to spindle shafts	7-S5, S8
	Apply grease to belt tension pulley	7-S5, S8
	Apply grease to belt tension pivot	7-S5, S8
	Apply grease to balance shaft (RCK60B-23BX-EU and RCK60-23BX-EU-F)	7-S6
	Apply grease to front and rear anti-scalp roller	7-S6
Initial 50 hours	Change gear box oil	7-S6
Every 150 hours	Change gear box oil	7-S6
Every 2 years (After purchase)	Replace gear box oil seal	7-S7, S10

W1025871

[5] CHECK AND MAINTENANCE

(1) RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU

(A) Check Points of Daily or Each Use



Retightening Mower Blade Screw


CAUTION

- **To avoid injury, always handle the mower blade with care.**
1. Dismount the mower and turn it over to expose the mower blades.
 2. Wedge a block of wood securely between the mower blade and mower deck.
 3. Retighten the mower blade screw to the specified torque.
 4. If the mower blade screw is worn or broken, replace it.

Tightening torque	Mower blade screw	98.1 to 117.1 N·m 10.0 to 12.0 kgf·m 72.3 to 86.8 lbf·ft
-------------------	-------------------	--

(1) Mower Blade Screw

W12345678



Checking Gear Box Oil Level

1. Place the mower on level ground.
2. Loosen the check plug (1), and check to see if oil seems from the opening.
3. If the oil level is low, remove the oil filler plug (2) and add new gear oil.


IMPORTANT

- **Use the specified gear oil.**
Refer to "LUBRICANTS". (See page 7-S2.)

(1) Check Plug
(2) Oil Filler Plug

(3) Drain Plug

W12378945




Greasing Universal Joint

1. Grease the internal splines (1) and grease nipples (2) of the universal joint if the amount of grease is insufficient.

(1) Spline

(2) Grease Nipple

W78945645



Greasing Spindle Shafts, Belt Tension Pivot and Tension Pulley


1. Grease the grease nipples (1), (2) of the spindle shafts if the amount of grease is insufficient.

(1) Grease Nipple (Spindle Shaft)

(3) Grease Nipple (Belt Tension Pivot)

(2) Grease Nipple (Belt Tension Pulley)

W98745632




Greasing Balance Shaft (RCK60B-23BX-EU)

1. Grease the grease nipple (1) of the balance shaft if the amount of grease is insufficient.

(1) Grease Nipple

W74136985



Greasing Front and Rear Anti-scalp Rollers (RCK60B-23BX-EU, RCK54-23BX-EU)


1. Grease the grease nipple (1), (2) of the front and rear anti-scalp rollers if the amount of grease is insufficient.

(1) Grease Nipple (Front Anti-scalp Roller)

(2) Grease Nipple (Rear Anti-scalp Roller)

W1026897

(B) Check Point of Initial 50 Hours



Changing Gear Box Oil



CAUTION

- Be sure to stop the engine and remove the key before changing the oil.
1. Dismount the mower from the tractor, and place the mower on level ground.
 2. Remove the oil filler plug (2).
 3. Remove the drain plug (1), and drain the used oil completely.
 4. After draining the used oil, reinstall the drain plug.
 5. Fill with new oil up to the specified level.

■ IMPORTANT

- Use the specified gear oil.
Refer to "LUBRICANTS". (See page 7-S2.)

(1) Drain Plug

(2) Oil Filter Plug


W1027307

(C) Check Point of Every 150 Hours

Changing Gear Box Oil

1. See above.

W1027627


(D) Check Point of Every 2 Years**Replacing Gear Box Oil Seal**

1. Replace the gear box oil seals (1), (2) with new ones.

(1) Oil Seal

(2) Oil Seal

W1027687

(2) RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F**(A) Check Points of Daily or Each Use****Retightening Mower Blade Screw****⚠ CAUTION**


- To avoid injury, always handle the mower blade with care.

1. Dismount the mower and turn it over to expose the mower blades.
2. Wedge a block of wood securely between the mower blade and mower deck.
3. Retighten the mower blade screw to the specified torque.
4. If the mower blade screw is worn or broken, replace it.

Tightening torque	Mower blade screw	98.1 to 117.1 N·m 10.0 to 12.0 kgf·m 72.3 to 86.8 lbf·ft
-------------------	-------------------	--

(1) Mower Blade Screw

W1021952

**Checking Gear Box Oil Level**

1. Place the mower on level ground.
2. Loosen the check plug (1), and check to see if oil seems from the opening.
3. If the oil level is low, remove the oil filler plug (2) and add new gear oil.

■ IMPORTANT

- Use the specified gear oil.


Refer to “LUBRICANTS”. (See page 7-S2.)

(1) Check Plug

(3) Drain Plug

(2) Oil Filler Plug

W1022386


**Greasing Universal Joint**

1. Grease the internal splines (1) and grease nipples (2) of the universal joint if the amount of grease is insufficient.

(1) Spline

(2) Grease Nipple

W1022790

**Greasing Spindle Shafts, Belt Tension Pivot and Tension Pulley**


1. Grease the grease nipples (1), (2) of the spindle shafts if the amount of grease is insufficient.

(1) Grease Nipple (Spindle Shaft)

(3) Grease Nipple (Belt Tension Pivot)

(2) Grease Nipple (Belt Tension Pulley)

W1023156




Greasing Balance Shaft (RCK60-23BX-EU-F)

1. Grease the grease nipple (1) of the balance shaft if the amount of grease is insufficient.

(1) Grease Nipple

W1023519



Greasing Front and Rear Anti-scalp Rollers (RCK60-23BX-EU-F, RCK54-23BX-EU-F)


1. Grease the grease nipple (1), (2) of the front and rear anti-scalp rollers if the amount of grease is insufficient.

(1) Grease Nipple (Front Anti-scalp Roller)

(2) Grease Nipple (Rear Anti-scalp Roller)

W1023869

(B) Check Point of Initial 50 Hours



Changing Gear Box Oil



CAUTION

- Be sure to stop the engine and remove the key before changing the oil.

1. Dismount the mower from the tractor, and place the mower on level ground.
2. Remove the oil filler plug (2).
3. Remove the drain plug (1), and drain the used oil completely.
4. After draining the used oil, reinstall the drain plug.
5. Fill with new oil up to the specified level.

■ IMPORTANT

- Use the specified gear oil.
Refer to "LUBRICANTS". (See page 7-S2.)

(1) Drain Plug

(2) Oil Filter Plug

W1021157


(C) Check Point of Every 150 Hours

Changing Gear Box Oil

1. See above.

W1021573

(D) Check Point of Every 2 Years



Replacing Gear Box Oil Seal

1. Replace the gear box oil seals (1), (2) with new ones.






(1) Oil Seal

(2) Oil Seal

W1021629

[6] SETTING UP MOWER

(1) RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU



Assembling Mower

1. Place the mower on blocks as illustrated.
Turn the anti-scalp rollers sideways and attach to the arms of the deck at the upper position with clevis pins and snap rings. Remove the blocks. (RCK60B-23BX-EU, RCK54-23BX-EU)
2. Attach the front anti-scalp rollers to the deck with clevis pins and snap rings. (RCK48-23BX-EU)
3. Attach the discharge to the deck with the spring, discharge pin and cotter pin.
Secure the spring to the discharge deflector as illustrated.

- | | |
|-----------------------|-------------------------|
| (1) Anti-scalp Roller | (6) Discharge Pin |
| (2) Block | (7) Discharge Deflector |
| (3) Clevis Pin | (8) Spring |
| (4) Snap Ring | (9) Cotter Pin |
| (5) Deck | |

W85236974

Setting Mower




CAUTION

- Park the tractor on a firm, flat and level surface, set the parking brake, stop the engine and remove the key.
1. Start the engine and the hydraulic lever rearward to raise the mower rear link to the highest position.
 2. Stop the engine and remove the key.
 3. Roll the mower under the tractor from right side.

- (1) Hydraulic Control Lever

W96321478



Universal Joint

1. Pull back the coupler (3) of the universal joint (2).
2. Push the universal joint (2) onto the mid-PTO shaft (1), until the coupler locks.
3. Slide the universal joint back and forward to make sure the universal joint is locked securely.



■ IMPORTANT

- Finally, tug on the universal joint to make sure it is locked on the PTO shaft.

- (1) Mid-PTO Shaft
(2) Universal Joint
(3) Coupler

A : Tug

W69724158





Rear Link

1. Set the cutting height control dial (1) to zero inch position.
 2. Operate the tractor's hydraulic control lever (2) forward to lower the mower rear links (3).
- Attach the rear link (3) to the mower with the L pins (4).

- (1) Cutting Height Control Dial
(2) Hydraulic Control Lever
(3) Rear Link
(4) L Pin

W96472687





Front Link

1. Hook the front link (1) to the front bracket groove (2) as shown in the figure.

(Reference)



- Make sure the length (L) of the front link (1) is 47 mm (1.85 in.).

(1) Front Link

L : Length 47 mm (1.85 in.)

(2) Front Bracket Groove

W74569821



Mounting Front Link

1. Position the front lever to the front link bracket.
2. Pull and lock the L pin. Then lower the front lever.
3. Hook the front link to the lever fulcrum, and lift the front lever.
4. Release the L pin to lock the front lever.

■ NOTE

- When hooking the front link to the lever fulcrum, normal position of the lever fulcrum groove is open to downward.

■ IMPORTANT

- Check that the front lever is locked securely with the L pin.

(1) L Pin

(4) Front Lever


(2) Lever Fulcrum

(5) Lever Fulcrum Groove





(3) Front Link Bracket

(6) Front Link

W1028530



(2) RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F



Pre-assembly

1. Take out all mower components from the case and check the parts as illustrated below. (Some of these parts may already be assembled to the mower deck.)

[A] RCK60-23BX-EU-F and RCK54-23BX-EU-F

[B] RCK48-23BX-EU-F

W1027595





Assembling Mower

1. Place the mower on blocks as illustrated.
Turn the anti-scalp rollers sideways and attach to the arms of the deck at the upper position with clevis pins and snap rings.
Remove the blocks. (RCK60-23BX-EU-F, RCK54-23BX-EU-F)
2. Attach the front anti-scalp rollers to the deck with clevis pins and snap rings. (RCK48-23BX-EU-F)
3. Attach the discharge to the deck with the spring, discharge pin and cotter pin.
Secure the spring to the discharge deflector as illustrated.

(1) Anti-scalp Roller
(2) Block

(3) Clevis Pin
(4) Snap Ring

W1025898








Setting Covers

1. Attach the discharge deflector to the deck with the spring, discharge pin and cotter pin.
Secure the spring to the discharge deflector as illustrated.
2. Insert the front universal joint into the front universal joint cover and set two holes to two pins as shown in the figure.
3. Use three bolts to install the universal joint cover stay to the deck securely.
4. Insert the rear universal joint into the rear universal joint cover and connect the rear universal joint to the front universal joint.

- | | |
|---------------------------------|---------------------------------|
| (1) Deck | (9) Hole |
| (2) Spring | (10) Pin |
| (3) Discharge Pin | (11) Universal Joint Cover Stay |
| (4) Cotter Pin | (12) Bolt |
| (5) Discharge Deflector | (13) Deck |
| (6) Front Universal Joint | (14) Front Universal Joint |
| (7) Front Universal Joint Cover | (15) Rear Universal Joint |
| (8) Universal Joint Cover Stay | (16) Rear Universal Joint Cover |

W1028497



Setting Mower and Universal Joint

CAUTION

- **Park the tractor on a firm, flat and level surface, set the parking brake, stop the engine and remove the key.**
- 1. Park the tractor on a firm, flat and level surface and set the parking brake.
- 2. Move the hydraulic control lever rearward to raise the mower rear link to the highest position.
- 3. Stop the engine and remove the key.
- 4. Roll the mower under the tractor from right side.
- 5. Mounting the universal joint.
 - Pull back the coupler of the universal joint.
 - Push the universal joint onto the PTO shaft until the coupler locks.
 - Slide the universal joint back and forth until the universal joint is locked securely.
 - Use two bolts under the stay to install the stay to the bracket as shown in the figure. Set the U-shaped notch of the plate to the pin of the universal joint cover rear stay and use a bolt on the left side of the stay to install the stay and the plate to the bracket.

IMPORTANT


- **Finally, tug on the universal joint to make sure it is locked on the PTO shaft.**

NOTE

- **Adjust the two specified bolts beforehand so that the measurements "L" from the bolt flange to the bracket are approximately 10 mm (0.39 in.) as shown in the figure.**

- | | |
|-------------------------------------|--|
| (1) Hydraulic Control Lever | (7) Pin of Universal Joint Cover Rear Stay |
| (2) Mid PTO | (8) Plate |
| (3) Universal Joint | (9) Bolt |
| (4) Coupler | |
| (5) Universal Joint Cover Rear Stay | |
| (6) Universal Joint Cover Bracket | |
- A : Tug**

W1026300





Attaching Rear Link

1. Attaching the mower to the rear links.
 - Set the cutting height control dial to zero inch position.
 - Move the tractor's hydraulic control lever forward to lower the mower rear links.
 - Attach the rear link to the mower with the L pins.

- (1) Cutting Height Control Dial
(2) Hydraulic Control Lever

- (3) Rear Link
(4) L Pin

W1026635



Attaching Front Link


1. Check that the length "L" of the front link is 47 mm (1.85 in.).
2. Attach the front link to the front bracket groove as shown in the figure.



Length "L"	RCK60-23BX-EU-F RCK54-23BX-EU-F RCK48-23BX-EU-F	47 mm 1.85 in.
------------	---	-------------------

- (1) Front Link
(2) Front Bracket Groove

L : Length

W1026978





Setting Front Link

1. Mounting the front link.

- Position the front lever to the front link bracket.
- Pull and lock the L pin. Then lower the front lever.
- Hook the front link to the lever fulcrum groove, and lift the front lever.
- Release the L pin to lock the front lever.

■ NOTE

- When hooking the front link to the lever fulcrum groove, normal position of the lever fulcrum groove is open to downward.

■ IMPORTANT

- Check that the front lever is locked securely with the L pin.

- | | |
|-------------------|--------------------------|
| (1) L Pin | (4) Front Link |
| (2) Front Lever | (5) Front Link Bracket |
| (3) Lever Fulcrum | (6) Lever Fulcrum Groove |




W1027281

[7] MOWER ADJUSTMENT



CAUTION

- Park the tractor on a firm, flat and level surface and set the parking brake.
- Stoop the engine, remove the key, and allow the blades to stop before making adjustments.
- Wear heavy gloves or wrap end of blade with a rag when you handle blades.
- Before starting the engine, set the PTO clutch lever to off position and range gear shift lever to the neutral position.



Adjusting Parallel Linkage




1. Tire pressure must be correct.
2. Make sure the level of the mower blades is adjusted as shown below. Then tighten the lock nuts securely.
3. Turn the cutting height control dial to "2.0" and the anti-scalp roller's height to keep clearance between rollers and ground from 6 to 13 mm (0.25 to 0.5 in.).
4. Turn right blade by hand parallel to direction of travel.
5. Adjust (L) of front links with lock nuts so that A is 0 to 5 mm (0 to 0.2 in.) $A = (R) - (F)$.
6. If the difference between front tip and rear tip of blade is not within the factory specification, adjust the length L of front link with lock nut (3). The height of rear blade tip R should be bigger than the front.

Difference (R-F) (R ≥ F) between front tip and rear tip of blade	Factory specification	0.0 to 5.0 mm 0.0 to 0.20 in.
--	-----------------------	----------------------------------

- (1) Cutting Height Control Dial
(2) Hydraulic Control Lever
(3) Lock Nut

L : Length of Front Link
F : Height of Blade Tip (Front)
R : Height of Blade Tip (Rear)

W98765412








Adjusting Mower Links

- 1. Tire pressure must be correct.
- 2. Move the hydraulic control lever rearward to raise the mower to the highest position.
- 3. Stop the engine and remove the key.
- 4. Adjust the left side links (See figure (A)) with bolt so that the clearance “L” is as follows. (See figure (B))

Clearance “L” between stopper and rear link	Factory specification	0 to 0.5 mm 0 to 0.02 in.
---	-----------------------	------------------------------

- (1) Bolt
 - (2) Lock Nut
 - (3) Stopper
 - (4) Rear Link
- L : 0 to 0.5 mm (0 to 0.02 in.)**
(A) Adjustment of Adjusting Bolt
(B) Adjustment of Clearance

W8796512



Adjusting Left and Right Cutting Height

1. Tire pressure must be correct.
2. Operate the hydraulic control lever (2) rearward to raise the mower deck to the highest position.
3. Stop the engine and remove the key.
4. Turn the cutting height control dial to the desired height.
5. Set the anti-scalp roller's height to keep clearance between rollers and ground from 6 to 13 mm (0.2 to 0.5 in.).
6. Lower the mower deck by moving the hydraulic control lever forward.
7. Turn left blade by hand parallel to tractor axle and turn right blade parallel to axle to measure from the outside blade tip at **L** and **R** to the level surface.
8. The difference between measurement should be less than 3 mm (0.12 in.).
9. If the difference between measurement is more than 3 mm (0.12 in.), loosen the lock nut of the left side.
10. Adjust the cutting height fine turning bolts so that the difference between measurement **L** and **R** is less than 3 mm (0.12 in.). Then lock the nut.

Difference (L-R) between left tip and right tip of blade	Factory specification	Less than 3 mm 0.12 in.
--	-----------------------	-------------------------------

- (1) Cutting Height Control Dial
 (2) Hydraulic Control Lever
 (3) Cutting Height Fine Turning Bolt
 (4) Lock Nut


L : Left Blade Measurement Position
R : Right Blade Measurement Position

A : Blade Height
H : Height of Cutting Height Fine Turning Bolt

[A] RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU

[B] RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F

W12398745



- Adjusting Self-Balance Suspended Linkage**
(RCK60B-23BX-EU and RCK60-23BX-EU-F)
1. Check the length “L” of balancer spring (2).
 2. If the length “L” is not within the factory specification, adjust the length of balancer spring (2) with lock nut (3).

■ **NOTE**






- **Check the left and right cutting height difference after adjusting the self-balancer linkage.**

Balancer spring length “L” (Right and left)	Factory specification	55.0 mm 2.17 in.
--	-----------------------	---------------------

- (1) Self-Balancer
(2) Balancer Spring
(3) Lock Nut
(4) Plain Washer
(5) Mower Deck

L : Balancer Spring Length

W87945612



Cutting Height



DANGER

- Never operate the mower in transport position.

IMPORTANT

- (for self-balance suspended linkage)
To reduce the stepped difference in cutting height when mowing rolling terrain, follow the procedure below.
1. To set the cutting height, move the hydraulic control lever rearward to raise the mower to the highest position. Turn the cutting height control dial (1) to adjust height.
 2. Set the anti-scalp roller's (3) height as shown to keep clearance between rollers and ground from 6 to 13 mm (0.2 to 0.5 in.).
 3. Lower the mower deck by moving the hydraulic control lever (2) forward.
 4. Use the higher settings for mowing in a rough area or when mowing tall grass. Lower settings should be used only for smooth lawns where short grass is desired.
 5. To set the cutting height, move the hydraulic control lever (2) rearward to raise the mower to the highest position. Turn the cutting height control dial to adjust height.
 6. Set the anti-scalp roller's (3) position as shown to have the same cutting height.

Dial (Cutting Height)	Anti-scalp Roller
25 mm (1.0 in.), 32 mm (1.25 in.)	G
38 mm (1.5 in.), 45 mm (1.75 in.)	F
51 mm (2.0 in.), 57 mm (2.25 in.)	E
64 mm (2.5 in.), 70 mm (2.75 in.)	D
76 mm (3.0 in.), 83 mm (3.25 in.)	C
89 mm (3.5 in.), 95 mm (3.75 in.)	B
102 mm (4.0 in.)	A

- (1) Cutting Height Control Dial
(2) Hydraulic Control Lever
(3) Anti-scalp Roller

[A] RCK60B-23BX-EU, RCK54-23BX-EU, RCK60-23BX-EU-F and RCK54-23BX-EU-F

[B] RCK48-23BX-EU and RCK48-23BX-EU-F

W1029723

2. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Blade Does Not Turn	Mid-PTO system malfunctioning	Check transmission	2-S39, S40
	Broken mower belt	Replace mower belt	7-S29
Blade Speed Is Slow	Loosen mower belt	Replace mower belt or tension spring	7-S29
	Clogged grass	Remove grass	–
	Flattened out or worn cup washer	Replace cup washer	7-S28
	Engine rpm too low	Mow at full throttle, check and reset engine rpm	–
Cutting Is Poor	Worn or broken mower blade	Sharpen or replace mower blade	7-S27, S28
	Loosen mower blade screw	Retighten mower blade screw	7-S28
	Cutting height improper	Adjust cutting height	7-S23
	Ground speed too fast	Slow-down	–
	Low tire inflation	Add air to correct	G-44
	Anti-scalp rollers not adjusted correctly	Adjust anti-scalp rollers	7-S23
Mower Is Not Lifted	Broken linkage system	Replace linkage system	7-M3, M4
	Trouble of hydraulic system	Check hydraulic system	–

W1014322

3. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Input Shaft (without Mower Belt)	Turning Force	Less than 117.7 N 12.0 kgf 26.5 lbf	—
	Turning Torque	Less than 1.47 N·m 0.15 kgf·m 1.08 lbf·ft	—
Bevel Gears in Gear Box	Backlash	0.1 to 0.2 mm 0.0039 to 0.0078 in.	0.4 mm 0.0157 in.

W1013874

4. TIGHTENING TORQUES


Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts: See page 7-S3.)

Item	N·m	kgf·m	lbf·ft
Gear box mounting screw and nut	77.4 to 90.2	7.9 to 9.2	57.1 to 66.5
Mower blade screw	102.9 to 117.7	10.5 to 12.0	75.9 to 86.8
Center pulley holder bolt and nut	77.4 to 90.2	7.9 to 9.2	57.1 to 66.5
Outer pulley mounting nut	196.17 to 225.6	20.0 to 23.0	144.7 to 166.4
Gear box bracket (RH) mounting bolt and nut	77.4 to 90.2	7.9 to 9.2	57.1 to 66.5
Pulley boss mounting nut	23.5 to 27.4	2.4 to 2.8	17.4 to 20.3
Pulley holder mounting bolt and nut (RCK48-23BX-EU and RCK48-23BX-EU-F)	48.0 to 55.9	4.9 to 5.7	35.4 to 41.2
Pulley holder mounting bolt and nut	77.4 to 80.2	7.9 to 9.2	57.1 to 66.5

W1012736

5. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING



Checking Mower Blade

1. Check the cutting edge of mower blade.
2. Sharpen the cutting edges, if the mower blades are as shown in figure (2).
3. Replace the mower blades, if they are as shown in figure (3).

■ IMPORTANT

- Never forget to set the dust cover, cup washer(s) and lock washer (RCK54-23BX-EU, RCK60B-23BX-EU, RCK54-23BX-EU-F and RCK60-23BX-EU-F), when reassembling the mower blades. (See page 7-S28.)


■ NOTE

- To sharpen the mower blades by yourself, clamp the mower blade securely in a vise and use a grinder along the original until sharp.
- To balance the mower blade, place a small rod through the center hole and check to see if the blade balance evenly. File heavy side of the blade until it balance out even.

- (1) New Blade
(2) Worn Blade

- (3) Cracked Blade

W1011041



Checking Mower Belt

1. Check to see the mower belt.
2. Replace the mower belt with a new one, if there is found surface split at more than 3 positions.

(When replacing mower belt)

1. Dismount the mower from the tractor.
2. Remove the left and right hand belt cover from the mower deck.
3. Clean around the gear box.
4. Remove the right hand bracket (3) which mounts the gear box to the mower deck.
5. Remove the mower belt (2) from the tension pulley (1). Slip the mower belt over the top of the gear box.
6. To install a new belt, reverse the above procedure.

Tightening torque	Gear box bracket RH mounting bolt and nut	77.4 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 lbf·ft
	Gear box bracket RH mounting screw (for aluminum gear case)	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 28.9 to 32.5 lbf·ft


■ IMPORTANT

- After setting the gear box bracket mounting screws on the deck without tightening, then mount the other screws on the gear box. And finally tighten them.


- (1) Tension Pulley
(2) Mower Belt

- (3) Gear Box Bracket (Right)

W1011180



[2] DISASSEMBLING AND ASSEMBLING




Universal Joint and Belt Cover (RCK48-23BX-EU, RCK54-23BX-EU and RCK60B-23BX-EU)

1. Unscrew the universal joint screw.
2. Remove the universal joint (1).
3. Remove the left and right belt covers (2), (3).

(1) Universal Joint (3) Belt Cover (Right)
(2) Belt Cover (Left)

W1012580



Universal Joint Cover, Universal Joint and Belt Cover (RCK48-23BX-EU-F, RCK54-23BX-EU-F and RCK60-23BX-EU-F)

1. Remove the shields (1), (4) and the covers (2), (3), (6).
2. Remove the universal joint (5).

(1) Left Shield (4) Right Shield
(2) Joint Cover (5) Universal Joint
(3) Center Cover (6) Joint Cover

W1032740



Mower Blades (Center Blade and Outer Blades)

1. Turn over the mower.
2. Unscrew the mower blade screw (5), and remove the lock washer (4), cup washer(s) (3), mower blade (2) and dust cover (1).

■ NOTE

- To remove the blade securely, wedge a block of wood between one blade and the mower deck in such position that it will hold the blade safely while loosening or tightening the blade screw.

(When reassembling)

[RCK48-23BX-EU, RCK54-23BX-EU, RCK48-23BX-EU-F and RCK54-23BX-EU-F]



- Install the blade in position together with the dust cover and the cup washer. Tighten them up with the screw.

[RCK60B-23BX-EU and RCK60-23BX-EU-F]

- Install the blade in position together with the dust cover, the lock washer and the 2 cup washers. Tighten them up with the screw.

■ IMPORTANT

- Make sure the cup washer is not flattened out or worn, causing blade to slip easily.
Replace cup washer(s) if either is damaged.



Tightening torque	Mower blade screw	102.9 to 117.7 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 lbf·ft
-------------------	-------------------	---


- (1) Dust Cover
(2) Mower Blade
(3) Cup Washer
(4) Lock Washer
(5) Mower Blade Screw

(A) RCK48-23BX-EU, RCK54-23BX-EU, RCK48-23BX-EU-F and RCK54-23BX-EU-F

(B) RCK60B-23BX-EU and RCK60-23BX-EU-F

a : Loosen


W1012667



Blade Boss
1. Remove the external snap ring (2).
2. Remove the blade boss (1).

(1) Blade Boss(2) External Snap Ring

W1012871



Gear Box and Mower Belt
1. Turn over the mower.
2. Remove the mower belt (3) from the tension pulley (5).
3. Unscrew the left and right gear box mounting screws (2), (4) and remove the gear box (1) from the mower deck.

(When reassembling)


- Install the reamer screws (2) at their original positions as shown in the figure.

Tightening torque	Gear box mounting screw and nut	77.4 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 lbf·ft
	Gear box mounting screw (for aluminum gear case)	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 28.9 to 32.5 lbf·ft

(1) Gear Box(2) Gear Box Mounting Screw (Reamer Screw)(3) Mower Belt

(4) Gear Box Mounting Screw(5) Tension Pulley(6) Tension Spring

W1012961



Disassembling Gear Box (RCK54-23BX-EU, RCK54-23BX-EU-F, RCK60B-23BX-EU, RCK60-23BX-EU-F)


1. Unscrew the drain plug (16), and drain the gear box oil.
2. Remove the center pulley (20) with a puller, and remove the feather key (19) on the bevel gear shaft.
3. Remove the gear box cap (5).
4. Remove the oil seal (10), internal snap ring (11) and shim (9).
5. Tap out the pinion shaft (14) with the ball bearing (13), and remove the bevel gear (1).
6. Remove the external snap ring (6), and draw out the bevel gear shaft (18).
7. Remove the bevel gear (7), ball bearing (8), shim (9) and oil seal (17).

(When reassembling)

- Replace the oil seals (10), (17) and gear box cap (5) with new one.
- Check the backlash and turning torque.
If not proper, adjust with the shims (9), (12).
(See page 7-S35.)

- | | |
|---|-------------------------|
| (1) 19T Bevel Gear (RCK54-23BX-EU, RCK54-23BX-EU-F) | (11) Internal Snap Ring |
| (2) Breather | (12) Shim |
| (3) Gear Box | (13) Ball Bearing |
| (4) Ball Bearing | (14) Pinion Shaft |
| (5) Gear Box Cap | (15) Oil Filler Plug |
| (6) External Snap Ring | (16) Drain Plug |
| (7) 16T Bevel Gear (RCK54-23BX-EU, RCK54-23BX-EU-F) | (17) Oil Seal |
| (8) Ball Bearing | (18) Bevel Gear Shaft |
| (9) Shim | (19) Feather Key |
| (10) Oil Seal | (20) Center Pulley |

W1018143



Center Pulley Holder

1. Unscrew the center pulley holder screws (1), (15) / center pulley nut (5), (11).
2. Remove the upper oil seal (6) and lower oil seal (4).
3. Remove the internal snap ring (3) and ball bearing (2).

(When reassembling)

- Replace the oil seals (4), (6) with new ones.
- Install the reamer screws (12) / reamer bolt (15) at their original positions as shown in the figure.
- Be sure to fix the O-rings (7), (13) to the original position.


NOTE

- When reassembling the center pulley holder (14), gear box and gear box stays (9), (10), tighten the bolts and nuts in the order as below, to prevent the incline the gear box.
- Tighten the reamer bolts (12) to the gear box first, then tighten the reamer bolts (15) and nut (11) to the center pulley holder (14) with the specified torque.
- Tighten the gear box bolts (8) to the gear box, then tighten the center pulley holder bolts (1) and the nut (5) with the specified torque.
- See page 7-S29 for tightening torque of the gear box screw.

Tightening torque	Center pulley holder bolt and nut	77.4 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 lbf·ft
-------------------	-----------------------------------	---

- | | |
|-------------------------------|---------------------------------------|
| (1) Center Pulley Holder Bolt | (9) Gear Box Stay RH |
| (2) Ball Bearing | (10) Gear Box Stay LH |
| (3) Snap Ring | (11) Nut |
| (4) Lower Oil Seal | (12) Gear Box Reamer Bolt |
| (5) Nut | (13) O-ring |
| (6) Upper Oil Seal | (14) Center Pulley Holder |
| (7) O-ring | (15) Center Pulley Holder Reamer Bolt |
| (8) Bolt | (16) Collar |

W1013720




Outer Pulley and Blade Shaft

1. Unscrew the outer pulley mounting nut (22), and remove the outer pulley (28).
2. Unscrew the pulley holder mounting nut (30), and remove the left pulley holder (36).
3. Remove the oil seal (39) and tap out the left blade shaft (40) with the ball bearings (38), (34), taking care not to damage the grease nipple (21).
4. Remove the oil seal (33).
5. Remove the ball bearings (38), (34) and collar (35) from the blade shaft (40).
6. Remove the right pulley holder (16) and blade shaft (20) as above.

(When reassembling)

- Replace the oil seals (33), (39), (13) and (19) with new ones.

Tightening torque	Outer pulley mounting nut	196.1 to 225.6 N·m 20.0 to 23.0 kgf·m 144.7 to 166.4 lbf·ft
	Pulley boss mounting nut	23.5 to 27.4 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 lbf·ft
	Pulley holder mounting bolt and nut (RCK48-23BX-EU and RCK48-23BX-EU-F)	48.0 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 lbf·ft
	Pulley holder mounting bolt and nut (RCK54-23BX-EU, RCK60B-23BX-EU, RCK54-23BX-EU-F and RCK60-23BX-EU-F)	77.4 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 lbf·ft





- | | |
|----------------------------------|----------------------------------|
| (1) Grease Nipple | (23) Spring Washer |
| (2) Outer Pulley Mounting Nut | (24) Plain Washer |
| (3) Spring Washer | (25) Pulley Boss Mounting Nut |
| (4) Plain Washer | (26) Spring Washer |
| (5) Outer Pulley Boss (Right) | (27) Outer Pulley Boss (Left) |
| (6) Outer Pulley (Right) | (28) Outer Pulley (Left) |
| (7) Pulley Holder Mounting Nut | (29) Pulley Boss Mounting Bolt |
| (8) Spring Washer | (30) Pulley Holder Mounting Nut |
| (9) Pulley Boss Mounting Bolt | (31) Spring Washer |
| (10) Pulley Holder Mounting Nut | (32) Plate (RCK48-23BX-EU) |
| (11) Spring Washer | (33) Oil Seal |
| (12) Plate (RCK48-23BX-EU) | (34) Ball Bearing |
| (13) Oil Seal | (35) Collar |
| (14) Ball Bearing | (36) Pulley Holder (Left) |
| (15) Collar | (37) Pulley Holder Mounting Bolt |
| (16) Pulley Holder (Right) | (38) Ball Bearing |
| (17) Pulley Holder Mounting Bolt | (39) Oil Seal |
| (18) Ball Bearing | (40) Blade Shaft (Left) |
| (19) Oil Seal | |
| (20) Blade Shaft (Right) | |
| (21) Grease Nipple | |
| (22) Outer Pulley Mounting Nut | |

[A] RCK48-23BX-EU and RCK48-23BX-EU-F

[B] RCK54-23BX-EU, RCK60B-23BX-EU, RCK54-23BX-EU-F and RCK60-23BX-EU-F

W1018943



Balancer (RCK60B-23BX-EU and RCK60-23BX-EU-F)

1. Remove the shields and the covers.
2. Unscrew the lock nut (1) both side.
3. Remove the plain washer (2) and balancer spring (3).
4. Unscrew the center pin bolt (6).
5. Remove the center pin (5) and balancer plate (4).

(When reassembling)

- Apply grease to the center pin (5).
- Adjust the balancer spring (3) length to the factory specification, with lock nut (1).


Balancer spring length “L” (Right and left)	Factory specification	55.0 mm 2.1653 in.
--	-----------------------	-----------------------

- (1) Lock Nut
(2) Plain Washer
(3) Balancer Spring
(4) Balancer Plate
(5) Center Pin
(6) Center Pin Bolt

L : Length

W1017924

[3] SERVICING



Turning Torque of Pinion Shaft

- 1. Remove the mower belt, and reassemble the gear box to the mower deck.
- 2. Wind a string around the pinion shaft and set a spring balance (or push-pull gauge) to the tip of the string, and then slowly pull the spring balance horizontally to measure the turning force.
- 3. If the measurement exceeds the factory specification, check the bearing and gears and adjust the adjusting shims (2), (6).

Turning force	Factory specification	Less than 117.7 N 12.0 kgf 26.5 lbf
Turning torque	Factory specification	Less than 1.47 N·m 0.15 kgf·m 1.08 lbf·ft

(Reference)

- Thickness of adjusting shims (2) : 0.2 mm (0.0079 in.)
0.3 mm (0.0118 in.)
- Thickness of adjusting shims (6) : 0.1 mm (0.0039 in.)
0.2 mm (0.0079 in.)

- (1) Bearing

(2) Adjusting Shim


(3) Cir-clip

(4) Bearing
- (5) Adjusting Shim

(6) Adjusting Shim

(7) Gear Box

W1019836



Backlash between Bevel Gears

1. Remove the gear box cap (3).
2. Place fuses the bevel gear (2) on the input shaft (7).
3. Turn the input shaft (7).
4. Take out the fuses, and measure the thickness of fuses with an outside micrometer. (Backlash equal thickness of fuse)
5. If the backlash exceeds the allowable limit, adjust with shims (1), (5), (10).

Backlash between bevel gears	Factory specification	0.10 to 0.20 mm 0.0039 to 0.0079 in.
	Allowable limit	0.4 mm 0.0157 in.

(Reference)

- Thickness of adjusting shims (5) : 0.2 mm (0.0079 in.)
0.3 mm (0.0118 in.)
- Thickness of adjusting shims (10) : 0.1 mm (0.0039 in.)
0.2 mm (0.0079 in.)

- (1) Shim
(2) 21T Bevel Gear
(RCK48-23BX-EU and RCK48-23BX-EU-F)
19T Bevel Gear
(RCK54-23BX-EU and RCK54-23BX-EU-F)
18T Bevel Gear
(RCK60B-23BX-EU and RCK60-23BX-EU-F)

- (3) Gear Box Cap
(4) Bearing
(5) Shim
(6) Cir-clip
(7) Input Shaft
(8) Bevel Gear
(9) Bearing
(10) Shim

W1020126


8 FRONT LOADER

MECHANISM

CONTENTS

1. HYDRAULIC CIRCUIT	8-M1
2. CONTROL VALVE ASSEMBLY	8-M2
[1] STRUCTURE	8-M2
[2] OPERATION	8-M3
3. BOOM CYLINDER AND BUCKET CYLINDER	8-M10

1. HYDRAULIC CIRCUIT




W1016476

To operate the front loader, the hydraulic oil pressurized by the hydraulic pump flows from **P** port through the boom control valve (4) and the bucket control valve (1) to **P.B.** port or **T** port.

Since relief valve is not equipped in the front loader control valve, the main relief valve in the tractor operates.

2. CONTROL VALVE ASSEMBLY

[1] STRUCTURE



- (1) Inlet and Outlet Section
- (2) Boom Control Valve
- (3) Bucket Control Valve
- (4) Power Beyond

P : P Port (From Pump)
T : T Port (To Tank)

A1 : A1 Port
A2 : A2 Port

B1 : B1 Port
B2 : B2 Port
P.B. : P.B. Port

The control valve assembly is composed of one casting block and four major section as shown above.

(1) Inlet and Outlet Section

This section has **P** and **T** ports.

The **P** port is connected to the **OUTLET** port of hydraulic block by the hydraulic hose.

The **T** port is connected to the **TANK** port of hydraulic block by the hydraulic hose.

(2) Boom Control Section

The boom control valve is of 4-position, 6-connection, detent, spring center type, consisting of a mono block valve housing, spool, load check valve, etc. This valve has **A1** and **B1** ports and controls oil flow to the boom cylinder.

(3) Bucket Control Section


The bucket control valve is of 4-position, 6-connection, no detent, spring center type, consisting of a mono block valve housing, spool, load check valve, etc. This valve has **A2** and **B2** ports and controls oil flow to the bucket cylinder.

(4) Power Beyond

This section has **P.B.** port which is connected to the **INLET** port of hydraulic block by the hydraulic hose, and feeds oil to the three point hydraulic control valve.

[2] OPERATION

■ **Neutral**




- (1) Boom Control Section
- (2) Bucket Control Section
- (3) Spool
- (4) Spool

- (5) **P.B.** Passage 1
(6) **P.B.** Passage 2
(7) Load Check Valve

- T : T Port (To Tank)**
P : P Port (From Pump)
A1 : A1 Port
A2 : A2 Port

- B1 : B1 Port
B2 : B2 Port
P.B. :P.B. Port
a : Low Pressure

■ Up



- (1) Boom Control Section
- (2) Bucket Control Section
- (3) Spool
- (4) P.B. Passage 1


- (5) Neutral Passage 1
- (6) Load Check Valve
- (7) Passage 1
- (8) Boom Cylinder

- P : P Port (From Pump)
- T : T Port (To Tank)
- A1 : A1 Port
(From Boom Cylinder)

- B1 : B1 Port (To Boom Cylinder)
- P.B. : P.B. Port (To 3 Hitch)
- a : Low Pressure
- b : High Pressure

1. When the hydraulic control lever is set to the "UP" position, the spool (3) of the boom control section (1) moves to the left, which forms oil passages between passage 1 (7) and B1 port, and between A1 port and P.B. passage 1 (4).
2. As the oil passage from the neutral passage 1 (5) to the P.B. passage 1 (4) is closed by the spool (3), the pressure-fed oil from the P port opens the load check valve (6) and flows through the notched section of the spool (3) and B1 port to extend the boom cylinder (8).
3. Return oil from the boom cylinder (8) flows from the A1 port through the passage in the spool (3) and P.B. passage 1 (4) to the bucket control section (3).

Down



- (1) Boom Control Section
- (2) Bucket Control Section
- (3) Spool
- (4) P.B. Passage 1

- (5) Neutral Passage 1
- (6) Load Check Valve
- (7) Passage 1
- (8) Boom Cylinder

P : P Port (From Pump)
T : T Port (To Tank)

A1 : A1 Port (To Boom Cylinder)

B1 : B1 Port
(From Boom Cylinder)


P.B. : P.B. Port (To 3 Hitch)

a : Low Pressure

b : High Pressure

1. When the hydraulic control lever is set to the “**DOWN**” position, the spool (3) moves to the right, which forms oil passages between passage 1 (7) and **A1** port, and between **B1** port and **P.B.** passage 1 (4).
2. As the oil passage from the neutral passage 1 (5) to the **P.B.** passage 1 (4) is closed by the spool (3), the pressurized oil from the **P** port opens the load check valve (6) and flows through the notched section of the spool (3) and **A1** port to retract the boom cylinder (8).
3. Return oil from the boom cylinder (8) flows from the **B1** port through the passage in the spool (3) and **P.B.** passage 1 (4) to the bucket control section (2).

Floating



- (1) Boom Control Section
- (2) Bucket Control Section
- (3) Spool
- (4) P.B. Passage 1


- (5) Detent Mechanism
- (6) Neutral Passage 1
- (7) Boom Cylinder

P : P Port (From Pump)
T : T Port (To tank)

A1 : A1 Port
B1 : B1 Port
P.B. : P.B. Port (To 3 Hitch)
a : Low Pressure

1. When the hydraulic control lever is set to the “FLOAT” position, the spool (3) moves further to the right from the “DOWN” position and is retained by the detent mechanism (5).
2. This forms oil passages among the A1 port, B1 port and T port. As a result, oil in the boom cylinder (7) flows freely from the A1 port and B1 port through the T port to the transmission case.
3. Oil entering the P port flows to the bucket control section (2) through the neutral passage 1 (6) and P.B. passage 1 (4).

Roll-back



3TAAAAGLP021A

- (1) Boom Control Section
- (2) Bucket Control Section
- (3) P.B. Passage 1
- (4) Spool
- (5) Neutral Passage 2


- (6) P.B. Passage 2
- (7) Load Check Valve
- (8) Passage 2
- (9) Bucket Cylinder

P : P Port (From Pump)
T : T Port (To Tank)
P.B. : P.B. Port (To 3 Hitch)
A2 : A2 Port
 (From Bucket Cylinder)

B2 : B2 Port
 (To Bucket Cylinder)
a : Low Pressure
b : High Pressure

1. When the hydraulic control lever is set to the “**ROLL-BACK**” position, the spool (4) of the bucket control section (2) moves to the left, which forms oil passages between passage 2 (8) and **B2** port, and between **A2** port and **T** port.
2. The pressure-fed oil from the **P** port flows to the neutral passage 2 (5) through the boom control section (1) and **P.B.** passage 1 (3). As the oil passage from the neutral passage 2 (5) to the **P.B.** passage 2 (6) is closed by the spool (4), this oil opens the load check valve (7), and flows through the notched section of the spool (4) and **B2** port to retract the bucket cylinder (9).
3. Return oil from the bucket cylinder (9) flows to the transmission case through the **A2** port and **T** port.

■ Dump 1



- (1) Boom Control Section
- (2) Bucket Control Section
- (3) P.B. Passage 1
- (4) Spool
- (5) Neutral Passage 2

- (6) P.B. Passage 2
- (7) Load Check Valve
- (8) Passage 2
- (9) Bucket Cylinder

P : P Port (From Pump)
T : T Port (To Tank)
P.B. : P.B. Port (To 3 Hitch)


A2 : A2 Port
 (To Bucket Cylinder)
B2 : B2 Port
 (From Bucket Cylinder)
b : High Pressure

1. When the hydraulic control lever is set to the “**DUMP 1**” position, the spool (4), which forms oil passages among passage 2 (8), **A2** port and **B2** port.
2. The pressure-fed oil from the **P** port flows through the boom control valve, opens the load check valve, and flows to the bucket cylinder to extend the cylinder through the notched section of the spool and **A2** port.
3. Return oil from the bucket cylinder (9) flows from the **B2** port to the passage 2 (8), and flows to the **A2** port together with the pressure-fed oil from the **P** port. As a result, the dump speed is increased.

(Reference)

- The oil pressure of the **A2** port and **B2** port is identical, but the bucket cylinder extends by the difference of received pressure area (cylinder rod part).

■ Dump 2



- (1) Boom Control Section
- (2) Bucket Control Section
- (3) P.B. Passage 1
- (4) Spool
- (5) Neutral Passage 2


- (6) P.B. Passage 2
- (7) Load Check Valve
- (8) Passage 2
- (9) Bucket Cylinder

P : P Port (From Pump)
T : T Port (To Tank)
P.B. : P.B. Port (To 3 Hitch)

A2 : A2 Port
(To Bucket Cylinder)
B2 : B2 Port
(From Bucket Cylinder)
a : Low Pressure
b : High Pressure

1. When the hydraulic control lever is set to the “DUMP 2” position, the spool (4) of the bucket control section (2) moves to the right of the bucket control section (2) moves further to the right from the “DUMP 1” position, which forms oil passages between passage 2 (8) and A2 port, and between B2 port and T port.
2. The pressure-fed oil from the P port flows to the neutral passage 2 (5) through the boom control section (1) and P.B. passage 1 (3). As the oil passage from the neutral passage 2 (5) to the P.B. passage 2 (6) is closed by the spool (4), this oil opens the load check valve (7) and flows through the notched section of the spool (4) and B2 port to extend the bucket cylinder (9).
3. Return oil from the bucket cylinder (9) flows to the transmission case through the B2 port and T port.

3. BOOM CYLINDER AND BUCKET CYLINDER



3UFAAACLP017A

- (1) Nut
(2) Piston
(3) Cylinder Tube
(4) Head
(5) Piston Rod

Both boom cylinder and bucket cylinder consists of a head (4), cylinder tube (3), piston rod (5), piston (2), and other parts as shown in the figure above. They are single-rod double acting cylinder in which the reciprocating motion of the piston is controlled by hydraulic force applied to both of its ends.

Cylinder Specifications

		LA243
Boom Cylinder	Cylinder I.D.	40 mm (1.57 in.)
	Rod O.D.	25 mm (0.98 in.)
	Stroke	326 mm (12.8 in.)
Bucket Cylinder	Cylinder I.D.	65 mm (2.56 in.)
	Rod O.D.	30 mm (1.18 in.)
	Stroke	204 mm (8.03 in.)

W1025274


SERVICING

CONTENTS

1. GENERAL	8-S1
[1] IDENTIFICATION.....	8-S1
[2] GENERAL PRECAUTION	8-S1
[3] LUBRICANTS	8-S2
[4] MAINTENANCE CHECK LIST	8-S2
[5] CHECK AND MAINTENANCE.....	8-S2
(1) Check Points of Each Use or Daily	8-S2
(2) Check Points of Every 10 Hours	8-S3
2. TROUBLESHOOTING	8-S4
3. SERVICING SPECIFICATIONS	8-S5
4. TIGHTENING TORQUES	8-S6
[1] GENERAL USE SCREWS, BOLTS AND NUTS.....	8-S6
[2] HYDRAULIC FITTINGS.....	8-S6
[3] TIGHTENING TORQUES OF SCREWS, BOLTS AND NUTS ON THE TABLE BELOW ARE ESPECIALLY SPECIFIED	8-S6
5. DISMOUNTING AND MOUNTING FRONT LOADER FROM TRACTOR.....	8-S7
[1] DISMOUNTING FRONT LOADER FROM TRACTOR	8-S7
[2] MOUNTING FRONT LOADER TO TRACTOR.....	8-S8
6. CHECKING, DISASSEMBLING AND SERVICING.....	8-S9
[1] CONTROL VALVE	8-S9
(1) Checking and Adjusting	8-S9
(2) Disassembling and Assembling	8-S9
[2] BUCKET, BOOM AND HYDRAULIC CYLINDERS.....	8-S12
(1) Disassembling and Assembling	8-S12
(2) Servicing	8-S15
[3] SIDE FRAMES, FRONT GUARD AND MAIN FRAMES.....	8-S15
(1) Disassembling and Assembling	8-S15

1. GENERAL

[1] IDENTIFICATION




When contacting your local KUBOTA distributor, always specify front loader model and serial number.

(1) Model / Serial Number

W1010468

[2] GENERAL PRECAUTION



- During disassembly, carefully arrange removed parts in a clean area to prevent later confusion. Screws, bolts and nuts should be replaced in their original positions to prevent reassembly errors.
- When special tools are required, use KUBOTA genuine tools. Special tools which are not used frequently should be made according to the drawings provided.
- Clean parts before measuring them.
- Use only KUBOTA genuine parts for parts replacement to maintain loader performance and to assure safety.
- O-ring and oil seals must be replaced during reassembly. Apply grease to new O-rings or oil seals before reassembling.

A : Grease

W1010531

[3] LUBRICANTS

To prevent serious damage to hydraulic system, use only specified fluid or its equivalent.

Place	Capacities	Lubricants
Transmission Case	11.6 L 3.1 U.S.gals 2.6 Imp.gals	KUBOTA SUPER UDT Fluid *
Grease fitting	Until grease overflows	Moly Ep Type grease

■ NOTE

- * KUBOTA SUPER UDT Fluid.....KUBOTA original transmission hydraulic fluid

W1010650

[4] MAINTENANCE CHECK LIST

To keep the machine working in good condition as well as to avoid any accident and trouble, carry out periodic inspection and maintenance. Check the following points before use.

Service Interval	Check Points	Reference Page
Daily (Each use)	Check the transmission fluid level	8-S2
	Check the hydraulic hoses	8-S2
Every 10 hours	Grease all grease fitting	8-S3
	Lubricate joints of control lever linkage	8-S3

W1010764


[5] CHECK AND MAINTENANCE



CAUTION

- When checking and repairing, park the tractor on flat ground and apply the parking brake.
- When checking and repairing, lower the bucket and stop the engine.

(1) Check Points of Each Use or Daily



3TAAAAH0P005B

Checking Transmission Fluid Level

1. Check the oil level at the dipstick (1).
2. If the level is too low, add new oil to the prescribed level at the oil inlet.


■ IMPORTANT

- If oil level is low, do not run engine.

(1) Dipstick

(A) Oil level is acceptable within this range.

W1010960



3TVAAACLP003A

Checking Hydraulic Hoses


1. Checking all hydraulic hoses for cuts or wear.
2. If defects are found, replace them.

(1) Hydraulic Hose

(3) Magnifying Glass

(2) Cardboard

W1011064

(2) Check Points of Every 10 Hours**Greasing**

1. Inject grease in all grease fitting with a hand grease gun.

W1011132

Lubricating

1. Lubricate joints of control lever linkage.

W1011274

2. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Boom Does Not Rise	Control valve malfunctioning	Repair or replace	8-S11
	Boom cylinder defective	Repair or replace	8-S12
	Control lever linkage defective	Repair or replace	8-S10
	Hydraulic pump malfunctioning	Repair or replace	2-S33
	Oil filter clogged	Clean or replace	G-13
	Hydraulic hose damaged	Replace	–
Boom Does Not Lower	Control valve malfunctioning	Repair or replace	8-S11
Insufficient Boom Speed	Boom cylinder tube worn or damaged	Replace	8-S12
	Boom cylinder piston ring (piston seal and O-ring) worn or damaged	Replace	8-S14
	Oil leaks from tube joints	Repair	8-S12
	Relief valve setting pressure too low	Adjust	8-S9
	Insufficient transmission fluid	Refill	8-S2
	Dirty relief valve	Clean	5-S4
Bucket Does Not Move	Control valve malfunctioning	Repair or replace	8-S11
	Bucket cylinder defective	Repair or replace	8-S12
	Control lever linkage defective	Repair or replace	8-S10
	Hydraulic pump malfunctioning	Repair or replace	2-S33
	Oil filter clogged	Clean or replace	G-13
	Relief valve spring damaged	Replace	5-S4
	Hydraulic hose damaged	Replace	–
	Dirty relief valve	Clean	5-S4
Insufficient Bucket Speed	Bucket cylinder tube worn or damaged	Replace	8-S13
	Bucket cylinder piston ring (piston seal and O-ring) worn or damaged	Replace	8-S14
	Oil leaks from tube joints	Repair	–
	Insufficient transmission fluid	Refill	8-S2
Front End Loader Drops by its Weight	Boom cylinder tube worn or damaged	Replace	8-S12
	Boom cylinder piston ring (piston seal and O-ring) worn or damaged	Replace	8-S14
	Oil leaks from tube joints	Repair	–
	Control valve malfunctioning	Repair or replace	8-S11

W1014322

3. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Piston Rod	Bend	—	0.25 mm 0.0098 in.

W1013874

4. TIGHTENING TORQUES

[1] GENERAL USE SCREWS, BOLTS AND NUTS

Screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual should be tightened according to the table below.

American standard cap screws with UNC or UNF Threads				Metric cap screws			
Grade	SAE 5 or 8			Grade	Property class 8.8 (Approx. SAE grade 5)		
Size \ Unit	N·m	kgf·m	lbf·ft	Size \ Unit	N·m	kgf·m	lbf·ft
1/4	9.8 to 11.7	1.0 to 1.2	7.2 to 8.6	M6	9.8 to 11.2	1.0 to 1.1	7.2 to 8.3
5/16	19.0 to 23.1	1.9 to 2.4	14 to 17	M8	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2
3/8	33.9 to 40.7	3.5 to 4.2	25 to 30	M10	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2
1/2	88.1 to 105.8	9.0 to 10.8	65 to 78	M12	77.5 to 90.1	7.9 to 9.2	57.2 to 66.5
9/16	122.0 to 146.4	12.4 to 14.9	90 to 108	M14	124 to 147	12.6 to 15.0	91.2 to 108
5/8	176.3 to 211.5	18.0 to 21.6	130 to 156	M16	196 to 225	20.0 to 23.0	145 to 166
–	–	–	–	M18	275 to 318	28.0 to 32.5	203 to 235

W1012507

[2] HYDRAULIC FITTINGS

Item	Thread size	Tightening torque		
		N·m	kgf·m	lbf·ft
Adjustable elbow and adapter	9/16	37 to 44	3.7 to 4.6	27 to 33
	3/4	47 to 54	4.8 to 5.5	35 to 40
Hose fitting and flare nut	9/16	22 to 25	2.2 to 2.6	16 to 19
	3/4	35 to 41	3.6 to 4.1	26 to 30
	7/8	65 to 71	6.6 to 7.2	48 to 52
	1/4	30 to 35	3.1 to 3.6	22 to 26
Adapter (NPT)	3/8	39 to 44	3.9 to 4.4	28 to 32
	1/2	49 to 58	5.0 to 5.9	36 to 43

■ NOTE

- When connecting a hose with flare nut, after tightening the nut with specified torque, return it approximately 45 degrees and re-tighten it to specified torque.

W1013389

[3] TIGHTENING TORQUES OF SCREWS, BOLTS AND NUTS ON THE TABLE BELOW ARE ESPECIALLY SPECIFIED

Item	N·m	kgf·m	lbf·ft
Boom cylinder piston mounting nut	150 to 180	15.3 to 18.3	111 to 132
Bucket cylinder piston mounting nut	350 to 400	35.7 to 40.7	259 to 295
Main frame mounting bolt (M14)	147	15.0	108





W1012736

5. DISMOUNTING AND MOUNTING FRONT LOADER FROM TRACTOR

■ IMPORTANT

- When dismantling the loader, park the tractor on flat and hard ground, apply the parking brake.
- When starting the engine or using the hydraulic control valve, always sit in the operator's seat.

[1] DISMOUNTING FRONT LOADER FROM TRACTOR



Side Frame

1. Raise the boom until the stands (1) can be rotated.
2. Stop the engine.
3. Remove the spring pin (2) holding the stand (1) to the boom.
4. Slide the stands (1) leftward and rotate it until the hole in the stand and pin on the boom are aligned. Then slide the stand (1) rightward and insert the spring pin (2) as shown.
5. Start the engine and run at idle.
6. Dump the bucket approximately 20 degrees.
7. Lower the boom and raise the front wheels slightly.

■ IMPORTANT





- Lift the front wheels with the bucket. Do not attempt to lift the with the stand.
8. Stop the engine.
 9. Remove the mounting pins from the loader side frames and hold them in the plate of side frame.
 10. Start the engine and run at idle. Slowly move the hydraulic control lever (3) to rollback position to raise the loader side frames up and out of the receives of the main frames as shown.
 11. Stop the engine.
 12. Slowly release all hydraulic pressure by moving the hydraulic control lever (3) in all directions.
 13. Disconnect the four hoses with quick couplers at the control valve and place them on the right side of the boom.
 14. Place the protective caps and plugs (4) on the quick coupler ends.
 15. Start the engine and slowly back the tractor away from the loader.

- (1) Stand
(2) Spring Pin

- (3) Hydraulic Control Lever
(4) Protective Plug

W1012789

[2] MOUNTING FRONT LOADER TO TRACTOR



Side Frame and Hoses

1. Slowly drive the tractor between the loader side frames until the rear portion of both side frames touches the main frames as shown.
2. Stop the engine.
3. Connect four hoses with couplers to the nipple on the control valve as indicated with color marks. Then connect the protective caps and plugs to each other.
4. Start the engine and run at idle.
5. Slowly move the loader control lever to dump position to lower the side frames into the main frames and engage the bosses of the main frames to the guide bosses of the side frames. Then lift the front wheels slightly with the loader.

■ IMPORTANT

- **Do not attempt to lift the front wheels with the stand.**
6. Stop the engine. Reinstall the mounting pins and secure them with the locking rods.
 7. Start the engine.
 8. Raise the boom until the stand can be rotated.
 9. Stop the engine.
 10. Store the stand to their original positions and secure it with the spring pin as shown.
 11. Start the engine.
 12. Lower the boom and level the bucket.

- (1) Side Frame
(2) Main Frame
(3) Hose

- (4) Loader Control Lever
(5) Stand
(6) Spring Pin

W1020231

6. CHECKING, DISASSEMBLING AND SERVICING

[1] CONTROL VALVE

(1) Checking and Adjusting

Relief Valve Setting Pressure

■ NOTE

- The relief valve is not installed on this model. However the relief valve of the tractor hydraulic system is used as the relief valve of the front loader. Refer to hydraulic section.

(Reference)

Relief valve setting pressure	Factory specification	12.3 to 12.7 MPa 125 to 130 kgf/cm ² 1778 to 1849 psi
-------------------------------	-----------------------	--

Condition

- Engine speed : Maximum
- Oil temperature : 45 to 55 °C (113 to 131 °F)

W1014688

(2) Disassembling and Assembling



Step and Battery

⚠ CAUTION



- When disconnecting the battery cables, disconnect the negative cable from the battery first. When connecting, connect the positive cable to the battery first.

- Remove the under panel (1).
- Disconnect the negative cable (3) from the battery (2).
- Remove the valve covers (4).
- Remove the HST pedal (5) and the step (6).

- (1) Under Panel
(2) Battery
(3) Negative Cable

- (4) Valve Cover
(5) HST Pedal
(6) Step

W1012394



Control Valve

1. Remove the loader frame (6).
2. Disconnect the cruise control rod (2).
3. Disconnect the frame loader control rods (3).
4. Remove the brake spring.
5. Remove the arms (4) from spool end.
6. Remove the stay bolt (5).
7. Remove the valve stay (7).
8. Disconnect the pipes (1).
9. Remove the control valve (8) with pipes.

(When reassembling)

- After reassembling a valve, check for oil leakage by starting up engine.

■ IMPORTANT

- **When starting up engine, watch out for the rotating propeller shaft (9).**

(Reference)

- When adjusting the length of rods, make the lever come to the neutral position.

A : 145 mm (5.71 in.)


B : 315 mm (12.46 in.)

C : 448 mm (17.64 in.)

- | | |
|------------------------------|---------------------------------|
| (1) Pipe | (9) Propeller Shaft |
| (2) Cruise Control Rod | (10) Front Loader Control Lever |
| (3) Front Loader Control Rod | (11) Rod 1 |
| (4) Arm | (12) Rod 2 |
| (5) Stay | (13) Rod 3 |
| (6) Loader Frame | |
| (7) Valve Stay | |
| (8) Control Valve | |

W1013522

Disassembling Control Valve



- (1) Dust Seal
- (2) Dust Seal
- (3) Load Check Valve
- (4) Spring
- (5) O-ring
- (6) Plug
- (7) Bolt
- (8) Plug
- (9) Seat
- (10) Spring
- (11) Ball
- (12) Stopper
- (13) Ring
- (14) Bolt
- (15) Plug
- (16) Seat
- (17) Spring
- (18) Ball
- (19) Stopper
- (20) Ring
- (21) Spool
- (22) O-ring
- (23) Back-up Ring
- (24) Collar
- (25) Spring Holder
- (26) Spring
- (27) Spring Holder
- (28) Valve Body
- (29) Spool
- (30) O-ring
- (31) Back-up Ring
- (32) Collar
- (33) Spring Holder
- (34) Spring
- (35) Spring Holder

A, C : Boom Control Section
B, D : Bucket Control Section

W1016062


1. Remove the plugs (6) and take out the spring (4) and load check valve (3).
2. Remove the seal plates (8), (15) with other parts inside plug (C), (D).
3. Draw out the spools (21), (29) with other component parts (A), (B) from the valve body (28).

(When reassembling)

- Clean all parts with a suitable solvent, and dry with a lint-free cloth or air.
- Visually inspect all parts for damage,
- Install the spools to the valve body, not to damage the O-ring.

[2] BUCKET, BOOM AND HYDRAULIC CYLINDERS

(1) Disassembling and Assembling



Bucket and Bucket Cylinder


1. Remove the pins (4) and remove the bucket (3).
2. Disconnect the hydraulic hoses from the bucket cylinder (2).
3. Remove the pin (1) and remove the bucket cylinder (2).

(When reassembling)

- When installing the bucket cylinder (2), the hydraulic port should face inside and be careful of the direction of grease fittings.

- | | |
|---------------------|------------|
| (1) Pin | (3) Bucket |
| (2) Bucket Cylinder | (4) Pin |

W1016780



Boom Cylinder and Hydraulic Tubes



1. Disconnect the hydraulic hoses from the boom cylinders (4).
2. Remove the pins (2) and remove the boom cylinders (4).
3. Disconnect the hydraulic hoses (6) with quick couplers at the control valve.
4. Remove the pins (1) and remove the boom (3) from the side frame (5).
5. Remove the hydraulic tubes (7) from the boom (3).





(When reassembling)

- When installing the boom cylinders (4), the hydraulic port should face inside and be careful of the direction of grease fittings.

- | | |
|-------------------|--------------------|
| (1) Pin | (5) Side Frame |
| (2) Pin | (6) Hydraulic Hose |
| (3) Boom | (7) Hydraulic Tube |
| (4) Boom Cylinder | |

W1016879





Piston Rod Assembly

1. Drain hydraulic oil from the cylinder, and secure the tube end of the cylinder in a vise.
2. Unscrew the cylinder head (1) with the adjustable gland nut wrench (4).
3. Pull out the piston rod assembly (2) from the cylinder tube (3).

(When reassembling)

- Visually inspect the cylinder tube for signs of scoring or damage.
- Insert the piston rod assembly to the cylinder tube, not to damage the piston seal on the piston.
- Install the cylinder head to the cylinder tube, not to damage the O-ring on the cylinder head.

(1) Cylinder Head

(2) Piston Rod Assembly

(3) Cylinder Tube

(4) Adjustable Gland Nut Wrench

W1017050

Cylinder Head, Piston and Nut

1. Secure the rod end in a vise.
2. Unscrew the nut (4), and remove the piston (3) and cylinder head (2) from the piston rod (1).

(When reassembling)

- Visually inspect all parts for signs of scoring or damage.
- Insert the piston rod to the cylinder head, not to damage the wiper seal (5) and oil seal (6).

Tightening torque	Boom cylinder piston mounting nut	150 to 180 N·m 15.3 to 18.3 kgf·m 111 to 132 lbf·ft
	Bucket cylinder piston mounting nut	350 to 400 N·m 35.7 to 40.7 kgf·m 259 to 295 lbf·ft

(1) Piston Rod

(2) Cylinder Head

(3) Piston




(4) Nut

(5) Wiper Seal

(6) Oil Seal

(7) O-ring

W1017322



Piston Seal and O-ring

1. Remove the piston seal (2) and O-ring (3) from the piston (1).

■ IMPORTANT


- When installing the O-ring (3) and piston seal (2) to the piston (1), use the slide jig and correcting jig as shown in the figure.

	Boom Cylinder (40 mm (1.57 in.))	Bucket Cylinder (65 mm (2.56 in.))
A	80 °	80 °
B	0.157 rad 9 °	0.157 rad 9 °
C	40.18 mm dia. 1.582 in. dia.	65.18 mm dia. 2.566 in. dia.
D	41.18 mm dia. 1.621 in. dia.	66.18 mm dia. 2.606 in. dia.
E	42.0 mm 1.65 in.	42.0 mm 1.65 in.
F	10.0 mm 0.4 in.	10.0 mm 0.4 in.
G	58.5 mm 2.30 in.	58.5 mm 2.30 in.
H	14 mm 0.55 in.	14 mm 0.55 in.
I	35.0 mm 1.38 in.	35.0 mm 1.38 in.
J	0.122 rad 7 °	0.122 rad 7 °
K	40.2 mm dia. 1.583 in. dia.	65.2 mm dia. 2.567 in. dia.
L	48.9 mm dia. 1.925 in. dia.	73.9 mm dia. 2.909 in. dia.

- (1) Piston
(2) Piston Seal
(3) O-ring

- (a) Slide Jig
(b) Correcting Jig

W1017590



Installing O-ring and Piston Seal


1. Place the slide jig (2) on the piston (4).
2. Install the O-ring (3) to the piston using the slide jig.
3. Install the piston seal (1) over the O-ring using the slide jig.
4. Compress the piston seal to the correct size by installing the piston into the correcting jig (5).

■ NOTE


- Do not turn (roll) the piston seal as you install it.

- (1) Piston Seal
(2) Slide Jig
(3) O-ring
- (4) Piston
(5) Correcting Jig

W1018156



(2) Servicing



Piston Rod Bend


1. Place piston rod on V blocks.
2. Set a dial indicator on the center of the rod.
3. Turn the piston rod and read the dial indicator.
4. If the measurement exceeds the allowable limit, replace it.

Piston rod bend	Allowable limit	0.25 mm 0.0098 in.
-----------------	-----------------	-----------------------

W1017385

[3] SIDE FRAMES, FRONT GUARD AND MAIN FRAMES

(1) Disassembling and Assembling



Side Frames

1. Remove the pins (2), (5).
2. Remove the side frames (1) from the boom assembly (3) and the boom cylinder (4).

- | | |
|-------------------|-------------------|
| (1) Side Frame | (4) Boom Cylinder |
| (2) Pin | (5) Pin |
| (3) Boom Assembly | |

W1015835




Front Guard

1. Remove the front guard (1).

- (1) Front Guard

W1015954



Main Frames

1. Remove the main frame mounting bolts and nuts (2) from the tractor body.
2. Remove the main frame (1).

Tightening torque	Main frame mounting bolt (M14)	147 N·m 15.0 kgf·m 108 lbf·ft
-------------------	--------------------------------	-------------------------------------

- | | |
|----------------|------------------------------|
| (1) Main Frame | (2) Main Frame Mounting Bolt |
|----------------|------------------------------|

W1016042

EDITOR:

KUBOTA FARM & INDUSTRIAL MACHINERY SERVICE, LTD.

64, ISHIZU-KITAMACHI, SAKAI-KU, SAKAI-CITY, OSAKA, 590-0823, JAPAN

PHONE : (81)72-241-1129

FAX : (81)72-245-2484

E-mail : ksos-pub@kubota.co.jp
